

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Break Pusher Bar Execute
00011 "# Function :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG IDX_BKPB1 = 64;
00018 00001 LONG IDX_BKPB2 = 65;
00019 00002 LONG IDX_BKPBZ1 = 66;
00020 00003 LONG IDX_BKPBZ2 = 67;
00021 END_VAR;
00022
00023 00004 MSEE MPS270; " Break Pusher Bar Speed, Position Updat
e Set
00024
00025 00005 DB000001 = 0;
00026
00027 00006 IF ML05430 == 0;
00028 00007 DB000001 = 1;
00029 00008 IEND;
00030
00031 00009 IF ML05432 == 0;
00032 00010 DB000001 = 1;
00033 00011 IEND;
00034
00035 00012 IF ML05434 == 0;
00036 00013 DB000001 = 1;
00037 00014 IEND;
00038
00039 00015 IF !DB000001 == 1;
00040 00016 VEL [BKPBZ1]ML05430 [BKPBZ2]ML05430;
00041 00017 ACC [BKPBZ1]ML05432 [BKPBZ2]ML05432;
00042 00018 DCC [BKPBZ1]ML05434 [BKPBZ2]ML05434;
00043 00019 IEND;
00044
00045 " Interlock
00046 00020 IOW MB50790 & MB50791 == 1 " Break Pusher Bar Y Interference Check
00047
00048 " Break Pusher Bar Start Position Check
00049 00021 IOW (MB050742 & MB51023) | MB050728 ==
00050
00051 " Break Pusher Bar No Commanc
00052 00022 IOW MB050694 == 1
00053
00054 " Cutter Z Wait & Head X Wait
00055 00023 IOW MB045740 | MB045741 == 1;
00056
00057 " Cutting Table Vacuum ON
00058 00024 IF GL21158 > MW15411;
00059 00025 IF !MB00201D == 1 " P Work : Dumm
00060 " [Sensor] Cutting Table All Vacuum Off
00061 00026 IF MB09023F == 1;
00062 00027 MB09049F = 1; " [Sol] Cutting Table All Vacuum On
00063 00028 IOW MB09019F | MB00800 == 1 " Cutting Table Vacuum On Check
00064 00029 TIM TMW26206; " Cutting Table Vacuum On Delay Ti
00065 00030 IEND;
00066 00031 IOW MB09019F | MB00800 == 1 " Cutting Table Vacuum On Check
00067 00032 IEND;
00068 00033 IEND;
00069
00070 00034 IF MB000023 == 1;
00071 00035 MB045159 = 1; " Step Mode Next Fla
00072 00036 IOW (!MB21684D | MB20544E) | MB045013 == " Step Mode
00073 00037 MB045159 = 0; " Step Mode Next Fla
00074 00038 IEND;
00075
00076 " Break Pusher Bar Z Execute Permission
00077 00039 IOW MB050774 == 1;
00078
00079 00040 IOW MB51003 == 1 " Break Pusher Bar Y Start Position Comp
lete Chec
00080
00081 " ChcuK Break Start Flag Bit ON
00082 00041 MB050728 = 1;
00083
00084 00042 ML16132 = ML73218 " [Calc] BKPBZ1 Breaking Execute Positio
n

```

```
00085
00086 00043      PLD [BKPZ1][BKPZ2];
00087 00044      MOV [BKPZ1]ML16132 [BKPZ2]ML16132;
00088
00089      " Chcuk Break Start Flag Bit OFF
00090 00045      MB050728 = 0;
00091
00092 00046      IF MB000023 == 1;
00093 00047          MB045159 = 1;
00094 00048          IOW (!MB21684D | MB20544E) | MB045013 ==
00095 00049              MB045159 = 0;
00096 00050      IEND;
00097
00098 00051      RET;
```

			MPS263 : Break Pusher Bar Execute	P00002
--	--	--	-----------------------------------	--------