

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Last Break Pusher Bar Execute
00011 "# Function :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG IDX_BKPB1 = 64;
00018 00001 LONG IDX_BKPB2 = 65;
00019 00002 LONG IDX_BKPBZ1 = 66;
00020 00003 LONG IDX_BKPBZ2 = 67;
00021 END_VAR;
00022
00023 00004 MSEE MPS270; " Break Pusher Bar Speed, Position Updat
e Set
00024 00005 DB000001 = 0;
00025
00026
00027 00006 IF ML05430 == 0;
00028 00007 DB000001 = 1;
00029 00008 IEND;
00030
00031 00009 IF ML05432 == 0;
00032 00010 DB000001 = 1;
00033 00011 IEND;
00034
00035 00012 IF ML05434 == 0;
00036 00013 DB000001 = 1;
00037 00014 IEND;
00038
00039 00015 IF !DB000001 == 1;
00040 00016 VEL [BKPBZ1]ML05430 [BKPBZ2]ML05430;
00041 00017 ACC [BKPBZ1]ML05432 [BKPBZ2]ML05432;
00042 00018 DCC [BKPBZ1]ML05434 [BKPBZ2]ML05434;
00043 00019 IEND;
00044
00045
00046 // IF !MB090142 | !MB090143 == 1;
00047 // " Cutting Table Brush Brush Up Stat
00048 // MB090402 = 0;
00049 // MB090403 = 0;
00050 // TIM T100;
00051 // MB090442 = 1;
00052 // MB090443 = 1;
00053 // TIM T200;
00054 // IOW (MB090142 & MB090143) | (MB090442 & MB090443) == 1;
00055 //
00056 // IEND;
00057
00058 " Cutting Table Brush Up Status
00059 00020 IF !MB09014E == 1;
00060 " Cutting Table Brush Brush Up Status
00061 00021 MB09040E = 0;
00062 00022 MB09044E = 1;
00063 00023 IOW MB09014E == 1;
00064 00024 IEND;
00065
00066 " Interlock
00067 00025 IOW MB50790 & MB50791 == 1 " Break Pusher Bar Y Interference Check
00068
00069 " Break Pusher Bar Start Position Check
00070 00026 IOW MB050748 | MB050729 == 1
00071
00072 " Break Pusher Bar No Commanc
00073 00027 IOW MB050694 == 1;
00074
00075 00028 IF MB030036 == 1 " P Work : Break Table
00076 00029 IF MB05685F == 1 " Break Table Vacuum All Off
00077 " Break Table Vaccum On
00078 00030 MB05584F = 1; " Break Table Vacuum On Request
00079 00031 IOW MB05684F | MB000800 == 1 " Break Table Vacuum On Check
00080 00032 TIM TMW26202; " Break Table Vacuum On Delay Time
00081 00033 IEND;
00082 00034 IOW MB05684F | MB000800 == 1 " Break Table Vacuum On Check
00083 00035 IEND;
00084
00085 00036 IF MB000023 == 1;
00086 00037 MB045159 = 1; " Step Mode Next Fla

```

```
00087 00038      IOW (!MB21684D | MB20544E) | MB045013 ==      " Step Mode
00088 00039      MB045159 = 0;      " Step Mode Next Fla
00089 00040      IEND;
00090
00091 00041      IOW MB050768 & MB050778 == 1      " [BKPBZ] Last Break Start Position Perm
00092      ission      " [BKPBZ] Last Break Start Position Perm
00093      ission
00093      " Chcuk Break Start Flag Bit On
00094 00042      MB050729 = 1;
00095
00096 00043      IF ML73238 == 0;
00097 00044      ML16132 = ML73238      " [Calc] BKPBZ Last Breaking Start Posit
00098 00045      ion      ELSE;
00099 00046      ML16132 = ML73218      " [Calc] BKPBZ Breaking End Position
00100 00047      IEND;
00101
00102 00048      MOV [BKPBZ1]ML16132 [BKPBZ2]ML16132;
00103
00104      " Chcuk Break Start Flag Bit Off
00105 00049      MB050729 = 0;
00106
00107      " [Manual] Break Table Complete
00108 00050      IF !MB000004 & MB030036 & !MB000800 == 1;
00109 00051      IF MW00051 == 111      " SC PTP : Last Break Pusher Bar Breakin
00110 00052      g Execute 1 Cycle      MB05572F = 1;
00111 00053      IEND;
00112 00054      IEND;
00113
00114 00055      IF MB000023 == 1;
00115 00056      MB045159 = 1;      " Step Mode Next Fla
00116 00057      IOW (!MB21684D | MB20544E) | MB045013 ==      " Step Mode
00117 00058      MB045159 = 0;      " Step Mode Next Fla
00118 00059      IEND;
00119
00120 00060      RET;
```