

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Break Pusher Bar Escape (Unuse)
00011 "# Function :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG IDX_BKPBY1 = 64;
00018 00001 LONG IDX_BKPBY2 = 65;
00019 00002 LONG IDX_BKPBZ1 = 66;
00020 00003 LONG IDX_BKPBZ2 = 67;
00021 END_VAR;
00022
00023 00004 MSEE MPS270; " Break Pusher Bar Speed, Position Updat
e Set
00024
00025 " Inner Bit Reset
00026 00005 DW00001 = 0;
00027
00028 00006 IOW MB045741 & MB046000 & MB046020 == " Cutter X Waiting Position
00029
00030 00007 PFORK BKPBY1 BKPBY2;
00031
00032 BKPBY1:
00033 " Chuck Break Y Escape Position
00034 00008 IOW DB00011 == 1 " Chuck Break Z Escape Position Moving C
omplete
00035 00009 IF MB051000 == 0
00036 00010 ML16128 = ML72802 " Chuck Break Y Moving Position Write
00037 00011 IOW MB045741 == 1 " Cutter X Waiting Position
00038 00012 MOV [BKPBY1]ML16128 [BKPBY2]ML1612 " Chuck Break Y Pos. Moving
00039 00013 IOW MB051000 == 1 " Chuck Break Y Escape Position
00040 00014 IEND;
00041
00042 00015 DB00010 = 1; " Chuck Break Y Escape Position Moving C
omplete
00043 00016 JOINTO LabelX;
00044
00045 BKPBY2:
00046 " Chuck Break Z Waiting Position
00047 00017 IF MB05101A == 0;
00048 00018 IOW MB045741 == 1 " Cutter X Waiting Position
00049 00019 IOW MB045691 & MB045741 == 1 " Chuck Break Y Escape Position Moving C
omplete
00050 00020 ML16132 = ML73202 " Chuck Break Z1 Moving Position Write
00051 00021 MOV [BKPBY1]ML16132 [BKPBY2]ML1613 " Chuck Break Z Pos. Movin
00052 00022 IOW MB05101A == 1 " Chuck Break Z Escape Position Check
00053 00023 IEND;
00054
00055 00024 DB00011 = 1; " Chuck Break Z Escape Position Moving C
omplete
00056 00025 JOINTO LabelX;
00057 00026 LabelX: PJOINT;
00058
00059 " Chuck Break Y Waiting Position Moving Permission
00060 00027 IOW MB50760 == 1 " Chuck Break Y Escape Position Move Per
mission
00061
00062 00028 ML16128 = ML72802 " Chuck Break Y Moving Position Write
00063
00064 00029 MOV [BKPBY1]ML16128 [BKPBY2]ML1612 " Chuck Break Y Pos. Moving
00065 00030 IOW MB51000 == 1 " Chuck Break Y Escape Position
00066
00067 00031 RET;

```