

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : Break Table Receive
00011 "# Function :
00012 "# Call Program : MPM05
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG IDX_BKTY1 = 69;
00018 00001 LONG IDX_BKTY2 = 70;
00019 00002 LONG IDX_BKTZ1 = 72;
00020 00003 LONG IDX_BKTZ2 = 73;
00021 00004 LONG IDX_BKTZ3 = 74;
00022 00005 LONG IDX_BKTT1 = 75;
00023 00006 LONG IDX_BKTT2 = 76;
00024 END_VAR;
00025
00026 00007 MSEE MPS310; " Break Table Speed, Position Update
Set
00027
00028 00008 IF MB000004 == 0; " Automatic Driving
00029 " Break Pusher Bar Waiting Position Check
00030 00009 IOW MB051020 | MB051023 == 1;
00031 00010 IEND;
00032
00033 " Cutter X Waiting Position
00034 00011 IOW MB045741 | MB046001 | MB045740 == 1;
00035
00036 " Break Table Glass Data Not Exist
00037 00012 IF ML05310 == 0 " Last Break Select (1:Use, 0:Not Us
e)
00038 00013 IOW !MB030036 == 1 " P Work : Break Table
00039 00014 IEND;
00040
00041 " Break Table Vacuum Off
00042 00015 IF !MB05685F == 1;
00043 00016 IF ML05310 <> 1;
00044 " Break Table Vacuum Off
00045 00017 MB05585F = 1; " Break Table Vacuum Off Request
00046 00018 IEND;
00047 00019 IEND;
00048
00049 00020 IF !MB030036 == 1 " P Work : Break Table
00050 00021 IF !MB05686F == 1; " Break Table Vacuum Break On
00051 " Break Table Blow On
00052 00022 MB05586F = 1; " Break Table Blow On Request
00053 00023 IEND;
00054 00024 IEND;
00055
00056 00025 IF !MB030035 & MB030036 & MB053100 & !MB045132 == 1;
00057 00026 IOW MB05684F | MB00800 == 1 " Break Table Vacuum On Check
00058 00027 ELSE;
00059 00028 IOW MB05685F | MB00800 == 1 " Break Table Vacuum Off Check
00060 00029 IEND;
00061
00062 00030 IF MB000023 == 1;
00063 00031 MB045159 = 1; " Step Mode Next Fla
00064 00032 IOW (!MB21684D | MB20544E) | MB045013 == " Step Mode
00065 00033 MB045159 = 0; " Step Mode Next Fla
00066 00034 IEND;
00067
00068 " Inner Bit Reset
00069 00035 DW00001 = 0;
00070 00036 PFORK TBL_Y2 TBL_Z2 TBL_T2;
00071
00072 TBL_Y2:
00073 " Break Table Y
00074 00037 IOW MB055790 & MB055791 & MB055792 == " Break Table Y Interference Check
00075
00076 00038 IOW (MB058920 & MB056800 | !MB058920) == 1 " Break Table Brush Fla
00077
00078 00039 ML16138 = ML73810 " Break Table Y Moving Position Writ
e
00079
00080 00040 IOW MB055762 == 1 " Break Table Y Receive Position Mov
ing Permission
00081
00082 00041 IF !MB056002 == 1;
00083 00042 MOV [BKTY1]ML16138 [BKTY2]ML16138 " Break Table Y Pos. Moving

```

```

00084 00043          IOW MB056002 == 1          " Break Table Y Receive Position
00085 00044          IEND;
00086 00045          DB000010 = 1;              " Break Table Y Receive Position Mov
ing Complete
00087
00088 00046          MB05580E = 0;
00089 00047          MB05580F = 0;
00090 00048          TIM T100;
00091          " Brush Up
00092 00049          MB05582E = 1;
00093 00050          MB05582F = 1;
00094
00095 00051          JOINTO LabelX;
00096
00097          TBL_Z2:
00098          " Break Table :
00099 00052          ML16144 = ML74410          " Break Table Z Moving Position Writ
e
00100
00101 00053          IOW DB000010 & DB000012 == 1;
00102
00103 00054          IOW MB055772 == 1          " Break Table Z Receive Position Mov
ing Permission
00104
00105 00055          IF !MB056022 == 1;
00106 00056          MOV [BKTZ1]ML16144 [BKTZ2]ML16144 [BKTZ3]ML16144 " Break Table Z Pos. Movin ;
00107 00057          IOW MB056022 == 1;
00108 00058          IEND;
00109 00059          DB000011 = 1;              " Break Table Y Receive Position Mov
ing Complete
00110
00111 00060          JOINTO LabelX;
00112
00113          TBL_T2:
00114
00115          " Brush 1 Cycle Execut
00116 00061          IF MB000004 & MB058920 == 1          " Break Table Brush Flag
00117 00062          MB05582E = 0;
00118 00063          MB05582F = 0;
00119 00064          TIM T100;
00120          " Brush Down
00121 00065          MB05580E = 1;
00122 00066          MB05580F = 1;
00123
00124 00067          ELSE;
00125 00068          MB05580E = 0;
00126 00069          MB05580F = 0;
00127 00070          TIM T100;
00128          " Brush Up
00129 00071          MB05582E = 1;
00130 00072          MB05582F = 1;
00131 00073          IEND;
00132
00133          " Break Table :
00134 00074          ML16150 = ML75002          " Break Table T Moving Position Writ
e
00135
00136 00075          IOW MB055780 == 1          " Break Table T Receive Position Mov
ing Permission
00137
00138 00076          IF !MB056050 == 1;
00139 00077          MOV [BKTT1]ML16150 [BKTT2]ML16150, " Break Table T Pos. Movin ;
00140 00078          IOW MB056050 == 1;
00141 00079          IEND;
00142
00143 00080          DB000012 = 1;              " Break Table T Receive Position Mov
ing Complete
00144
00145 00081          JOINTO LabelX;
00146 00082          LabelX: PJOINT;
00147
00148          " 스크라이브 척 얼라이먼트 위치 이동간 브레이크 테이블 블로우 Off됨
00149          " 픽스, 커팅, 브레이크 테이블에 대한 흡착/파기 지령은 스크라이브 유닛에서 관장함
00150          " 추후 특이사항 없을 경우 아래 부분 삭제
00151          " Break Table Blow All Off
00152          // MB05587F = 1;
00153          // IOW MB05687F == 1;
00154
00155          " Break Cleaning Brush Up Statu
00156 00083          IOW MB05682E & MB05682F == 1;
00157
00158 00084          RET;

```