

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG Axis_MTRY1 = 3;
00018     CONST LONG Axis_MTRY2 = 4;
00019     CONST LONG Axis_MTRX  = 5;
00020     CONST LONG Axis_MTRZ1 = 6;
00021     CONST LONG Axis_MTRZ2 = 7;
00022     CONST LONG Axis_MTRT  = 8;
00023     CONST LONG Axis_MPALX = 10;
00024     CONST LONG Axis_MPARX = 11;
00025     CONST LONG Axis_MMCRX = 12
00026 END_VAR;
00027
00028 00000     PLD [MTRY1] [MTRY2] [MTRX] [MTRZ1] [MTRZ2] [MTRT] [MMCRX];
00029
00030 00001     DW00000 = 0;
00031 00002     DL00010 = 5000;
00032
00033 00003     IF ILAE96 > ML46162;
00034 00004         DL00020 = ILAE96 - ML46162;
00035 00005     ELSE;
00036 00006         DL00020 = ML46162 - ILAE96;
00037 00007     IEND;
00038
00039 00008     IF DL00020 > DL00010
00040 00009         DB000000 = 1;
00041 00010     IEND;
00042
00043 00011     IF !MB071020 == 1                                " Main Transfer Z St
andby Pos
00044 00012         MW07344 = 1;
00045 00013         MSEE MPS412;
00046 00014     IEND;
00047
00048 00015     IF !MB071010 == 1                                " Main Transfer X St
andby Pos
00049 00016         MW07342 = 1;
00050 00017         MSEE MPS411;
00051 00018     IEND;
00052
00053 00019     IF !MB071039 == 1                                " Main Transfer T MCR Po
s
00054 00020         IF DB000000 == 1
00055 00021             MSEE MPS416;                                " Main Transfer Turn Pos
00056 00022         IEND;
00057 00023     IEND;
00058
00059 00024     PFORK MTRY MTRX MTRT MMCRX;
00060
00061     MTRY:
00062
00063 00025         IOW MB071039 == 1                                " Main Transfer T MCR Po
s Check
00064
00065 00026         IF !MB071005 == 1                                " Main Transfer Y MCR Po
s
00066
00067 00027             IOW MB070765 == 1                                " Main Transfer Y MCR Po
s Enable
00068
00069 00028             ML16006 = ML60630                                " Move Data:Main Transfe
r Y MCR Pos
00070 00029             MOV [MTRY1]ML16006 [MTRY2]ML16006;
00071
00072 00030             IOW MB071005 == 1                                " Main Transfer Y MCR Po
s Moving Comp Check
00073 00031             IEND;
00074
00075 00032             JOINTO Label0X;
00076
00077     MTRX:
00078
00079 00033             IOW MB071039 == 1                                " Main Transfer T MCR Po

```

```

s Check
00080
00081 00034      IF !MB071015 == 1          " Main Transfer X MCR Po
s
00082 00035      IOW MB070775 == 1          " Main Transfer X MCR Po
s Enable
00083
00084 00036      ML16010 = ML61018          " Move Data:Main Transfe
r X MCR Pos
00085 00037      MOV [MTRX]ML16010;
00086
00087 00038      IOW MB071015 == 1          " Main Transfer X MCR Po
s Moving Comp Check
00088 00039      IEND;
00089
00090 00040      JOINTO Label0X,
00091
00092      MTRT:
00093
00094 00041      IF !MB071039 == 1          " Main Transfer T MCR Po
s
00095 00042      IOW MB070789 == 1          " Main Transfer T MCR Po
s Enable
00096
00097 00043      ML16016 = ML72234          " Move Data:Main Transfe
r T MCR Pos
00098 00044      MOV [MTRT]ML16016;
00099
00100 00045      IOW MB071039 == 1          " Main Transfer T MCR Po
s Moving Comp Check
00101 00046      IEND;
00102
00103 00047      JOINTO Label0X;
00104
00105      MMCRX:
00106
00107
00108 00048      IF !MB071061 == 1          " Main MCR Camera X MCR
Pos
00109 00049      IOW MB070799 == 1          " Main MCR Camera X MCR
Pos Enable
00110
00111 00050      ML16020 = ML62406          " Move Data:Main MCR Cam
era X MCR Pos
00112 00051      MOV [MMCRX]ML16020;
00113
00114 00052      IOW MB071061 == 1          " Main MCR Camera X MCR
Pos Moving Comp Check
00115 00053      IEND;
00116
00117 00054      JOINTO Label0X,
00118
00119      Label0X: PJOINT;
00120 00055
00121
00122 00056      IF !MB071025 == 1          " Main Transfer Z MCR Po
s
00123 00057      MW07344 = 6;
00124 00058      MSEE MPS412;
00125 00059      IEND;
00126
00127
00128 00060      MB071372 = 0;          " Unit7 Cycle1 Move Chec
k
00129
00130 00061      RET;

```