

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      : MPM082
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 00000      MB21460A = 1;           " (MTR)Recipe Update Request
00021 00001      IOW MB20520A == 1     " (MTR)Recipe Update Responce
00022
00023 00002      DB000001 = 0;         " 1st Alignment Comp Clear
00024 00003      DB000002 = 0;         " 2nd Alignment Comp Clear
00025
00026 00004      DL00060 = 0;           " Turn Center X Result
00027 00005      DL00062 = 0;           " Turn Center Y Result
00028 00006      CLR DW00010 W10;
00029 00007      CLR DW00030 W10;      " Turn Center X Data Table (5 Ti
mes)
00030 00008      CLR DW00040 W10;      " Turn Center Y Data Table (5 Ti
mes)
00031
00032 00009      DL00052 = ML60626      " MTRY Alignment Positio
00033 00010      DL00054 = ML62006      " MPALX Alignment Positic
00034 00011      DL00056 = ML62206      " MPARX Alignment Positic
00035 00012      DL00070 = 0;         " MTR T Current Pos Save (Before
Turn)
00036 00013      DL00072 = 0;         " MTR T Current Pos Save (After
Turn)
00037 00014      DL00080 = 0;         " MTR Turn Count
00038 00015      MB07360F = 0;         " MTR Center Calc Excecute Clear
00039
00040 00016      IF ML30344 <> 0       " Machine Parameter : Turn Value
<> 0
00041 00017      WHILE DL00080 < 5;
00042
00043 00018      IF (MB002002 | MB000800) == 1      " P Work: MTR or Dummy
Run
00044 00019      MB07360F = 1;           " MTR Center Calc Excecu
te
00045 00020      IF !MB071020 == 1;
00046 00021      MW07344 = 1;
00047 00022      MSEE MPS412;
00048 00023      IEND;
00049 00024      MSEE MPS421;           " MTR PreAlignment Pos M
ove
00050 00025      TIM T500;
00051 00026      EOX;
00052 00027      DL00070 = ILAE96      " MTR T Current Pos Save
00053
00054      "1st Alignment Exec
00055 00028      MSEE MPS426;
00056
00057 00029      DL00010 = ML23108      " Alignment Data X1
00058 00030      DL00012 = (ML23110 * -1) " Alignment Data Y1
00059 00031      DL00014 = ML23112      " Alignment Data X2
00060 00032      DL00016 = (ML23114 * -1) " Alignment Data Y2
00061 00033      DB000001 = 1;         " 1st Alignment Comp
00062
00063 00034      IF DB000001 == 1      " 1st Alignment Comp
00064
00065 00035      DL00018 = DL00070 + ML30344 " MTR Turn Target Pos
00066
00067 00036      PLD [MTRT];
00068 00037      MOV [MTRT]DL00018;
00069 00038      TIM T500;
00070 00039      EOX;
00071
00072 00040      DL00072 = ILAE96      " MTR T Current Pos Save
(After Turn)
00073
00074      "2nd Alignment Exec
00075 00041      MSEE MPS426;
00076
00077 00042      DL00020 = ML23108      " Alignment Data X1
00078 00043      DL00022 = (ML23110 * -1) " Alignment Data Y1

```

```
00079 00044          DL00024 = ML23112          " Alignment Data X2
00080 00045          DL00026 = (ML23114 * -1)    " Alignment Data Y2
00081 00046          DB000002 = 1;              " 2nd Alignment Comp
00082 00047          IEND;
00083
00084 00048          IF (DB000001 & DB000002) == 1      " 1st,2nd Alignment Comp

00085
00086 00049          DL00028 = DL00072 - DL00070      " MTR T Turn Θ
00087
00088          " Transfer Turn Center Calculation
00089 00050          UFC TR_CEN DL00010 DL00012 DL00020 DL00022 DL00028,,DB000003 DL00030[DL00100] DL
00040[DL00100];
00090 00051          IEND;
00091 00052          IEND;
00092 00053          EOX;
00093 00054          DL00080 = DL00080 + 1;
00094 00055          MB07360F = 0;                      " MTR Center Calc Excecu
te
00095 00056          WEND;
00096
00097 00057          DL00060 = (DL00030 + DL00032 + DL00034 + DL00036 + DL00038)/      " Turn Center X Result
00098 00058          DL00062 = (DL00040 + DL00042 + DL00044 + DL00046 + DL00048)/      " Turn Center Y Result
00099
00100
00101          "DL00000 = DL00060;"      "(MCDATA 영역 할당 필요)
00102          "DL00002 = DL00062;"      "(MCDATA 영역 할당 필요)
00103 00059          ML23948 = DL00060;"      "(비휘발성 메모리 임시 저장용)
00104 00060          ML23950 = DL00062;"      "(비휘발성 메모리 임시 저장용)
00105
00106          "MB21539F = 1,              (Dialog 호출 -> 등록 버튼 -> 확인 버튼 -> 장치파라미터에 Write)
00107          "IOW MB20039F == 1;
00108          "MB21539F = 0;
00109 00061          IEND;
00110
00111 00062          RET;
```