

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG AXIS_STR1Z1 = 6;
00018     CONST LONG AXIS_STR1Z2 = 7;
00019 END_VAR;
00020
00021 00000     PLD [STR1Z1][STR1Z2];
00022 00001     VEL [STR1Z1]ML41812 [STR1Z2]ML41812;
00023
00024 00002     DW00030 = MW07844                                " Stick Transfer 1 Z Motion Code Setting
00025
00026 00003     SFORK    DW00030 == 1 ? LBL01                      " Stick Transfer 1 Z Standby Pos
00027                  DW00030 == 2 ? LBL02                      " Stick Transfer 1 Z Carry In Pos
00028                  DW00030 == 3 ? LBL03                      " Stick Transfer 1 Z Carry Out Pos
00029                  DW00030 == 4 ? LBL04                      " Stick Transfer 1 Z PreAlign Pos
00030                  DW00030 == 5 ? LBL05                      "
00031                  DW00030 == 6 ? LBL06                      "
00032                  DW00030 == 7 ? LBL07                      "
00033                  DW00030 == 8 ? LBL08                      "
00034                  DEFAULT ? LBL100;
00035
00036 00004     LBL01:
00037
00038 00005         IOW MB075770 == 1                                " Stick Transfer 1 Z Standby Pos Enable
00039
00040 00006         ML16036 = ML63602                                " Move Data:Stick Transfer 1 Z StandBy P
00041 os
00042         MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00043 00008         IOW MB076010 == 1                                " Stick Transfer 1 Z Pos Moving Comp Che
00044 ck
00045 00009         JOINTO LBL0X;
00046
00047 00010     LBL02:
00048
00049 00011         IOW MB075771 == 1                                " Stick Transfer 1 Z Carry In Pos Enable
00050
00051 00012         ML16036 = ML63606                                " Move Data:Stick Transfer 1 Z Carry In
00052 Pos
00053         MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00054 00014         IOW MB076011 == 1                                " Stick Transfer 1 Z Carry In Pos Moving
00055     Comp Check
00056 00015         JOINTO LBL0X;
00057
00058 00016     LBL03:
00059
00060 00017         IOW MB075772 == 1                                " Stick Transfer 1 Z Carry Out Pos Enabl
00061 e
00062 00018         ML16036 = ML63610                                " Move Data:Stick Transfer 1 Z Carry Out
00063 Pos
00064         MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00065 00020         IOW MB076012 == 1                                " Stick Transfer 1 Z Carry Out Pos Movin
00066     g Comp Check
00067 00021         JOINTO LBL0X;
00068
00069 00022     LBL04:
00070
00071 00023         IOW MB075773 == 1                                " Stick Transfer 1 Z PreAlign Pos Enable
00072
00073 00024         ML16036 = ML41842                                " Move Data:Stick Transfer 1 Z PreAlign
00074 Pos
00075         MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00076 00026         IOW MB076013 == 1                                " Stick Transfer 1 Z PreAlign Pos Moving
00077     Comp Check
00078 00027         JOINTO LBL0X;

```

```

00079
00080 00028      LBL05:
00081
00082 00029      JOINTO LBL0X;
00083
00084 00030      LBL06:
00085
00086 00031      JOINTO LBL0X;
00087
00088 00032      LBL07:;
00089
00090 00033      JOINTO LBL0X;
00091
00092 00034      LBL08:;
00093
00094 00035      JOINTO LBL0X;
00095
00096 00036      LBL100:
00097 00037      JOINTO LBL0X;
00098 00038      LBL0X: SJOINT;
00099
00100
00101 00039      SFORK    DW00030 == 9    ? LBL09      " Stick Transfer 1 Z 2 Pos Carry In Befo
re Pos
00102          DW00030 == 10   ? LBL10      " Stick Transfer 1 Z 2 Pos Carry In Pos
00103          DW00030 == 11   ? LBL11      " Stick Transfer 1 Z 2 Pos Carry Out Bef
ore Pos
00104          DW00030 == 12   ? LBL12      " Stick Transfer 1 Z 2 Pos Carry Out Pos
00105          DW00030 == 13   ? LBL13      " Stick Transfer 1 Z Vacuum Retry Pos
00106          DW00030 == 14   ? LBL14      " Stick Transfer 1 Z Before Carry In Pos

00107          DW00030 == 15   ? LBL15      "
00108          DW00030 == 16   ? LBL16      "
00109          DEFAULT      ? LBL101;
00110
00111 00040      LBL09:
00112
00113 00041      IOW MB075771 == 1      " Stick Transfer 1 Z Carry In Pos Enable
00114
00115 00042      ML16036 = ML63606 - GL51106      " Move Data:Stick Transfer 1 Z 2 Pos Car
ry In Before Pos
00116 00043      VEL [STR1Z1]ML41812 [STR1Z2]ML41812;
00117 00044      IF GL51104 <> 0;
00118 00045      IF MB002006 == 1;
00119 00046      VEL [STR1Z1]GL51104 [STR1Z2]GL51104;
00120 00047      IEND;
00121 00048      IEND;
00122 00049      MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00123
00124 00050      JOINTO LBL1X;
00125
00126 00051      LBL10:
00127
00128 00052      IOW MB075771 == 1      " Stick Transfer 1 Z Carry In Pos Enable
00129
00130 00053      ML16036 = ML63606      " Move Data:Stick Transfer 1 Z 2 Pos Car
ry In Pos
00131      //VEL [STR1Z1]GL51104 [STR1Z2]GL51104;
00132      //IF GL51104 == 0;
00133 00054      VEL [STR1Z1]ML41812 [STR1Z2]ML41812;
00134      //IEND;
00135 00055      MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00136
00137 00056      IOW MB076011 == 1      " Stick Transfer 1 Z Carry In Pos Moving
Comp Check
00138
00139 00057      JOINTO LBL1X;
00140
00141 00058      LBL11:
00142
00143 00059      IOW MB075772 == 1      " Stick Transfer 1 Z Carry Out Pos Enabl
e
00144
00145 00060      ML16036 = ML63610 - GL51112      " Move Data:Stick Transfer 1 Z 2 Pos Car
ry Out Before Pos
00146 00061      MOV [STR1Z1]ML16036 [STR1Z2]ML1603
00147
00148 00062      JOINTO LBL1X;
00149
00150 00063      LBL12:
00151
00152 00064      IOW MB075772 == 1      " Stick Transfer 1 Z Carry Out Pos Enabl
e
00153
00154 00065      ML16036 = ML63610      " Move Data:Stick Transfer 1 Z 2 Pos Car
ry Out Pos
00155 00066      VEL [STR1Z1]GL51110 [STR1Z2]GL51110;

```

```
00156 00067      IF GL51110 == 0;
00157 00068          VEL [STR1Z1]ML41812 [STR1Z2]ML41812;
00158 00069      IEND;
00159 00070      MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00160
00161 00071      IOW MB076012 == 1                                " Stick Transfer 1 Z Carry Out Pos Movin
g Comp Chec
00162 00072          JOINTO LBL1X;
00163
00164 00073      LBL13:
00165
00166 00074          IOW MB075771 == 1                                " Stick Transfer 1 Z Carry In Pos Enable
00167
00168 00075          ML16036 = ML63606 - GL51102                    " Move Data:Stick Transfer 1 Z 2 Pos Car
ry In Vacuum Retry Pos
00169 00076          MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00170
00171 00077          IOW MB076019 == 1                                " Stick Transfer 1 Z Carry In Vacuum Ret
ry Pos Moving Comp Check
00172
00173 00078          JOINTO LBL1X;
00174
00175 00079      LBL14:
00176
00177 00080          IOW MB07577A == 1                                " Stick Transfer 1 Z Before Carry In Pos
Enable
00178 00081          ML16036 = ML41870                                " Move Data:Stick Transfer 1 Z 2 Pos Car
ry In Pos
00179
00180 00082          MOV [STR1Z1]ML16036 [STR1Z2]ML16036;
00181
00182 00083          IOW MB07601A == 1                                " Stick Transfer 1 Z Carry In Pos Moving
Comp
00183 00084          JOINTO LBL1X;
00184
00185 00085      LBL15:
00186
00187 00086          JOINTO LBL1X;
00188
00189 00087      LBL16:
00190
00191 00088          JOINTO LBL1X;
00192
00193 00089      LBL101:
00194 00090          JOINTO LBL1X;
00195 00091      LBL1X: SJOINT;
00196
00197
00198 00092          DW00030 = 0;                                " Stick Transfer 1 Z Motion Code Reset
00199 00093          MW07844 = 0;                                " Stick Transfer 1 Z Motion Code Reset
00200
00201 00094      RET;
```