

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 00000      PLD [STR1Y1][STR1Y2][STR1Z1][STR1Z2];
00021
00022 00001      MW07527 = 0;                                " Stick Transfer 1 PIO Reset
00023
00024 00002      IF MB080280 == 1                                " [Stick Buffer Table -> Stick Transfer
00025 00003      1) Receive Possible                               MB075270 = 1;                                " [Stick Transfer 1 -> Stick Buffer Tabl
00026 00004      e) Send Possible                                   IOW MB080281 == 1                                " [Stick Buffer Table -> Stick Transfer
00027 00005      1) Receive Start
00028 00005      MB075271 = 1;                                " [Stick Transfer 1 -> Stick Buffer Tabl
00029 00006      e) Send Strat
00030 00006      IF GL51108 == 0                                " Stick Transfer 1 2 Pos Carry Out Mode
00031 00007      (0:Use 1:Unuse)                                IF GL51112 <> 0                                " Stick Transfer 1 2 Pos Carry Out Dista
00032 00008      nce                                           MW07844 = 11;                                " Stick Transfer 1 Z 2 Pos Carry Out Bef
00033 00009      ore Pos                                           MSEE MPS471;
00034
00035 00010      MW07844 = 12;                                " Stick Transfer 1 Z 2 Pos Carry Out Pos
00036 00011      MSEE MPS471;
00037 00012      ELSE;
00038 00013      MW07844 = 3;                                " Stick Transfer 1 Z Carry Out Pos
00039 00014      MSEE MPS471;
00040 00015      IEND;
00041 00016      ELSE;
00042 00017      MW07844 = 3;                                " Stick Transfer 1 Z Carry Out Pos
00043 00018      MSEE MPS471;
00044 00019      IEND;
00045
00046      //      IF !MB080013 == 1;
00047 00020      MB075275 = 1;                                " [Stick Transfer 1 -> Stick Buffer Tabl
00048 00021      e) Vacuum On Request 0                               MB075898 = 1;                                " Stick Transfer 1 Vacuum Off
00049 00022      IOW MB07689C == 1                                " Stick Transfer 1 Vacuum Off Chec k
00050 00023      IF !MB000800 == 1
00051 00024      MB07588C = 1;                                " Stick Transfer 1 Vacuum Break On
00052 00025      IOW MB07688C | MB000800 == 1                " Stick Transfer 1 Vacuum Break On C
00053 00026      heck                                           TIM TMW30410;                                " Stick Transfer 1 Vacuum Break Conf
00054 00027      irm Timer                                           ELSE;
00055 00028      TIM TMW30410;
00056 00029      IEND;
00057
00058 00030      IOW MB002007 | MB080013 == 1                                " P Wokr : Stick Buffer Tabl
00059 00031      //      IEND;
00060
00061      //      IF !MB080013 == 1;
00062 00031      IOW MB080282 == 1                                " [Stick Buffer Table -> Stick Transfer
00063
00064 00032      1) Receive Complete                               MW07844 = 1;                                " Stick Transfer 1 Z Standby Pos
00065 00033      MSEE MPS471;
00066
00067 00034      MB075275 = 0;                                " [Stick Transfer 1 -> Stick Buffer Tabl
00068 00035      e) Vacuum On Request Of                               MB075272 = 1;                                " [Stick Transfer 1 -> Stick Buffer Tabl
00069
00070 00036      e) Send Complet                                           MB07589C = 1;                                " Stick Transfer 1 Vacuum Break O:
00071 00037      IOW MB07689C == 1                                " Stick Transfer 1 Vacuum Break Off Chec
00072
00073 00038      k                                           IOW MB080282 == 0                                " [Stick Buffer Table -> Stick Transfer

```

```

1] Receive Complet
00074 //      ELSE;
00075 //      MB075275 = 0;
                                " [Stick Transfer 1 -> Stick Buffer Tabl
e] Vacuum On Request Of
00076 //      MW07844 = 1;
                                " Stick Transfer 1 Z Standby Po
00077 //      MSEE MPS471;
00078 //      IEND;
00079
00080 00039      MW07527 = 0;
00081 00040      IEND;
00082 00041      MB076370 = 0;
                                " Unit8 Cycle1 Move Check
00083
00084 00042  RET;

```

			MPS479 : STR1 Cycle 5 (Stick Transfer Carry Out PIO)	P00002
--	--	--	--	--------