

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG AXIS_SBTY = 21;
00018     CONST LONG AXIS_SBYX = 22;
00019 END_VAR;
00020
00021 00000     PLD [SBTY][SBTT];
00022 00001     VEL [SBTY]ML42112 [SBTT]ML46212;
00023
00024 00002     IF !MB000004 == 1;
00025 00003         IOW MB075293 & MB07529B == 1           " Stick Transfer 2 Z Standby Position
00026 00004     ELSE;
00027 00005         IOW (MB075293 | MB117013B) & (MB07529B | MB118014B) ==  " Stick Transfer 2 Z Standby Pos
00028 00006     IEND;
00029
00030 00007     DW00030 = MW08340           " Stick Buffer Table Y Motion Code Setti
00031 ng
00032 00008     SFORK     DW00030 == 1 ? LBL01
00033                 DW00030 == 2 ? LBL02
00034                 DW00030 == 3 ? LBL03
00035                 DW00030 == 4 ? LBL04
00036                 DW00030 == 5 ? LBL05
00037                 DW00030 == 6 ? LBL06
00038                 DW00030 == 7 ? LBL07
00039                 DW00030 == 8 ? LBL08
00040                 DEFAULT ? LBL100;
00041
00042 00009     LBL01:
00043
00044 00010         IOW MB080760 == 1           " Stick Buffer Table Y StandBy Pos Enabl
00045 e
00046 00011         ML16042 = ML42130           " Move Data:Stick Buffer Table Y StandBy
00047 00012     Pos
00048         MOV [SBTY]ML16042;
00049 00013         IOW MB081000 == 1           " Stick Buffer Table Y StandBy Pos Movin
00050 g Comp Check
00051
00052 00014         JOINTO LBL0X;
00053
00054 00015     LBL02:
00055
00056 00016         IOW MB080761 == 1           " Stick Buffer Table Y Turn Pos Enable
00057
00058 00017         ML16042 = ML42142           " Move Data:Stick Buffer Table Y Turn Po
00059 00018     s
00060         MOV [SBTY]ML16042;
00061 00019         IOW MB081001 == 1           " Stick Buffer Table Y Turn Moving Comp
00062 Check
00063 00020         JOINTO LBL0X;
00064
00065 00021     LBL03:
00066
00067 00022         IOW MB080762 == 1           " Stick Buffer Table Y Carry In Pos Enab
00068 le
00069 00023         ML16042 = ML64206           " Move Data:Stick Buffer Table Y Carry I
00070 00024     n Pos
00071         MOV [SBTY]ML16042;
00072 00025         IOW MB081002 == 1           " Stick Buffer Table Y Carry In Pos Movi
00073 ng Comp Check
00074
00075         JOINTO LBL0X;
00076 00027     LBL04:
00077

```

```
00078 00028      IOW MB080763 == 1      " Stick Buffer Table Y Carry Out Pos Ena
ble
00079
00080 00029      ML16042 = ML64210      " Move Data:Stick Buffer Table Y Carry O
ut Pos
00081 00030      MOV [SBTY]ML16042;
00082
00083 00031      IOW MB081003 == 1      " Stick Buffer Table Y Carry Out Pos Mov
ing Comp Check
00084
00085 00032      JOINTO LBL0X;
00086
00087 00033      LBL05:
00088
00089 00034      JOINTO LBL0X;
00090
00091 00035      LBL06:
00092
00093 00036      JOINTO LBL0X;
00094
00095 00037      LBL07:
00096
00097 00038      JOINTO LBL0X;
00098
00099 00039      LBL08:
00100
00101 00040      JOINTO LBL0X;
00102
00103 00041      LBL100:
00104 00042      JOINTO LBL0X;
00105 00043      LBL0X: SJOINT;
00106
00107
00108 00044      DW00030 = 0;      " Unit9 Stick Buffer Table Y Motion Code
Reset
00109 00045      MW08340 = 0;      " Unit9 Stick Buffer Table Y Motion Code
Reset
00110
00111 00046      RET;
```