

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG AXIS_SBTY = 21;
00018     CONST LONG AXIS_SBYX = 22;
00019 END_VAR;
00020
00021 00000     PLD [SBTY][SBTT];
00022 00001     VEL [SBTY]ML42112 [SBTT]ML46212;
00023
00024     "SBT Brush Up Status
00025 00002     IF !MB081820 == 1;
00026 00003         MB080820 = 1;
00027 00004     IEND;
00028
00029     " SBT AirKin Off Status
00030     //IF !MB81871 == 1;
00031 00005         MB0080871 = 1;
00032         //IOW MB081871 == 1;
00033     //IEND;
00034
00035 00006     DW00030 = MW08346                                " Stick Buffer Table T Motion Code Setti
ng
00036
00037 00007     SFORK     DW00030 == 1 ? LBL01                                " Stick Buffer Table T StandBy Pos
00038                     DW00030 == 2 ? LBL02                                "
00039                     DW00030 == 3 ? LBL03                                " Stick Buffer Table T Carry In Pos
00040                     DW00030 == 4 ? LBL04                                " Stick Buffer Table T Carry Out Pos
00041                     DW00030 == 5 ? LBL05                                " Stick Buffer Table T 0 De
00042                     DW00030 == 6 ? LBL06                                " Stick Buffer Table T 90 Deg
00043                     DW00030 == 7 ? LBL07                                " Stick Buffer Table T 180 Deg
00044                     DW00030 == 8 ? LBL08                                "
00045                     DEFAULT ? LBL100;
00046
00047 00008     LBL01:
00048
00049 00009         IOW MB080770 == 1                                " Stick Buffer Table T StandBy Pos Enabl
e
00050
00051 00010         ML16044 = ML46230                                " Move Data:Stick Buffer Table T StandBy
Pos
00052 00011         MOV [SBTT]ML16044;
00053
00054 00012         IOW MB081010 == 1                                " Stick Buffer Table T StandBy Pos Movin
g Comp Check
00055
00056
00057 00013         JOINTO LBL0X;
00058
00059 00014         LBL02:
00060
00061 00015         JOINTO LBL0X;
00062
00063 00016         LBL03:
00064
00065 00017         IOW MB080772 == 1                                " Stick Buffer Table T Carry In Pos Enab
le
00066
00067 00018         ML16044 = ML72406                                " Move Data:Stick Buffer Table T Carry I
n Pos
00068 00019         MOV [SBTT]ML16044;
00069
00070 00020         IOW MB081012 == 1                                " Stick Buffer Table T Carry In Pos Movi
ng Comp Check
00071
00072 00021         JOINTO LBL0X;
00073
00074 00022         LBL04:
00075
00076 00023         IOW MB080773 == 1                                " Stick Buffer Table T Carry Out Pos En
able
00077
00078 00024         ML16044 = ML72410                                " Move Data:Stick Buffer Table T Carry
Out Pos

```

```

00079 00025      MOV [SBTT]ML16044;
00080
00081 00026      IOW MB081013 == 1          " Stick Buffer Table T Carry Out Pos Mo
ving Comp Check
00082
00083 00027      JOINTO LBL0X;
00084
00085 00028      LBL05:
00086
00087 00029      IOW MB080775 == 1          " Stick Buffer Table T 0 Degree Pos Enab
le
00088
00089 00030      ML16044 = ML46254          " Move Data:Stick Buffer Table T 0 Degr
e Pos
00090 00031      MOV [SBTT]ML16044;
00091
00092 00032      IOW MB081017 == 1          " Stick Buffer Table T 0 Degree Pos Movi
ng Comp Chec
00093
00094 00033      JOINTO LBL0X;
00095
00096 00034      LBL06:
00097
00098 00035      IOW MB080776 == 1          " Stick Buffer Table T 90 Degree Pos Ena
ble
00099
00100 00036      ML16044 = ML46258          " Move Data:Stick Buffer Table T 90 Degr
ee Pos
00101 00037      MOV [SBTT]ML16044;
00102
00103 00038      IOW MB081018 == 1          " Stick Buffer Table T 90 Degree Pos Mov
ing Comp Chec
00104
00105 00039      JOINTO LBL0X;
00106
00107 00040      LBL07:
00108
00109 00041      IOW MB080777 == 1          " Stick Buffer Table T 180 Degree Pos En
able
00110
00111 00042      ML16044 = ML46262          " Move Data:Stick Buffer Table T 180 Deg
ree Pos
00112 00043      MOV [SBTT]ML16044;
00113
00114 00044      IOW MB081019 == 1          " Stick Buffer Table T 180 Degree Pos Mo
ving Comp Chec
00115
00116 00045      JOINTO LBL0X;
00117
00118 00046      LBL08:
00119
00120 00047      JOINTO LBL0X;
00121
00122 00048      LBL100:
00123 00049      JOINTO LBL0X;
00124 00050      LBL0X: SJOINT;
00125
00126
00127 00051      DW00030 = 0;                " Unit9 Stick Buffer Table T Motion Code
Reset
00128 00052      MW08346 = 0;                " Unit9 Stick Buffer Table T Motion Code
Reset
00129
00130 00053      RET;

```