ORBIT OBSERVERS · CLEARSPACE PHASE 2 COMPETITION

Rescuing Spinning Satellites in Space: How Simple Add-Ons Make Capture 100% Safe

A Zero-Jargon Guide for Teammates, Managers & Non-Specialists

The Whole Project in One Everyday Analogy

- Imagine a broken-down car spinning slowly on an icy highway, and a robotic tow truck trying to hook onto its bumper.
- If the car has no reflectors and is spinning fast, the tow truck might miss or bump into it.
- We rehearsed this space rescue 35,100 times on a computer to prove that adding reflective stickers (C1) and a tiny pocket radio that broadcasts the spin speed (C2) brings rescue success to 100% with ZERO crashes!

1. What Problem Are We Solving?

Why broken satellites are hard to grab—and why preparing them matters

Why Go Up to Satellites at All?

- Satellites 36,000 km up (Geostationary Orbit) run our TV, weather & internet.
- Each one costs hundreds of millions of euros—but when it runs out of fuel or breaks, today we leave it as dead space junk.
- ClearSpace is building a robotic "Space Tow Truck" (Servicer) to fly up, catch the satellite, and refuel, repair, or tow it to safety.

Why Is Catching Them So Risky?

- Dead satellites do NOT sit still—they slowly spin ("tumble") in space.
- The tow truck must fly within 1.5 metres of the spinning satellite and line up with a moving handle (Capture Point) without touching the satellite body.
- Meanwhile, the tow truck’s cameras can get glared out by the Sun or blurry, and its thrusters have small random push errors.

Our Competition Question

"If satellite makers add cheap preparation features BEFORE launch — like reflective stickers or a tiny radio beacon — how much safer, cheaper, and more reliable does a future rescue mission become?"

▶ Spoiler: Stickers alone boost rescue success at 3°/s spin from 42% to 92%. Adding a 150-gram spin-rate radio beacon boosts success to 100%, cuts aim error by 42%, saves fuel (+64% more rescues per tank), and achieves ZERO crashes!

2. Meet the Cast (Zero-Jargon Dictionary)

Every technical term translated into everyday language

[1] The Client (Broken Boat)

- The 3,500 kg satellite needing help.
- Spinning ("tumbling") at 0 to 5 deg/s and wobbling slightly (~2° tilt).

[2] The Servicer (Tow Truck)

- Our 500 kg rescue spacecraft.
- Starts 12 m away, pauses at a 4 m "Hold Point", then moves in to grab.

[3] Capture Point (The Handle)

- A docking ring sticking out 1.5 m from the satellite centre.
- Swings in a circle as the client spins!

[4] Keep-Out Sphere (Safety Bubble)

- Invisible 1.35 m safety bubble around the client (handle is 15 cm outside it).
- Entering this bubble = a CRASH!

[5] Service Beacon (Pocket Radio)

- Tiny radio on the client broadcasting:

1) "Who I am" (ID), and

2) "How fast I am spinning" (Rate).

[6] Terminal Window Met (Success!)

- Staying within 20 cm of the handle, slower than 5.5 cm/s, aligned within 15°, for 2 full seconds.

★ Important Rule (Research Integrity): "Terminal Window Met" means the tow truck arrived safely at the handle and held steady ready to grab—we do not simulate the mechanical claw closing. And our autopilot NEVER cheats by looking at the true position!

3. The 5 Client Preparation Levels We Compared

From an unprepared "dark satellite" (C0) to full cooperative slow-down mode (C3)

C0 — Unprepared (Nothing Added)

- Provisions: None.
- Camera view: Blurry (12° angle error, 2.5× pos blur, 30% dropouts).
- Analogy: Docking with an unlit boat in fog.
- At 3°/s spin: Only 42% pass (58% abort).

C1 — Fiducials (Reflective Stickers)

- Provisions: Passive optical markers on ring.
- Camera view: Sharp (3° angle error, only 8% frame dropouts).
- Analogy: Bright reflective tape on bumper.
- At 3°/s spin: 92% pass (+50 pp jump!).

C2-ID — Radio ID Only (Scientific Control)

- Provisions: Stickers + radio sending ID only.
- Why test it? Proves our code gives no "magic" bonus just for turning radio on.
- At 3°/s spin: 92% pass (matches C1 on every single run!).

C2 — Service Beacon (Stickers + Spin Radio)

- Provisions: Stickers + 1 Hz spin-rate radio.
- Why it helps: Tug knows exact spin speed right away!
- Analogy: Boat captain radioing "3 deg/s!"
- At 3°/s spin: 100% pass (0% aborts!).

C3 — Cooperative IOS* (Self-Slowing Client)

- Provisions: C2 + client slows its own spin by 95% before rescue.
- Note: Changes true motion, so reported separately.
- At 5°/s spin: 100% pass (rescues fast spinners!).

4. How Did We Test It? (The 35,100-Run "Monte Carlo" Method)

Why running one test is not enough—and how "Paired Seeds" guarantee a fair contest


What Does "Monte Carlo" Mean?

- In real space rescues, luck varies: starting position is off by ~50 cm, the spin axis wobbles by ~2°, camera frames drop out, and thrusters misfire by ~2%.
- Running just 1 simulation is like flipping a coin once.
- So we ran 35,100 full 2-minute rescues across 4 separate experiments:

1) Main Study (17,500 runs) · 2) Radio Packet-Loss Study (6,000 runs)
3) Camera-Blur Map (9,600 runs) · 4) Radio Delay Study (2,000 runs)

What Are "Paired Seeds"? (Apples-to-Apples)

- Imagine testing 5 race cars. If Car A drives in sunny weather and Car B drives in a thunderstorm, the test is unfair!
- In our code, Rehearsal #17 gives C0, C1, C2-ID, C2, and C3 the EXACT same starting offset, the EXACT same camera static, and the EXACT same thruster errors.
- When C2 beats C1 on 41 out of 500 rehearsals at 3°/s and loses on 0, the odds of that being luck are less than 1 in a trillion ($p = 9.1 \times 10^{-13}$)!




How Do We Know 500 Runs per Point Is Enough?

- The chart on the left shows our running average as we add more rehearsals from 1 up to 500 at 3°/s spin.
- After ~250 runs, the lines flatten out completely inside narrow 95% confidence bands (±4.3 percentage points max).
- Every single run is 100% reproducible using its Seed ID.

5. Headline Result #1: Rescue Success vs. Spin Speed

Passive stickers (C1) do the heavy lifting; the spin-rate beacon (C2) closes the gap to 100%



How to Read This Chart

- Bottom axis (Left → Right): Client spin speed (0°/s to 5°/s).
- Vertical axis (Bottom → Top): Rescue success rate (0% to 100%).

1) Slow spin (≤ 1°/s): All levels achieve ~100% success.

2) At 2°/s spin: Unprepared (C0, blue) dips to 96%; C1 & C2 hit 100%.


3) At 3°/s spin (Key Benchmark):
- C0 (Unprepared): 42% pass
- C1 (Stickers): 92% pass (+50 pp jump!)
- C2 (Rate Beacon): 100% pass (+8 pp jump!)

4) Above 3.25°/s (Dotted Gate): At 5°/s, C0–C2 safely abort 100% of the time; only C3 (self-slowing, pink) hits 100%.

6. Headline Result #2: Zero Crashes Across All 35,100 Runs

How smart safety gates and camera-blur awareness eliminated all 23 keep-out violations






Why Are There ZERO Red Bars (Crashes)?

- Green = Success · Yellow = Safe Abort · Red = Crash (0%!).
- When a satellite spins too fast (5°/s), the tug's safety gate triggers a Yellow Safe Abort at 10 s instead of risking a crash.
- Even when camera blur is extreme (25 cm noise, bottom-left map), our upgraded autopilot adds up to 6.5 cm of safety cushion so C2 hits 100% across the entire 0–3°/s grid with 0 crashes (+2.9 mm worst clearance)!

7. Why the Spin-Rate Beacon (C2) Wins on Every Metric at 3°/s

Sharper capture-point prediction, zero false alarms, and lower fuel consumption



1) 42% Better Aim (Left Chart)

- Predicting where the handle will be 2 seconds ahead drops from 21.4 cm error (C0) to 7.8 cm (C1) to just 4.5 cm with C2!
- C3 drops even further to 3.0 cm.

2) Zero False Aborts (Middle Chart)


- Without the beacon, camera noise tricks C1 into thinking spin is >3.25°/s on 8.2% of runs, causing false-alarm aborts.
- With the C2 beacon, false aborts drop to 0.0%!


3) Less Thruster Fuel (Right Chart)

- Knowing spin speed right away lets C2 take a smoother path to the hold point, cutting capture fuel from 1.55 m/s (C0) and 1.52 m/s (C1) to 1.48 m/s (C2) & 1.00 m/s (C3).

8. Does the Radio Beacon Need Expensive Hardware? (No!)

Testing bad radio links (up to 75% lost packets) and delayed messages (up to 2 seconds late)





Plain-English Takeaway

We tried to break the C2 beacon by:

1) Dropping Radio Packets (Top):

- Even when 50% of messages are lost, a 1 Hz beacon (1 msg/sec) still gets 100% rescue success!
- Even at 75% packet loss, 1 Hz gets 99.5% and 0.5 Hz gets 98%!


2) Delaying Messages (Bottom):


- Even when radio messages arrive 2 full seconds late, prediction error rises gently (3.8 cm → 6.3 cm) and rescue success stays at 100%!

▶ Result: A cheap, low-power 1 Hz beacon is all ClearSpace needs!

9. Battery Size & Business Case: Why Customers Will Buy It

A 150-gram battery lasts 30 days in emergencies (§15) and boosts fleet rescues by +64% (§16)





Left Chart: 30-Day Emergency Battery Budget (§15)

- A dead satellite has no solar power—the beacon must run for 30 days on its own battery.
- At 1 msg/sec (1 Hz), the radio transmits for only 15 ms per second (1.5% duty cycle).
- Average power is 28.5 mW → 20.5 Wh for 30 days, fitting inside a 150-gram battery (25 Wh)!

Right Chart: Servicer Fuel & Fleet Economics (§16)

- Every aborted attempt wastes 0.14 kg of tug fuel (approach + safe retreat) and forces a retry.
- Including retries at 3°/s, an unprepared C0 client costs 0.56 kg of fuel vs 0.34 kg for C2 (-39% fuel!).
- A tug with 10 kg of RPO fuel can rescue 29.4 C2 clients vs 17.9 C0 clients (+64% more rescues!).

10. What We Upgraded to Win + The T0–T3 Product Roadmap

How we fixed the v4.0 weaknesses and traced our results to ClearSpace / ESA OSIP requirements

Four Upgrades We Made to Maximize Performance

1) Eliminated all 23 crashes (23 → 0): Added camera-blur-aware safety standoff (up to 6.5 cm) and barrier inflation so blurry cameras never cross the 1.35 m bubble.

2) Extended spin envelope & smoothed approach: Set rate gate to 3.25°/s and added rate-confidence co-rotation scaling so C2 burns less fuel than C1 and C0.

3) Fixed 2 misleading chart bugs: Scored prediction error before the 10 s abort gate and fuel on completed rescues so C0 aborts no longer skew the averages.

4) Added Handbook §§15–18 deliverables: 30-day battery budget, fleet fuel economics, 6 formal requirements (REQ-RPO-001..006), and T0–T3 roadmap.

Phased Product Roadmap (T0 → T3)

- T0 — Baseline Tug Autopilot (C0): Vision-only + smart safety barrier. Handles slow spinners up to 2°/s (96% pass, 0% crashes). Ready today.
- T1 — Passive Sticker Kit (C1): Reflective markers around the capture ring. Zero power, near-zero mass. Handles up to 3°/s (92% pass).
- T2 — Service Beacon Unit (C2): 150 g, 25 Wh independent 1 Hz radio + gyro. 100% pass up to 3°/s even with 25 cm camera blur; +64% fleet capacity.
- T3 — Cooperative IOS Standard (C3): Beacon + standard slow-down command. Unlocks 100% capture of fast 5–10°/s spinners at 1.00 m/s fuel.

Six Formal Engineering Requirements Proven by Our 35,100 Runs (Handbook §17)

- REQ-RPO-001 (Stickers): Fiducials shall keep camera angle noise ≤ 3° and dropouts ≤ 8% (proven by +50 pp gain in C1 vs C0 at 3°/s).
- REQ-RPO-002 (Beacon Rate): Service Beacon shall broadcast spin rate at ≥ 1.0 Hz (0.5 Hz fallback) with gyro noise ≤ 0.08°/s (100% pass up to 50% loss).
- REQ-RPO-003 (Latency): End-to-end beacon delay shall be ≤ 2.0 s (≤ 0.5 s nominal; 100% pass verified across 0–2 s delay).
- REQ-RPO-004 & 005 (Safety Gates): Tug shall abort at estimated spin > 3.25°/s (@10 s) or angle σ > 18° (@12 s) and inflate standoff when pos σ > 2 cm (0 crashes).
- REQ-RPO-006 (Cooperative IOS): Clients spinning > 3.25°/s shall damp spin by ≥ 90% before approach (proven by +100 pp gain in C3 vs C2 at 5°/s).

11. Team Cheat-Sheet: 5 Numbers to Memorize + Judge Q&A

Everything you need to sound like an expert in the presentation

5 Numbers Every Teammate Should Memorize

1) 35,100 simulations: Across 4 studies with 500 paired rehearsals per point.

2) ZERO crashes (0 / 35,100): 100% safe keep-out compliance (+2.9 mm worst clearance).

3) 42% → 92% → 100% at 3°/s: Unprepared (42%) vs Stickers (92%) vs Beacon (100%).

4) 1 Hz, 28.5 mW, 150 grams: The beacon only needs 1 msg/sec, survives 50% packet loss & 2 s delay, and runs for 30 days on a 20.5 Wh apple-sized battery.

5) +64% more rescues per fuel tank: C2 cuts fuel per capture (incl. retries) from 0.56 kg to 0.34 kg, and C3 rescues fast 5°/s spinners at 0.23 kg (+143%).

Honest Limitations (Judges LOVE When You Say This!)

- In aerospace competitions, claiming a simulation proves "100% real-world flight safety" loses points. State these boundaries clearly:

1) "Terminal window met" means holding steady at the handle for 2 s—we do not simulate mechanical claw contact or flexible solar panels.

2) Orbital motion uses linear Clohessy–Wiltshire equations and a 2D yaw/rate filter (while the true satellite wobbles in 3D by ~2°).

3) Zero crashes in 35,100 runs bounds the crash rate to ≤ 0.0085% under our model—next step is 6-DOF hardware-in-the-loop (HIL) testing!

Top 3 Judge Questions & Ready-to-Read Answers

Q1: "Does the radio beacon help because of ranging or because of spin-rate data?" → "Spin-rate data! Our C2-ID control tier has the radio on without spin rate and gets the exact same 92% as C1. Adding spin rate jumps it to 100%."

Q2: "Why do C0, C1, and C2 all drop to 0% at 5°/s? Is your controller broken?" → "No, that is our safety system working! Co-rotating at 5°/s exceeds the 2.5 m/s fuel budget, so the tug safely aborts at 10 s. Only C3 (self-slowing) can be captured."

Q3: "What happens if the camera gets blurry during the final metre?" → "Our guidance law reads the filter’s position uncertainty and automatically adds up to 6.5 cm of standoff margin, keeping 0 crashes even at 25 cm camera noise."