
WikipediA

Multiplexing

In <u>telecommunications</u> and <u>computer networks</u>, **multiplexing** (sometimes contracted to **muxing**) is a method by which multiple analog or digital signals are combined into one signal over a <u>shared medium</u>. The aim is to share a scarce resource. For example, in telecommunications, several <u>telephone calls</u> may be carried using one wire. Multiplexing originated in <u>telegraphy</u> in the 1870s, and is now widely applied in communications. In <u>telephony</u>, <u>George Owen Squier</u> is credited with the development of telephone carrier multiplexing in 1910.



The multiplexed signal is transmitted over a communication channel such as a cable. The multiplexing divides the capacity of the communication channel into several logical channels, one for each message signal or data stream to be transferred. A reverse process, known as demultiplexing, extracts the original channels on the receiver end.

Multiple low data rate signals are multiplexed over a single high data rate link, then demultiplexed at the other end

A device that performs the multiplexing is called a <u>multiplexer</u> (MUX), and a device that performs the reverse process is called a demultiplexer (DEMUX or DMX).

<u>Inverse multiplexing</u> (IMUX) has the opposite aim as multiplexing, namely to break one data stream into several streams, transfer them simultaneously over several communication channels, and recreate the original data stream.

Contents

Types

Space-division multiplexing
Frequency-division multiplexing
Time-division multiplexing
Polarization-division multiplexing
Orbital angular momentum multiplexing
Code-division multiplexing

Multiple access method

Application areas

Telegraphy
Telephony
Video processing
Digital broadcasting
Analog broadcasting

Other meanings

See also

References

External links

Types

Multiple <u>variable</u> bit <u>rate</u> digital <u>bit streams</u> may be transferred efficiently over a single fixed <u>bandwidth</u> channel by means of <u>statistical multiplexing</u>. This is an <u>asynchronous</u> mode time-domain multiplexing which is a form of time-division multiplexing.

Digital bit streams can be transferred over an analog channel by means of code-division multiplexing techniques such as frequency-hopping spread spectrum (FHSS) and direct-sequence spread spectrum (DSSS).

In <u>wireless communications</u>, multiplexing can also be accomplished through alternating polarization (horizontal/vertical or <u>clockwise/counterclockwise</u>) on each <u>adjacent channel</u> and satellite, or through <u>phased multi-antenna array</u> combined with a multiple-input multiple-output communications (MIMO) scheme.


Space-division multiplexing

In wired communication, <u>space-division multiplexing</u>, also known as Space-division multiple access is the use of separate point-to-point electrical conductors for each transmitted channel. Examples include an analogue stereo audio cable, with one pair of wires for the left channel and another for the right channel, and a multi-pair <u>telephone cable</u>, a switched <u>star</u> network such as a telephone access network, a switched Ethernet network, and a mesh network.

In wireless communication, space-division multiplexing is achieved with multiple antenna elements forming a <u>phased array antenna</u>. Examples are <u>multiple-input and multiple-output</u> (MIMO), single-input and multiple-output (SIMO) and multiple-input and single-output (MISO) multiplexing. An IEEE 802.11n wireless router with k antennas makes it in principle possible to communicate with k multiplexed channels, each with a peak bit rate of 54 Mbit/s, thus increasing the total peak bit rate by the factor k. Different antennas would give different <u>multi-path propagation</u> (echo) signatures, making it possible for <u>digital signal processing</u> techniques to separate different signals from each other. These techniques may also be utilized for <u>space diversity</u> (improved robustness to fading) or <u>beamforming</u> (improved selectivity) rather than multiplexing

Frequency-division multiplexing

Frequency-division multiplexing (FDM) is inherently an analog technology. FDM achieves the combining of several signals into one medium by sending signals in several distinct frequency ranges over a single medium. In FDM the signals are electrical signals. One of the most common applications for FDM is traditional radio and television broadcasting from terrestrial, mobile or satellite stations, or cable television. Only one cable reaches a customer's residential area, but the service provider can send multiple television channels




Frequency-division multiplexing (FDM): The spectrum of each input signal is shifted to a distinct frequency range.

or signals simultaneously over that cable to all subscribers without interference. Receivers must tune to the appropriate frequency (channel) to access the desired signal.^[1]

A variant technology, called wavelength-division multiplexing (WDM) is used in optical communications.

Time-division multiplexing

Time-division multiplexing (TDM) is a digital (or in rare cases, analog) technology which uses time, instead of space or frequency, to separate the different data streams. TDM involves sequencing groups of a few bits or bytes from each individual input stream, one after the other, and in such a way that they can be associated with the appropriate receiver. If done sufficiently quickly, the receiving devices will



not detect that some of the circuit time was used to serve another logical communication path.

Consider an application requiring four terminals at an airport to reach a central computer. Each terminal communicated at 2400 <u>baud</u>, so rather than acquire four individual circuits to carry such a low-speed transmission, the airline has installed a pair of multiplexers. A pair of 9600 baud modems and one dedicated analog communications circuit from the airport ticket desk back to the airline data center are also installed. [1] Some <u>web proxy servers</u> (e.g. <u>polipo</u>) use TDM in HTTP pipelining of multiple HTTP transactions onto the same TCP/IP connection. [2]

<u>Carrier sense multiple access</u> and <u>multidrop</u> communication methods are similar to time-division multiplexing in that multiple data streams are separated by time on the same medium, but because the signals have separate origins instead of being combined into a single signal, are best viewed as channel access methods, rather than a form of multiplexing.

TDM still is a legacy multiplexing technology still providing the backbone of most National fixed line Telephony networks in Europe, providing the 2m/bit voice and signalling ports on Narrow band Telephone exchanges such as the DMS100, System X and AXE10's. Each E1 or 2m/bit TDM port provides either 30 or 31 speech timeslots in the case of CCITT7 signalling systems and 30 voice channels for customer connected Q931,DASS2,DPNSS,V5 and CASS signalling systems. Each E1 or 2m/bit TDM port utilises 32 time slots, timeslot zero being used for frame alignment ,CRC and alarm indication, signalling such as CCITT7 ISUP/IUP is usually carried in timeslot 16 on national interconnects and timeslot 1 for international interconnects, CCITT7 E1/2mbit interconnects that are not part of the CCITT7 linkset will have 31 timeslots available for carrying speech or ISDN services. Each E1/2mbit TDM port is then multiplexed further using a PDH hierarchy usually 2meg to 8m/bit to 34mbit to 140m/bit and upto 565m/bit, or an SDH hierarchy where a single VC4 will carry 63 E1 2m/bit ports as VC12's.

Polarization-division multiplexing

<u>Polarization-division multiplexing</u> uses the <u>polarization</u> of electromagnetic radiation to separate orthogonal channels. It is in practical use in both radio and optical communications, particularly in 100 Gbit/s per channel <u>fiber optic transmission</u> systems.

Orbital angular momentum multiplexing

Orbital angular momentum multiplexing is a relatively new and experimental technique for multiplexing multiple channels of signals carried using electromagnetic radiation over a single path.^[3] It can potentially be used in addition to other physical multiplexing methods to greatly expand the transmission capacity of such systems. As of 2012 it is still in its early research phase, with small-scale laboratory demonstrations of bandwidths of up to 2.5 Tbit/s over a single light path.^[4] This is a controversial subject in the academic community, with many claiming it is not a new method of multiplexing, but rather a special case of space-division multiplexing.^[5]


Code-division multiplexing

Code division multiplexing (CDM), Code division multiple access (CDMA) or spread spectrum is a class of techniques where several channels simultaneously share the same frequency spectrum, and this spectral bandwidth is much higher than the bit rate or symbol rate. One form is frequency hopping, another is direct sequence spread spectrum. In the latter case, each channel transmits its bits as a coded channel-specific sequence of pulses called chips. Number of chips per bit, or chips per symbol, is the spreading factor. This coded transmission typically is accomplished by transmitting a unique time-dependent series of short pulses, which are placed within chip times within the larger bit time. All channels, each with a different code, can be transmitted on the same fiber or radio channel or other medium, and asynchronously demultiplexed. Advantages over conventional techniques are that variable bandwidth is possible (just as in statistical multiplexing), that the wide bandwidth allows poor signal-to-noise ratio according to Shannon-Hartley theorem, and that multi-path propagation in wireless communication can be combated by rake receivers.

A significant application of CDMA is the Global Positioning System (GPS).

Multiple access method

A multiplexing technique may be further extended into a <u>multiple access method</u> or <u>channel access method</u>, for example, TDM into <u>time-division multiple access</u> (TDMA) and statistical multiplexing into <u>carrier-sense multiple access</u> (CSMA). A multiple access method makes it possible for several transmitters connected to the same physical medium to share its capacity.



Telecommunication multiplexing

Multiplexing is provided by the <u>Physical Layer</u> of the <u>OSI model</u>, while multiple access also involves a <u>media access control</u> protocol, which is part of the <u>Data Link Layer</u>.

The Transport layer in the OSI model, as well as TCP/IP model, provides statistical multiplexing of several application layer data flows to/from the same computer.

Code-division multiplexing (CDM) is a technique in which each channel transmits its bits as a coded channel-specific sequence of pulses. This coded transmission typically is accomplished by transmitting a unique time-dependent series of short pulses, which are placed within chip times within the larger bit time. All channels, each with a different code, can be transmitted on the same fiber and asynchronously demultiplexed. Other widely used multiple access techniques are time-division multiple access (TDMA) and frequency-division multiple access (FDMA). Code-division multiplex techniques are used as an access technology, namely code-division multiple access (CDMA), in Universal Mobile Telecommunications System (UMTS) standard for the third-generation (3G) mobile communication identified by the ITU.

Application areas

Telegraphy

The earliest communication technology using electrical wires, and therefore sharing an interest in the economies afforded by multiplexing, was the <u>electric telegraph</u>. Early experiments allowed two separate messages to travel in opposite directions simultaneously, first using an electric battery at both ends, then at only one end.

- Émile Baudot developed a time-multiplexing system of multiple Hughes machines in the 1870s.
- In 1874, the <u>quadruplex telegraph</u> developed by <u>Thomas Edison</u> transmitted two messages in each direction simultaneously, for a total of four messages transiting the same wire at the same time.
- Several workers were investigating <u>acoustic telegraphy</u>, a <u>frequency-division multiplexing</u> technique, which led to the invention of the telephone.

Telephony

In <u>telephony</u>, a <u>customer</u>'s <u>telephone line</u> now typically ends at the <u>remote concentrator</u> box, where it is multiplexed along with other <u>telephone lines</u> for that <u>neighborhood</u> or other similar area. The multiplexed signal is then carried to the <u>central switching office</u> on significantly fewer wires and for much further distances than a customer's line can practically go. This is likewise also true for digital subscriber lines (DSL).

<u>Fiber in the loop</u> (FITL) is a common method of multiplexing, which uses <u>optical fiber</u> as the <u>backbone</u>. It not only connects <u>POTS</u> phone lines with the rest of the <u>PSTN</u>, but also replaces DSL by connecting directly to <u>Ethernet</u> wired into the home. Asynchronous Transfer Mode is often the communications protocol used.

Because all the phone (and data) lines have been clumped together, none of them can be accessed except through a demultiplexer. Where such demultiplexers are uncommon, this provides for more-secure communications, though the connections are not typically encrypted.

<u>Cable TV</u> has long carried multiplexed <u>television channels</u>, and late in the **20**th century began offering the same services as telephone companies. IPTV also depends on multiplexing.

Video processing

In <u>video</u> editing and processing systems, multiplexing refers to the process of interleaving audio and video into one coherent data stream.

In <u>digital video</u>, such a transport stream is normally a feature of a <u>container format</u> which may include <u>metadata</u> and other information, such as <u>subtitles</u>. The audio and video streams may have variable bit rate. Software that produces such a transport stream and/or container is commonly called a <u>statistical multiplexer</u> or **muxer**. A **demuxer** is software that extracts or otherwise makes available for separate processing the components of such a stream or container.

Digital broadcasting

In <u>digital television</u> and <u>digital radio</u> systems, several variable bit-rate data streams are multiplexed together to a fixed bitrate transport stream by means of <u>statistical multiplexing</u>. This makes it possible to transfer several video and audio channels simultaneously over the same frequency channel, together with various services.

In the digital television systems, this may involve several <u>standard definition television</u> (SDTV) programmes (particularly on <u>DVB-T</u>, <u>DVB-S2</u>, <u>ISDB</u> and ATSC-C), or one <u>HDTV</u>, possibly with a single SDTV companion channel over one 6 to 8 MHz-wide TV channel. The device that accomplishes this is called a <u>statistical multiplexer</u>. In several of these systems, the multiplexing results in an <u>MPEG transport stream</u>. The newer DVB standards DVB-S2 and <u>DVB-T2</u> has the capacity to carry several <u>HDTV</u> channels in one multiplex. Even the original DVB standards can carry more HDTV channels in a multiplex if the most advanced MPEG-4 compressions hardware is used.

On <u>communications</u> satellites which carry <u>broadcast</u> <u>television networks</u> and <u>radio networks</u>, this is known as **multiple channel per carrier** or **MCPC**. Where multiplexing is not practical (such as where there are different sources using a single transponder), single channel per carrier mode is used.

Signal multiplexing of satellite TV and radio channels is typically carried out in a central signal playout and <u>uplink</u> centre, such as <u>SES Platform Services</u> in Germany, which provides <u>playout</u>, digital archiving, <u>encryption</u>, and satellite uplinks, as well as multiplexing, for hundreds of digital TV and radio channels.

In digital radio, both the <u>Digital Audio Broadcasting</u> (DAB) Eureka 147 system of digital audio broadcasting and the <u>inband on-channel HD Radio</u>, <u>FMeXtra</u>, and <u>Digital Radio Mondiale</u> systems can multiplex channels. This is essentially required with DAB-type transmissions (where a multiplex is called a <u>DAB ensemble</u>), but is entirely optional with IBOC systems.

Analog broadcasting

In <u>FM broadcasting</u> and other <u>analog radio</u> media, multiplexing is a term commonly given to the process of adding <u>subcarriers</u> to the audio signal before it enters the <u>transmitter</u>, where <u>modulation</u> occurs. (In fact, the stereo multiplex signal can be generated using time-division multiplexing, by switching between the two (left channel and right channel) input signals at an ultrasonic rate (the subcarrier), and then filtering out the higher harmonics.) Multiplexing in this sense is sometimes known as **MPX**, which in turn is also an old term for <u>stereophonic</u> FM, seen on <u>stereo systems</u> since the 1960s.

Other meanings

In <u>spectroscopy</u> the term is used to indicate that the experiment is performed with a mixture of frequencies at once and their respective response unravelled afterwards using the <u>Fourier transform</u> principle.

In <u>computer programming</u>, it may refer to using a single in-memory resource (such as a file handle) to handle multiple external resources (such as on-disk files).^[6]

Some electrical multiplexing techniques do not require a physical "<u>multiplexer</u>" device, they refer to a "<u>keyboard matrix</u>" or "Charlieplexing" design style:

- Multiplexing may refer to the design of a multiplexed display (non-multiplexed displays are immune to break up).
- Multiplexing may refer to the design of a "switch matrix" (non-multiplexed buttons are immune to "phantom keys" and also immune to "phantom key blocking").

In high-throughput <u>DNA</u> sequencing, the term is used to indicate that some artificial sequences (often called *barcodes* or *indexes*) have been added to link given sequence reads to a given sample, and thus allow for the sequencing of multiple samples in the same reaction.

See also

- Add-drop multiplexer
- Central office multiplexing
- Channel bank
- Codec (encoder-decoder)
- Multiplexed display
- Optical add-drop multiplexer
- Orthogonal frequency-division multiplexing (OFDM) (which is a modulation method)