Analog Electronic Circuits
Quadrature Down Converter Project

Team name - Mixed Signals
Members: Sreekar Reddy Arepally, Supratheek SNV, Sravan Kumar
Roll Numbers:
Sreekar Reddy Arepally - 2025102074
Supratheek SNV - 2025102064
Sravan Kumar - 2025102033
table number: 8
Electronics and Communication Engineering
IIIT Hyderabad
Hyderabad, India

***Abstract*—This report addresses the fundamental need for Quadrature (I-Q) down-conversion in modern wireless communication systems. While standard single-branch mixing effectively translates high-frequency Radio Frequency (RF) signals to a lower Intermediate Frequency (IF), it suffers from a fatal flaw known as the Image Frequency problem. By mathematically analyzing the mixing process, this paper demonstrates how splitting the local oscillator into two orthogonal phases (In-Phase and Quadrature) preserves the phase polarity of the frequency difference. This orthogonal separation allows modern receivers to cancel image interference, double spectral efficiency, and process complex modulation schemes such as QAM and PSK. This report details the complete design, simulation, and hardware realization of a QDC system including the oscillator, mixer, filters, and amplifiers.**

***Index Terms*—Quadrature Down Converter, Mixer, Intermediate Frequency, Low Pass Filter, Common-Source Amplifier, Oscillator.**

I. Introduction: The Need for Quadrature Mixing (Q1)

A. The Flaw of Standard Mixing

In a traditional heterodyne receiver, an incoming RF signal (ω_{RF}) is multiplied by a local oscillator (ω_{LO}) to step the frequency down to a manageable Intermediate Frequency (ω_{IF}). The mathematical operation of a standard mixer is a simple trigonometric multiplication:

$$\cos(\omega_{RF}t) \times \cos(\omega_{LO}t) = \frac{1}{2}\left[\cos((\omega_{RF}-\omega_{LO})t) + \cos((\omega_{RF}+\omega_{LO})t)\right] \quad (1)$$

A low-pass filter easily removes the high-frequency sum, leaving only the difference $|\omega_{RF} - \omega_{LO}|$. However, the absolute value function reveals a critical physical vulnerability. Suppose our desired signal is located at $\omega_{LO}+\omega_{IF}$. The mixer will output ω_{IF}.

Now suppose there is an unwanted noise signal, or "Image," located at $\omega_{LO} - \omega_{IF}$. Because cosine is an even function ($\cos(-x) = \cos(x)$), the mixer will process the image as follows:

$$\cos(-\omega_{IF}t) = \cos(\omega_{IF}t) \quad (2)$$

Both the desired signal and the unwanted image noise map into the exact same IF band, permanently corrupting the data. A standard single-branch mixer cannot distinguish between frequencies that lie above the LO and frequencies that lie below the LO.

B. The Quadrature (I-Q) Solution

To solve this, modern receivers utilize a Quadrature Down Converter (QDC). Instead of one mixer, the RF signal is split and fed into two parallel mixers. The LO signal is also split; one branch remains untouched (In-Phase, or I), while the other is shifted by exactly 90° (Quadrature, or Q).

Let the Local Oscillator signals be:

$$LO_I = \cos(\omega_{LO}t) \quad (3)$$

$$LO_Q = -\sin(\omega_{LO}t) \quad (4)$$

1) Processing the Desired Signal: Let the desired signal be higher than the LO: $\omega_{RF} = \omega_{LO} + \omega_{IF}$.

$$I_{desired} = \cos((\omega_{LO}+\omega_{IF})t)\cos(\omega_{LO}t) \xrightarrow{\text{LPF}} \frac{1}{2}\cos(\omega_{IF}t) \quad (5)$$

$$Q_{desired} = \cos((\omega_{LO}+\omega_{IF})t)(-\sin(\omega_{LO}t)) \xrightarrow{\text{LPF}} \frac{1}{2}\sin(\omega_{IF}t) \quad (6)$$

2) Processing the Image Signal: Now, let the unwanted image signal be lower than the LO: $\omega_{IM} = \omega_{LO} - \omega_{IF}$.

$$I_{image} = \cos((\omega_{LO}-\omega_{IF})t)\cos(\omega_{LO}t) \xrightarrow{\text{LPF}} \frac{1}{2}\cos(-\omega_{IF}t) = \frac{1}{2}\cos(\omega_{IF}t) \quad (7)$$

$$Q_{image} = \cos((\omega_{LO}-\omega_{IF})t)(-\sin(\omega_{LO}t)) \xrightarrow{\text{LPF}} \frac{1}{2}\sin(-\omega_{IF}t) = -\frac{1}{2}\sin(\omega_{IF}t) \quad (8)$$

3) The Mathematical Takeaway: Looking closely at the results, the I channel outputs are identical for both the desired signal and the image. However, the Q channel outputs have **opposite signs**. By using an orthogonal (90-degree) reference, the QDC preserves the polarity of the frequency difference. Because the image and the desired signal have different phase relationships in the Q channel, the Digital Signal Processor (DSP) can mathematically add or subtract the I and Q streams (often via a Weaver or Hartley architecture) to completely cancel out the image frequency, leaving only the pristine desired signal.

C. Utility in Modern Wireless Receivers

The mathematical separation provided by I-Q mixing is the foundational bedrock of modern wireless standards (Bluetooth, Wi-Fi, 5G). Its utility extends beyond simply rejecting image noise:

1) **Direct-Conversion (Zero-IF) Receivers:** By setting the LO frequency exactly equal to the RF frequency ($\omega_{IF} = 0$), the QDC translates the signal directly to baseband. Because $f_{IF} = 0$, the image frequency is the signal itself. I-Q mixing is strictly required here to separate the upper and lower sidebands of the original RF spectrum, preventing the signal from folding over and destroying itself.
2) **Complex Modulation Schemes:** Modern data transmission does not just alter amplitude or frequency; it alters both simultaneously to pack more bits into the same bandwidth. Quadrature Amplitude Modulation (QAM) and Phase-Shift Keying (PSK) rely entirely on I-Q independence. By transmitting unique data on the I carrier and completely independent data on the Q carrier, the spectral efficiency of the communication link is mathematically doubled.

D. Graphical Spectrum Representation

While the time-domain trigonometric equations prove that the Q channel preserves the sign of the frequency difference, looking at the frequency domain (the spectrum) provides a much clearer visual intuition.

If we look at a standard single-mixer spectrum, both the desired RF band and the Image band fold over the LO frequency and land on top of each other at baseband (the IF). Because we only have one axis of information (amplitude), they are permanently superimposed.

However, when we introduce the Q channel, we are effectively adding a second, orthogonal dimension to our spectrum (a complex plane). In this complex frequency domain, positive frequencies (the desired signal) rotate counter-clockwise, while negative frequencies (the image) rotate clockwise. By having both I (real) and Q (imaginary) components, the receiver's digital signal processor can "see" this rotation direction and filter out the image spectrum completely before demodulation.




Fig. 1. Spectrum depiction of a standard mixer: The Image and Desired signals irreversibly overlap at the Intermediate Frequency, causing data corruption.




Fig. 2. Spectrum depiction of I-Q mixing: By utilizing phase information, the image spectrum is shifted into the negative complex plane, preserving the desired signal.

E. The Complex Envelope (Euler's Formula)

To tie the physical QDC circuit to the digital software that processes its output, we look to Euler's formula:

$$e^{j\omega t} = \cos(\omega t) + j\sin(\omega t) \tag{9}$$

In modern digital receivers, the processor treats the I channel as the "Real" part and the Q channel as the "Imaginary" part of a single, complex number stream. The combined baseband signal $S(t)$ can be written as:

$$S(t) = I(t) + jQ(t) \tag{10}$$

If we only had $I(t)$ (a standard mixer), we would only have $\cos(\omega t)$. But because we have $I(t) + jQ(t)$, we possess the full complex exponential $e^{j\omega t}$. Possessing the full complex signal gives the receiver absolute knowledge of the signal's instantaneous amplitude, phase, and frequency trajectory at any given microsecond. This mathematical elegance is the ultimate reason why Quadrature Down Converters are the undisputed standard in every modern wireless device.