指令编码											** ** ** ** ** **				ID				EX		MEM		WB					
指令	15	14	13 12	11		8 7			4 3		2 1 0		imm拓展万式	涉及特殊寄存器	目标寄存器	ŧ.	imm_chooser	Branch	BranchOp	RxSrc	RySrc	RegDst	ALUOp	Branch	MemRead	MemWrite	MemToReg	RegWrit
DSP3	0	0	0 0	0	ГX				imm	1		s	sign	SP	гx		000			001	1							1
	0	0	0 0	1	0 0	0 0	0	0	0	0 (0 0	0																
	0	0	0 1	0				imm				s	sign	PC	PC		001	1	11		1			1				
Z	0	0	1 0	0	ΓX				imm	1		s	sign	PC	PC		000	1	01		1			1				
Z	0	0	1 0	1	гх				imm	1		s	sign	PC	PC		000	1	10		1			1				
	0	0	1 1	0	гх		гу		ir	mm	0	0 z	zero, 3位表示1~8		гх		010				1		0101					1
	0	0	1 1	0	гх		ry		ir	mm	- 1	1 2	zero, 3位表示1~8		гх		010				1		0110					1
IU3	0	1	0 0	0	гх		ry		0		imm	s	sign		ry		011				1	001						1
U	0	1	0 0	1	гх				imm	1			sign		ΓX		000				1							1
ΩZ	0	1	1 0	0	0 0	0			imm				sign	T, PC	PC		000	1	01	011	1			1				
z	0	1	1 0	0	0 0	1			imm	1			sign	T, PC	PC		000	1	10	011	1			1				
SP	0	1	1 0	0	0 1	1			imm	1			sign	SP	SP		000			001	1	011						1
5			1 0		1 0	0	rv				0 0		•	SP	SP							011	1010					1
			1 0		- FX		-,		imm				zero	<u> </u>	rx		100				1	• • • • • • • • • • • • • • • • • • • •	1010					1
1	0	1	1 1		rx				imm					Т	T		000				1	101	0100					1
SP	1	0	0 1	0	ΓX				imm				sign	SP	rx		000			001	1				1		0	1
	1	0	0 1	1	rx		гу				nm		sign		ry		101			-	1	001			1		0	1
SP	1	1	0 1	0	ΓX		.,		imm				sign	SP	,		000			001	1	-				1	-	
-			0 1		rx		гу				nm		sign	-			101				1					1		
U	_	_	1 0		ΓX		ry			rz	0		9		rz							010						1
U			1 0		rx		ΓV			rz		1			rz							010	0001					1
_			1 0		rx rx	0	-	0		0 (PC	PC			1	11			010	1001	1				
2			1 0		rx rx		1			0 1		-		PC	rx				- "	100			1001					1
_	1		1 0		rx rx		rv	-	0	1	1 0	-		10	DX.					100			0010					1
	1		1 0		rx		ΓV		0	1 .	1 0	-			rx								0010					1
			1 0		rx rx		rv rv		-	0 (0		Т	T							101	1000					1
			1 0		TX TX		- '		0	1 1		0		T	T							101	0100					1
			1 0		TX TX		ry			0 (-		Ť	T							101	0111					1
						0	ry 0			0 1				IH.						010		101	1001					1
			1 1 1		rx		0							IH IH	rx IH					010		100	1001					1
	-	•		U	rx	U	U	U	U	0 1	0 0	- 1		ın	In	Default	111	0	00	000	0	000	0000	0	0	0	1	1
																					-	000:rx		0:非分支语句	0:不读	-	0:读出的数据	0: 不写回
																解释	没得解释	0:非分支语句	00:不跳转	000 : R[x]	0:R[y]					0:不写		
																		1:分支语句	11:跳转	001:SP	1:立即数	001:ry		1:分支语句	1:读	1:写	1:算出的数据	1:写回
																			01:相等跳转	010:IH		010:rz	0010: 与运算					
																			10:不等跳转	011:T		011:SP	0011:或运算					
																				100:PC		100:IH	0100:判断相等					
																						101:T	0101:逻辑左移					
																							0110:算术右移					
																							0111: 无符号比较					
																							1000: 有符号比较					
																							1001:第一个输入					
																							1010:第二个输入					