## Университет ИТМО

# Факультет программной инженерии и компьютерной техники

Кафедра вычислительной техники

# Информационно-управляющие системы Лабораторная работа №2 Вариант №8

Выполнили:

Милосердов А. О.

Калугин Ф. И.

Группа Р3410

Преподаватель:

Ключев А. О.

Санкт-Петербург 2017 г.

#### Описание задания

Разработать и реализовать драйвер системного таймера микроконтроллера и драйвер звукового излучателя, позволяющий задавать частоту для ADuC812. Написать тестовую программу с использованием разработанного драйвера по алгоритму: контроллер SDK-1.1 циклически проигрывает нисходящую гамму нот второй октавы (длительность каждой ноты – 0,5 секунды) и на линейку светодиодов выводит количество замыканий входа INT1. В результате выполнения работы должны быть разработаны драйверы системного таймера, звукового излучателя, светодиодных индикаторов, счетчика срабатываний внешнего прерывания.

### Модель взаимодействия




Рис. 1: Модель взаимодействия модулей

### Листинги

```
isr.h
   #pragma once
   // Set interrupts vectors
   void set_vectors( );
   isr.c
   #include "isr_utils.h"
   #include "isr.h"
   #include "sys_timer.h"
   #include "aduc812.h"
   #include "max.h"
   #include "sound.h"
   #include "led.h"
   // INT1 counter
   unsigned char k;
   // Toggler for ENA in TO ISR
12
   char t;
14
   char g_note_h;
15
   char g_note_1;
16
17
   unsigned long systime = 0;
18
   // Handler for INT1 interrupt, controls LED output
   void INT1_ISR( void ) __interrupt {
           k++;
           leds( k );
23
   }
24
   // Handler for timer1 interrupts, interrupts every millisecond
   void T1_ISR ( void ) __interrupt {
27
     systime++;
     TH1 = MS_H;
     TL1 = MS_L;
31
32
   // Handler for timer0 interrupts, generates sound of set frequency
   void T0_ISR( void ) __interrupt {
     if( t ) {
       write_max(ENA, VOL1);
38
       t = 0;
     } else {
       write_max(ENA, VOL0);
41
       t = 1;
42
     }
     TH0 = g_note_h;
44
     TL0 = g_note_1;
45
  }
```

```
void set_vectors( ) {
     set_vector( 0x200B, (void *)T0_ISR );
49
     set_vector( 0x2013, (void *)INT1_ISR );
     set_vector( 0x201B, (void *)T1_ISR );
   }
52
   isr_utils.h
   #pragma once
   // Set user interrupts handlers
   void set_vector( unsigned char __xdata * Address, void * Vector );
   isr utils.c
   #include "isr_utils.h"
   void set_vector( unsigned char __xdata * Address, void * Vector ) {
     unsigned char __xdata * TmpVector;
     *Address = 0x02;
     TmpVector = (unsigned char __xdata *) (Address + 1);
     *TmpVector = (unsigned char) ((unsigned short) Vector >> 8);
     ++TmpVector;
     *TmpVector = (unsigned char) Vector;
12
13
   }
   sound.h
   #pragma once
   // Volume levels
   #define VOL0 0
   #define VOL1 0b00011100
   // Note frequency data
   extern char g_note_h;
   extern char g_note_1;
   // Set sound frequency
11
   {f void} set_note( {f int} hz );
   sound.c
   #include "sound.h"
   #include "notes.h"
   void set_note( int hz ) {
     g_note_h = note_h( hz );
     g_note_1 = note_1(hz);
7 }
```

#### notes.h

#pragma once #define C\_NOTE\_0 16.4 #define C\_SHARP\_NOTE\_0 17.3 #define D\_NOTE\_0 18.4 #define D\_SHARP\_NOTE\_0 19.5 #define E\_NOTE\_0 20.6 #define F\_NOTE\_0 21.8 #define F\_SHARP\_NOTE\_0 23.1 #define G\_NOTE\_0 24.5 #define G\_SHARP\_NOTE\_0 #define A\_NOTE\_0 27.5 12 #define A\_SHARP\_NOTE\_0 29.1 13 #define B\_NOTE\_0 30.9 15 #define C\_NOTE\_3 130.81 #define C\_SHARP\_NOTE\_3 138.59 #define D\_NOTE\_3 146.83 #define D\_SHARP\_NOTE\_3 155.56 19 #define E\_NOTE\_3 164.81 #define F\_NOTE\_3 174.61 #define F\_SHARP\_NOTE\_3 185.00 #define G\_NOTE\_3 196.00 #define G\_SHARP\_NOTE\_3 207.65 24 #define A\_NOTE\_3 220.00 #define A\_SHARP\_NOTE\_3 233.08 #define B\_NOTE\_3 246.94 #define C\_NOTE\_4 261.63 #define C\_SHARP\_NOTE\_4 277.18 30 #define D\_NOTE\_4 293.66 #define D\_SHARP\_NOTE\_4 311.13 #define E\_NOTE\_4 329.63 #define F\_NOTE\_4 349.23 #define F\_SHARP\_NOTE\_4 369.99 #define G\_NOTE\_4 392.00 #define G\_SHARP\_NOTE\_4 415.30 #define A\_NOTE\_4 440.00 #define A\_SHARP\_NOTE\_4 466.16 #define B\_NOTE\_4 493.88 41 #define C\_NOTE\_5 523.25 42 #define C\_SHARP\_NOTE\_5 554.37 #define D\_NOTE\_5 587.33 #define D\_SHARP\_NOTE\_5 622.25 #define E\_NOTE\_5 659.25 #define F\_NOTE\_5 698.46 #define F\_SHARP\_NOTE\_5 739.99 #define G\_NOTE\_5 783.99 #define G\_SHARP\_NOTE\_5 830.61 #define A\_NOTE\_5 #define A\_SHARP\_NOTE\_5 932.33 #define B\_NOTE\_5 987.77 53 54

```
short note( int hz );
   char note_h( int hz );
   char note_l( int hz );
   notes.c
   #include "notes.h"
   #include "sys_timer.h"
   short note( int hz ) {
     // hz is multiplied by 2 cause we handle a note in two half periods
     return 0xFFFF - MCLKIN / ( ( hz * 2 ) ) / 12;
   }
   char note_h( int hz ) {
     return ( note( hz ) >> 8 ) & 0xFF;
   }
11
   char note_l( int hz ) {
     return ( note( hz ) & 0xFF );
14
15
   sys_timer.h
   #pragma once
   // For init set
   #define A_H 0xFB
   #define A_L 0x8B
   // Define main clock speed
   #define MCLKIN 11059200
   // Calculate timer ticks to count a millisecond
   #define MS 0xFFFF - ( MCLKIN / 12 ) / 1000
   // Break ms into two 8 bit values
   #define MS_H ( MS >> 8 ) & 0x00FF
   #define MS_L MS & 0x00FF
   // Time in ms since timer1 start
   extern unsigned long systime;
   // Get current systime
   unsigned long get_ms_counter( void );
21
   // Get time difference
   unsigned long d_time_ms( unsigned long t2 );
   // Set delay in ms
   void delay_ms( unsigned long ms );
   // Init timers
   void init_timers( );
```

#### sys timer.c #include "sys\_timer.h" #include "notes.h" #include "aduc812.h" unsigned long get\_ms\_counter( void ) { unsigned long res; ET1 = 0;res = systime; ET1 = 1;return res; 11 } 12 unsigned long d\_time\_ms( unsigned long t2 ) { 13 unsigned long t1 = get\_ms\_counter(); 14 return t1 - t2; 16 17 void delay\_ms( unsigned long ms ) { unsigned long t1 = get\_ms\_counter(); 19 while ( 1 ) $\{$ if ( d\_time\_ms( t1 ) > ms ) break; 21 } 22 } 23 void init\_timers( ) { // Set TO and T1 to timer mode 27 TMOD = 0x11;// Set INT1 edge-sensitive IT1 = 1;32 // Timers priorities 33 PT1 = 0;PT0 = 1;35 // Start values for T0 $TH0 = A_H;$ $TL0 = A_L;$ // Start values for T1 41 $TH1 = MS_H;$ 42 $TL1 = MS_L;$ 44 // Start timers TO and T1 TR1 = 1;TR0 = 1;47 // Enable timers TO and T1 ET1 = 1;50 ET0 = 1;51 // Enable external interrupt 1 53 EX1 = 1;54

```
// Allow interrupts
     EA = 1;
57
   main.c
   #include "sys_timer.h"
   #include "isr.h"
   #include "sound.h"
   #include "notes.h"
   #include "MasterOfPuppets.h"
   #define DELAY_MS 500
   void main( void ) {
     init_timers( );
     set_vectors( );
10
     while( 1 ) {
12
13
        set_note( B_NOTE_4 );
        delay_ms( DELAY_MS );
15
        set_note( A_NOTE_4 );
        delay_ms( DELAY_MS );
        set_note( G_NOTE_4 );
        delay_ms( DELAY_MS );
21
        set_note( F_NOTE_4 );
        delay_ms( DELAY_MS );
        set_note( E_NOTE_4 );
        delay_ms( DELAY_MS );
        set_note( D_NOTE_4 );
        delay_ms( DELAY_MS );
        set_note( C_NOTE_4 );
        delay_ms( DELAY_MS );
33
34
   }
```

## Вывод

В результате выполнения лабораторной работы были разработаны и реализованы драйвер системного таймера микроконтроллера и драйвер звукового излучателя, позволяющий задавать частоту для ADuC812.