```
070A
      F8
          LDI
                    ;Set R3 = address refer sub @ 0901
      09
  0B
  OC
      B3
          PHI
                 R3 :
      F8
  OD
          LDI
  0E
      01
  OF
      A3
          PLO
                 R3 ;
0710
      D3
                 R3 : Do MLS -- set RA.0 = board address per VA VB
          SEP
      F8
  11
          LDI
  12
      01
  13
      5A
          STR
                 RA ;Store an 01 white piece @ VA VB (piece moving)
  14
      86
          GLO
                 R6 ; D=R6.0 which is = FA from refer sub (VA)
  15
      A7
          PLO
                 R7 : R7.0=R6.0
  16
      17
          INC
                 R7 ; R7 now points to Chip-8 VB
                 R6 : D=M(R(6)) Get value of VA
  17
      06
          LDN
  18
      BD
          PHI
                 RD ; Put in RD.1 to save original VA
  19
      07
          LDN
                 R7 : D=M(R(7)) Get value of VB
          PLO
  1A
      AD
                 RD : Put in RD.O to save original VB
  1B
      F8
          LDI
                     ;Set RF.0 = FF = cycle index \#2 (VY)
  10
      FF
                 RF ;
  1D
      AF
          PLO
      F8
  1E
           LDI
                     ;Set RE.0 = FF = cycle index #1 (VX)
  1F
      FF
0720
      AE
          PLO
  21
      F8
          LDI
                     :Set R3.0 = address search sub
  22
      24
  23
      A3
          PLO
                 R3
  24
                 R3 ; Do MLS -- add indexes to VA VB and set "I" to
      D3
          SEP
  25
26
      OA.
          LDN
                 RA :Get piece @ M(R(A))
                                                          board square
          XRI
                     :Test if = 01 white
      FB
  27
      01
                     ; If so, done search, branch to 0740 to change line
  28
      32
          BZ
  29
      40
                 RA : Get same piece
  2A
      OA
          LDN
                     :Test if = 80 black
  2B
      FB
           XRI
  2C
      80
  2D
      32
           BZ
                     :If so, branch to 0721 to continue search
      21
  2E
                 RD : Reset VA value
  2F
      9D
          GHI
0730
      56
           STR
                 R6 ;
                          3 M(R(6))
      8D
           GLO
                 RD ; Reset VB value
  31
      57
1E
                          @ M(R(7))
           STR
                 R7 ;
                 RE : Add 01 to RE index #1
           INC
      8E
           GLO
                    :Test if RE.O = 02 yet
      FB
           XRI
      02
           BNZ
                    ; If not, branch to 0721
      3A
```