```
006B
       FB
             XRI
                         :Test if RA.1 = OA = Past text page #6
  6C
        OA.
  6D
        3A.
             BNZ
        44
  6E
                         ; If not, continue
  6F
       D4
                   R4
             SEP
0070
        02
                         ; Call Create Link Table Entry
        C4
  71
  72
        30
                         ;Then branch to Signal User for next section
             BN
        2D
  73
                         ; Or 2nd pass
                          -PATCH-
0074
       D4
                   R4
             SEP
  75
76
        03
                         ; Call Initialize Link Table
        B7
       F8
             LDI
                         :Patched instruction - value for RD.1
  78
        0A
       30
23
  79
             BN
                         ; Branch back from patch @ 0023
  7A
                   2ND PASS CONTROLLER
007B
       D4
             SEP
                   R4
                         Begin 2nd pass
  7C
        03
                         ;Call Reinitialize Link Table-Entry #2
       C4
  7D
       F8
  7Ξ
             LDI
  7F
        0C
0080
        B9
                         ;Set R9 = First address for creating Object Code
             PHI
                   R9
  81
        F8
             LDI
  82
        00
  83
             PLO
        Λ9
                   R9
                         End preinitialization
  84
        D4
             SEP
                   R4
                         Begin Main Loop
  85
86
        03
                         ; Call Signal User (Pass 2 or END)
        54
  87
        DC
             SEP
                   RC
                         ;Call Key Scan in ROM
  88
        FB
             XRI
  89
        02
  81
        3A
             BNZ
                         ; If key 2 not pressed, go end
  8B
        F8
                         ;Else continue
  80
        F8
             LDI
  8D
        06
  8E
        AE
             PLO
                   RE
                         ;RE.0 = # pages to be read
  28
        D4
             SEP
                   R4
        03
65
0090
                         ; Call Tape Read/Write
  91
        04
  92
                         ;Start address to input source code
  93
94
        00
        C2
                         ; Indicator byte selects Tape Read
        F8
             LDI
```