```
0108
       16
            None
       16
  09
            None
  0A
        CF
            Erase Text Buffer
  0B
       E2
            Tape Read
       F5
  OC
            Home Cursor
  OD
            Delete to End of Line
  0E
        98
            Delete to End of Page
       E2
  OF
            Tape Write
                     CONTROL (C) FUNCTION DECODE
0110
       DC
             SEP
                   RC
                        ;Do sub - Key Scan in ROM
  11
       AF
             PLO
                   RF
                        ;Put the key press into RF.0
  12
        93
             GHI
                   R3
                        :Load RF.1 with page address of Jump Table
  13
14
        BF
             PHI
                   RF
                        ;RF indexes the above table
       OF
             LDN
                   RF
                        Get the byte from table
             PLO
       А3
                   R3
                        ; Put in R3.0 to effect jump to that function
       D5
             SEP
                   R5
                        Return instruction for disabled functions
                         REVERSE FIELD VIDEO
       F8
0117
             LDI
  18
       03
  19
       BE
             PHI
                   RE
  1A
       F8
             LDI
  1B
       B8
  1C
       AE
             PLO
                   RE
                        RE points to Erase Routine Memory byte @ 03B8
  1D
       OE
                        Get the current erase byte
             LDN
                   RE
  1E
       FB
             XRI
  1F
       FF
                        :Compliment
0120
       5E
             STR
                   RE
                        ; Put new byte back
       D4
  21
             SEP
                   R4
                        ; (Routines branch to here that require the next sub)
  22
       03
                        ; Call Display Memory Page
  23
24
       2F
       D4
             SEP
                   R4
  25
26
       03
                        ; Call Home Cursor
       53
  27
       D5
             SEP
                   R5
                        ; Return
                             PAGE FORWARDS
0128
       99
             GHI
                   R9
  29
       FB
             XRI
                        :Test if R9.1 is at last page of text
  2A
       05/09
                        (3K=05/4K=09)
                        ; If not, continue
  2B
       3A
             BNZ
       2E
  2C
  2D
       D5
             SEP
                        ;Else return
                   R5
  2E
       99
             GHI
                   R9
  2F
       FC
             ADI
                        ; Add 01 to R9.1 for next page
```