```
0236
        B7
             PHI
                   R7
                         Restore old cursor address
  37
38
        D4
              SEP
                   R4
        03
                         ; Call Display Cursor
  39
3A
3B
3C
3D
        5Ĉ
        D5
             SEP
                   R5
                         Return
        7B
             SEQ
                         ; Tone on for end of text warning
        F8
             LDI
        3C
                         ; Value for 1 second tone
  3Ē
        Ã8
             PLO
                         :Put into timer
                   R8
        88
  3F
             GLO
                   R8
0240
        3A
              BNZ
                         ;Loop until timer = 00
        3F
  41
  42
        7A
             REQ
                         :Tone off
  43
        D5
             SEP
                         ;Return
                   R5
                     SCROLL BACKWARD - CURSOR HOMED
0244
        89
             GLO
                   R9
  45
46
        FF
              SMI
        10
                         :Subtract 16 decimal
  47
48
        A9
             PLO
                   R9
        99
             GHI
                         From R9 (data page pointer)
                   R9
  49
        7F
              SMBI
  4A
        00
                         ;To point back one row
  4B
        B9
             PHI
                   R9
  4C
        FB
             XRI
  4D
        03
                         ; Test if R9 went past first page
        32
  4E
              BZ
        57
D4
  4F
                         Boundary (0400)-If so, branch to error & return
0250
              SEP
                   R4
                                                   (resetting R9 = 0400)
        03
2F
  5123456789ABCD
                         ; Call Display Memory - one text page (scrolled back)
                                                    (cursor off)
        D4
              SEP
                   R4
        03
53
                                                    (cursor on)
                         : Call Home Cursor
        D5
                    R5
              SEP
                         :Return
        F8
              LDI
        04
                         :Reset R9
        B9
              PHI
                    R9
        F8
              LDI
                          ;To first text page
        00
              PLO
                          :At 0400
        A9
                   R9
        30
              BN
  5E
        3B
                          Branch to error tone @ 023B & return
                               CURSOR DOWN
025F
60
        D4
                    R4
              SEP
        03
                          ; Call Display Cursor to erase old
```