```
005E
        22
              DEC
                   R2
                         ; Decrement stack to counter unwanted INC next
5F
0060
        61
              OUT
                         ; Turn off video (R(x)+1)
        83
             GLO
                   R3
        A4
  61
              PLO
                   R4
  62
        24
             DEC
                   R4
                         ;Swap program counters - R4 now is PC
  63
64
        93
B4
             GHI
                   R3
                          and must later be reset to 0313 for Call Routine
              PHI
                   R4
  65
66
        D4
              SEP
                   R4
        F8
             LDI
  67
        80
  68
        B3
             PHI
                   R3
                         ;Set R3.1 to ROM Read/Write Routine addresses
  69
        8Ē
             GLO
                   RF
  6A
                         ;Test RF.0 to see if Read/Write selected
        FB
             XRI
  6B
        OF
                         (Key press is still in RF.0)
        3A
74
  6c
             BNZ
                         ; Branch to Read Routine
  6D
        F8
  6E
             LDI
                         Begin Call to Tape Write
  6F
        91
0070
        A3
             PLO
                   R3
                         ;Set R3 = Tape Write
        D3
             SEP
  71
                   R3
                         ; Do sub - Write RE.O pages to tape
        30
78
  72
                         Returns via D4 to here
             BN
                         :Branch to exit
  74
        F8
             LDI
                         ; Begin Call to Tape Read
  75
76
        C2
        A3
             PLO
                         R3 points to Read Routine in ROM
                   R3
  77
78
        D3
                         :Call Tape Read - returns via D4 to next line
             SEP
                   R3
        E2
             SEX
                         X = 2
                                                          (video is on)
        60
  79
             IRX
                         Point to saved data
        72
A6
             LDXA
  7A
                         ;Pop R6.0
  7B
             PLO
                   R6
                         Restore R6.0
             LDX
  7C
        FO
                         ; Pop R6.1
             PHI
                         :Restore R6.1
                                          (R4 still PC)
        B6
                   R6
  7D
        84
                   R4
  7E
             GLO
        A3
23
94
  7F
             PLO
                   R3
0080
             DEC
                   R3
                         ;Swap PC's
                   R4
             GHI
  81
        B3
             PHI
  82
                   R3
  83
        D3
             SEP
                   R3
                         :R3 now is PC again
  84
        F8
             LDI
  85
86
        03
B4
             PHI
                   R4
        F8
  87
             LDI
                         :Reset R4 for use
  88
        13
A4
                         ; As dedicated Call Routine pointer
  89
                   R4
             PLO
             LDI
  88
        F8
        04
  8в
                         Reinitialize R9 -Text Data pointer
  8c
        B9
             PHI
                   R9
        F8
  ans
             LDI
  8E
        00
                         :To point to first page of text
  8F
        A9
             PLO
                   R9
```