```
036A
                                 PC's
              GLO
                    R3
                                         R4=PC
                                               & must later be reset
                           ; Swap
        \Lambda \tilde{4}
  6B
              PLO
                    R4
                                   64
  6C
                              88
                                   86
                                                                      11
        24
                    R4
              DEC
  6D
        93
B4
              GHI
                    R3
                           3
                    R4
  6E
              PHI
                              64
                                                    69
  6F
        D4
                    R4
              SEP
0370
        22
              DEC
                    R2
                           ;To counter increment next (x=2)
        61
  71
              INP
                           ; Turn off video (R(x)+1)
  72
        F8
              LDI
  73
74
        80
        B3
47
              PHI
                    R3
                           R3.1 = 80
  75
76
                          ;Get Read=C2/Write=91 byte from caller
              LDA
                    R7
        A3
              PLO
                           ; Put in R3 to address proper routine
                    R3
  77
78
        97
              GHI
                    R7
        73
87
              STXD
                           Push R7.1
  79
7A
              GLO
                    R7
        73
                                                 Save old R7 R9 which will
              STXD
                           ;Push R7.0
                                                 change (RC.0 will also
  7B
        99
                    R9
              GHI
        73
89
  7C
              STXD
                           Push R9.1
                                                 change & must be reset
  7D
              GLO
                                                 to 95 (8195)
                    R9
  7E
        73
              STXD
                           ;Push R9.0
        D3
84
  7F
              SEP
                    R3
                           ;Call ROM Read/Write
0380
              GLO
                    R4
                           ;Swap PC's back
                                               R3=PC again
        A3
  81
              PLO
                    R3
                           3
                                   98
                                         **
  82
        23
              DEC
                    R3
        94
                    R4
  83
              GHI
  84
        B3
              PHI
                    R3
  85
86
                             48
                                         89
        D3
              SEP
                    R3
        E2
              SEX
                    2
                           :X = 2
  87
        60
              IRX
                           :Point to saved data
  88
        72
              LDXA
                           :Pop R9.0
  89
        A9
              PLO
                    R9
                           ;Restore R9.0
        72
  8A
                           ;Pop R9.1
              LDXA
              PHI
  8B
        B9
                           Restore R9.1
                    R9
        72
  8¢
              LDXA
                           ;Pop R7.0
  8D
        A7
              PLO
                    R7
                           Restore R7.0
  8E
        FO
                           ;Pop R7.1
              LDX
  8F
                           :Restore R7.1
        B7
              PHI
                    R7
        F8
0390
              LDI
  91
        03
B4
                           Reset R4 = 0313 - Call routine PC
  92
              PHI
                    R4
  93
94
        F8
              LDI
        01
  95
96
        A4
                    R4
                           :Reset R4 = 0313 - Call routine PC
              PLO
        F8
              LDI
                           Reset RC = 8195 - Key Scan Routine
  97
        95
  98
        AC
              PLO
                    RC
  99
        D5
              SEP
                    R5
                           ;Return
```