```
0109
         FF
                 -None-
  0A
         FF
                 -None-
                 (Second Escape key press returns to normal mode)
  0B
         FF
                 -None-
  OC.
         FF
  OD
         FF
                 -None-
  0E
         FF
                 -None-
  OF
         FF
                 -None-
0110
         FF
                Key 0 - Return to normal typing mode
  11
         37
                Key 1 - Page Back
  12
         28
                Key 2 - Page Forward
                Key 3 - Select Page "N"
Key 4 - Cursor On/Off
  13
         FO
  14
         E6
                Key 5 - No Function (old Reverse Video)
Key 6 - Insert Line
Key 7 - Delete Line
Key 8 - None
  15
16
         FF
         44
  17
18
         6c
         FF
                Key 9 - None
-None-
  19
         FF
  1A
         FF
  1B
        FF
                -None-
  1C
        FF
                -None-
  1D
        FF
                -None-
  1E
                -None-
        FF
  1F
        FF
                -None-
```

MODIFICATION #2 ESCAPE FUNCTION SELECT

01FA	93	GHI	R3	Get page address of Jump Table
$\mathbf{F}\mathbf{B}$	BF	PHI	RF	Put in RF.1
FC	OF	LDN	RF	; Load function address from table
FD	A3	PLO	R3	Put in R3.0 to jump to function
FE	E2	NOP		Filler
$\mathbf{F}\mathbf{F}$	D5	SEP	R5	Return (for disabled functions)

MODIFICATION #2 CALL TO ESCAPE DECODING

02F0 F1	D4 02	SEP	R4	;Call warning tone to signal ESCAPE key pressed
F2 F3 F4	3B D4 00	SEP	R4	;Call Escape Decoding routine
F5 F6	44 D5	SEP	R5	Return