```
01B4
        52
              STR
                    R2
                          Push RA.O to test
        8C
  B5
              GLO
                    RC
        F3
32
  В6
              XOR
                          :If = RC.0 (last line of text pointer)
  B7
              BZ
                          ; If = (RA=RC) then done - branch to exit
  B8
        BE
                          ;Else continue
        D4
  B9
              SEP
                    R4
        02
  BA
                          ; Call Carriage Return for next line
  BB
        98
        30
  BC
              BN
                         ;Loop till done
        A9
  BD
        D4
  BE
              SEP
                   R4
  BF
        03
                         ; Call Display Cursor to erase
        5C
01C0
        E2
  C1
                   2
              SEX
                         X = 2
  C2
        60
              IRX
                         ; Point to saved data
  C3
C4
        72
              LDXA
                         ;Pop RA.O
        AA
             PLO
                   RA
  05
06
        72
             LDXA
                         ;Pop RA.1
        BA
             PHI
                   RA
                         ;Restore RA
  C7
        72
             LDXA
                         :Pop R7.0
  C8
        A7
             PLO
                   R7
  C9
        FO
             LDX
                         ; Pop R7.1
  CA
        B7
             PHI
                   R7
                         :Restore R7
  CB
        D4
             SEP
                   R4
  CC
        03
                         ; Call Display Cursor
        5Ĉ
  CD
  CE
        D5
             SEP
                   R5
                         :Return
                           ERASE TEXT BUFFER
01CF
        F8
             LDI
        04
  DO
  D1
                                  R9 = 0400 = beginning Text Buffer
        BE
             PHI
                   RE
                         ;Set RE,
  D2
        B9
             PHI
                   R9
                         ş
  D3
        F8
                                *1
             LDI
  D4
                                11
        00
  D5
D6
                                         11
        AE
             PLO
                   RE
                         i
                                **
        A9
             PLO
                   R9
        F8
  D7
             LDI
  D8
        20
                         ASCII code for space
  D9
        5E
             STR
                   RE
                         ;Store via RE in text
  DA
        1E
                         ;Re + 1 next character position
             INC
                   RE
  DB
        9E
             GHI
                   RE
  DC
        FB
             XRI
                         ; Test if RE went past last page of text
        06/0A
  DD
                         ; If not, loop until all text set to ASCII 20's
  DE
        3А
             BNZ
  DF
        D7
01E0
        30
             BN
                         ; Branch to exit point, displaying memory page,
        21
  E1
                         Homing cursor, and return @ 0121
```