## SUBROUTINE LIST

0100-01FF 0110-0116 0117-0127 0128-0136 0137-0141 0142-0143 0144-016B 016C-0176 0177-0197 0198-01CE 01CF-01E1 01E2-01E5 01E6-01EF 01F0-01F4 01F5-01F9	Jump table for Control C functions Control C function decode Reverse field video Page forward Page backward  FILLER  Insert line Delete and close up line Erase to end of line Erase to end of page Erase text buffer Call to tape read/write routines Call to Cursor On/off routine Call to show page "N" Home cursor (on command)
01FA-01FF	AVAILABLE
0200-020F 0210-0243	Function decode for keys 8-F Scroll forward. Cursor position unchanged. Error tone @ 023B
0244-025E 025F-027E 027F-0297 0298-02C5 02C6-02DD 02DE-02EF 02F0-02F6 02F7-02FF	Scroll backward - cursor homed Cursor down Cursor up Carriage return Cursor right Cursor left Control C select  AVAILABLE
0300-0311 0312-0321 0322-032E 032F-0352	4-page interrupt with timer Call routine - runs in R4 Return routine - runs in R5 Display memory page. One page displayed. Cursor off on return
0353-035B 035C-035E 035F-0387 0388-039E	Home cursor. Cursor must be off on entry
039F-03AD 03AE-03BF 03C0-03D2	New character at cursor; for entering new characters Erase display pages. Sets 4 refresh pages = 0 Cursor on/off. Complements cursor for invisible or underline display
03D3-03DF	Show page "N". Enter # of page to display. 1-6-4K
03E0-03FF	AVAILABLE