```
05A4  F8  LDI         ;Load Address of Back Up
  A5  DE              ;Cursor subroutine, and put
  A6  AE  PLO   RE    ;In RE.0
  A7  DE  SEP   RE    ;Then call the subroutine
  A8  F8  LDI         ;Load loop count...Begin part two...
  A9  04              ;Right character...and put the count
  AA  AF  PLO   RF    ;In Utility register RF.0
  AB  0C  LDN   RC    ;Get bit pattern of the character
  AC  F6  SHR         ;Shift right to push MSB's
  AD  F6  SHR         ;To LSB position (right side)
  AE  F6  SHR         ;    "      "
  AF  F6  SHR         ;    "      "
05B0  52  STR   R2    ;Push stack
  B1  0D  LDN   RD    ;Get existing character line on display
  B2  F1  OR          ;page, then "OR" it with Stack
  B3  5D  STR   RD    ;And replace it on display page
  B4  F8  LDI         ;Load address
  B5  E9              ;Of Next-line Subroutine
  B6  AE  PLO   RE    ;Into RE.0
  B7  DE  SEP   RE    ;And call the subroutine
  B8  4C  LDA   RC    ;Get same bit pattern (packed)
  B9  FA  ANI         ;"AND" it with
  BA  0F              ;0F for LSB's
  BB  52  STR   R2    ;Push stack
  BC  0D  LDN   RD    ;Get existing character bit pattern displayed
  BD  F1  OR          ;"OR" it with top of stack
  BE  5D  STR   RD    ;And replace in memory
  BF  DE  SEP   RE    ;Call Next-line Subroutine
05C0  2F  DEC   RF    ;Loop count-01
  C1  8F  GLO   RF    ;To test if done
  C2  3A  BNZ         ;Loop to 05AB
  C3  AB              ;RF=00 (two characters displayed per byte)
  C4  8D  GLO   RD    ;Get current cursor position
  C5  FA  ANI         ;"AND" it with 0F to mask for
  C6  0F              ;LSB's (End of line is always X7)
  C7  FB  XRI         ;Exclusive OR with 07
  C8  07              ;To test if at end of line
  C9  32  BZ          ;Branch if at end of line to
  CA  D7              ;Carriage Return @ 05D7
  CB  F8  LDI         ;Or load address
  CC  DE              ;Of back up cursor subroutine
  CD  AE  PLO   RE    ;Put in RE.0
  CE  DE  SEP   RE    ;And call the subroutine
  CF  1D  INC   RD    ;Next character position (cursor +1)
05D0  9C  GHI   RC    ;Get RC to test
  D1  FB  XRI         ;If at end of
  D2  08              ;Character set
  D3  3A  BNZ         ;If not, loop until
  D4  8E              ;Done to 058E
  D5  12  INC   R2    ;R2+1 (Reset Stack Pointer)
  D6  D4  SEP   R4    ;Return to CHIP-8 control
  D7  8D  GLO   RD    ;Carriage return
  D8  FF  SMI         ;Subtract 07 from cursor
  D9  07              ;To back to beginning of line
```