洲江水学

实验报告

课程名称:	嵌入式系统	实验类型:_	综合
实验项目名称:	任务 11:DHCP 服务器		
学生姓名:3	E宁 专业: <u>计算机科学</u>	<u> </u>	120101836
同组学生姓名:		指导老师:	葵铭
实验地点:	实验日期: <u>2</u>	015 年 3 月 27	日

实验目的和要求

- 掌握 DHCP 服务器的概念;
- 了解如何在 Raspberry Pi 搭建 DHCP 服务器。
- 把 Raspberry Pi 变成一个 DHCP 服务器。。

实验器材

硬件:

- Raspberry Pi 板一块;
- 5V/1A 电源一个;
- microUSB 线一根;

- USB-TTL 串口线一根(PL2303 芯片)。
- PC(Windows/Mac OS/Linux)一台;
- 以太网线一根(可能还需要路由器等)

软件:

- PC 上的 USB-TTL 串口线配套的驱动程序;
- PC 上的串口终端软件,如 minicom、picocom、PuTTY 等;
- PC 上的 SSH 软件,如 PuTTY, XShell 等

实验内容和原理

- 安装 DHCP 服务器软件;
- 对 DHCP 服务器软件进行配置;
- 验证 DHCP 服务器的功能。

实验过程和数据记录

1. 配置无线网卡

本实验选择使用无线网卡来完成。因此必须先配置无线网卡。网卡型号是 RealTek RTL8188CUS。

首先安装 hostapd 用于管理无线共享。

sudo apt-get install hostapd

但是官方的版本不支持我们手中的无线网卡,在网络上找到了可行的方法:有人专门编译了适用的版本。通过以下的指令来修改安装好的 hostapd。

```
# wget http://www.daveconroy.com/wp3/wp-
content/uploads/2013/07/hostapd.zip
# unzip hostapd.zip
# sudo mv /usr/sbin/hostapd /usr/sbin/hostapd.bak
# sudo mv hostapd /usr/sbin/hostapd.edimax
# sudo ln -sf /usr/sbin/hostapd.edimax /usr/sbin/hostapd
# sudo chown root.root /usr/sbin/hostapd
# sudo chmod 755 /usr/sbin/hostapd
```

2. 安装 DHCP 服务器软件;

首先安装 udhcpd

sudo apt-get install udhcpd

```
Pi@raspberrypi ~ $ sudo apt-get install udhcpd
Reading package lists... Done
Building dependency tree
Reading state information... Done
The following extra packages will be installed:
    busybox
The following NEW packages will be installed:
    busybox udhcpd
0 upgraded, 2 newly installed, 0 to remove and 0 not upgraded.
Need to get 459 kB of archives.
After this operation, 843 kB of additional disk space will be used.
Do you want to continue [Y/n]? y
Get:1 http://mirrordirector.raspbian.org/raspbian/ wheezy/main busybox armhf 1:1.20.0-7 [438 kB]
Get:2 http://mirrordirector.raspbian.org/raspbian/ wheezy/main udhcpd armhf 1:1.20.0-7 [20.9 kB]
Fetched 459 kB in 14s (30.8 kB/s)
Selecting previously unselected package busybox.
(Reading database ... 84700 files and directories currently installed.)
Unpacking busybox (from .../busybox 1%3a1.20.0-7_armhf.deb) ...
Selecting previously unselected package udhcpd.
Unpacking udhcpd (from .../udhcpd_1%3a1.20.0-7_armhf.deb) ...
Setting up busybox (1:1.20.0-7) ...
Setting up busybox (1:1.20.0-7) ...
Setting up udhcpd (1:1.20.0-7) ...
Setting up udhcpd (Edit /etc/default/udhcpd to enable it.
```

3. 对 DHCP 服务器软件进行配置;

编辑 udhcpd 的配置文件/etc/udhcpd.conf

sudo nano /etc/udhcpd.conf

主要修改的内容如下:

```
# The start and end of the IP lease block
start
               192.168.0.20
                              #default: 192.168.0.20
              192.168.0.254
                              #default: 192.168.0.254
end
# The interface that udhcpd will use
   interface
                  wlan0
                                 #default: eth0
# keyword 'opt' or 'option'. If an option can take
multiple items, such
# as the dns option, they can be listed on the same
line, or multiple
# lines. The only option with a default is 'lease'.
#Examles
opt
       dns
               114.114.114.114
option subnet 255.255.255.0
opt
              192.168.10.2
       router
opt
               192.168.10.10
       wins
               129.219.13.81
option dns
# appened to above DNS servers for a total of 3
option domain local
                              # 10 days of seconds
option lease
               864000
```

随后还需要修改/etc/default/udhcpd, 注释其中的

DHCPD_ENABLED="no" 这一行。

sudo nano /etc/default/udhcpd

```
# Comment the following line to enable

# DHCPD_ENABLED="no"

# Options to pass to busybox' udhcpd.

# -S Log to syslog
# -f run in foreground

DHCPD_OPTS="-S"
```

还需要给我们的无线网卡一个 IP。

sudo ifconfig wlan0 192.168.10.2

再编辑网卡配置文件/etc/network/interfaces 注释掉其中关于无线网卡的部分,最终得到下图的结果。

sudo nano /etc/network/interfaces

```
GNU nano 2.2.6
                         File: /etc/network/interfaces
auto lo
iface lo inet loopback
# iface eth0 inet dhcp
allow-hotplug wlan0
# iface wlan0 inet manual
# wpa-roam /etc/wpa_supplicant/wpa_supplicant.conf
# iface default inet dhcp
iface wlan0 inet static
address 192.168.10.2
netmask 255.255.255.0
iface eth0 inet static
address 222.205.47.11
gateway 222.205.47.1
netmask 255.255.255.0
network 222.205.47.0
```


接着,还需要配置我们之前安装好的 hostapd。设置 Wi-Fi 相关的内容。如下图

sudo nano /etc/hostapd/hostapd.conf

```
interface=wlan0
driver=rtl871xdrv
ssid=Ning's RPi
hw_mode=g
channel=6
macaddr_acl=0
auth_algs=1
ignore_broadcast_ssid=0
wpa=2
wpa_passphrase=wangning
wpa_key_mgmt=WPA-PSK
wpa_pairwise=TKIP
rsn_pairwise=CCMP
File: /etc/hostapd/hostapd.conf
```

配置完成后,重启系统,以使得 hostapd 正常工作。键入以下命令以验证 hostapd。

sudo hostapd -dd /etc/hostapd/hostapd.conf 这时适用 PC 搜索 Wi-Fi 信号,能找到 SSID 为我们在配置文件里所预设的 AP。则说明 hostapd 配置正确。



4. 验证 DHCP 服务器的功能。

选择连接上述的 Wi-Fi,打开 Windows 的网络共享中心,可以看到以下。



看到分配的 IP 段在我们的预设 IP 段之内。这说明 DHCP 服务配置正确。

实验结果分析

DHCP 服务器搭建成功。