# 1. Description


### 1.1. Project

Project Name	INC-MBPCM1-01
Board Name	custom
Generated with:	STM32CubeMX 4.26.0
Date	06/29/2018

### 1.2. MCU

MCU Series	STM32F0
MCU Line	STM32F0x0 Value Line
MCU name	STM32F030F4Px
MCU Package	TSSOP20
MCU Pin number	20

### 2. Pinout Configuration




# 3. Pins Configuration

Pin Number TSSOP20	Pin Name (function after reset)	Pin Type	Alternate Function(s)	Label
1	воото	Boot		
2	PF0-OSC_IN	I/O	RCC_OSC_IN	
3	PF1-OSC_OUT	I/O	RCC_OSC_OUT	
4	NRST	Reset		
5	VDDA	Power		
6	PA0 *	I/O	GPIO_Output	SYS_LED
7	PA1 *	I/O	GPIO_Output	K10_GPIO
8	PA2	I/O	USART1_TX	
9	PA3	I/O	USART1_RX	
10	PA4 *	I/O	GPIO_Output	K1_GPIO
11	PA5 *	I/O	GPIO_Output	K2_GPIO
12	PA6 *	I/O	GPIO_Output	K9_GPIO
13	PA7 *	I/O	GPIO_Output	K4_GPIO
14	PB1 *	I/O	GPIO_Output	K5_GPIO
15	VSS	Power		
16	VDD	Power		
17	PA9 *	I/O	GPIO_Output	K7_GPIO
18	PA10 *	I/O	GPIO_Output	K6_GPIO
19	PA13	I/O	SYS_SWDIO	
20	PA14	I/O	SYS_SWCLK	

<sup>\*</sup> The pin is affected with an I/O function

## 4. Clock Tree Configuration



# **5.** IPs and Middleware Configuration 5.1. RCC

High Speed Clock (HSE): Crystal/Ceramic Resonator

5.1.1. Parameter Settings:

#### **System Parameters:**

VDD voltage (V) 3.3
Prefetch Buffer Enabled

Flash Latency(WS) 1 WS (2 CPU cycle)

**RCC Parameters:** 

HSI Calibration Value 16
HSE Startup Timout Value (ms)

LSE Startup Timout Value (ms) 5000

#### 5.2. SYS

mode: Debug Serial Wire Timebase Source: TIM1

#### 5.3. USART1

**Mode: Asynchronous** 

5.3.1. Parameter Settings:

#### **Basic Parameters:**

Baud Rate 115200 \*

Word Length 8 Bits (including Parity)

Parity None Stop Bits 1

#### **Advanced Parameters:**

Data Direction Receive and Transmit

Over Sampling 16 Samples
Single Sample Disable

#### **Advanced Features:**

Auto Baudrate Disable

TX Pin Active Level Inversion Disable

RX Pin Active Level Inversion Disable

Data Inversion Disable

TX and RX Pins Swapping Disable

Overrun Enable

DMA on RX Error Enable

MSB First Disable

#### 5.4. FREERTOS

mode: Enabled

#### 5.4.1. Config parameters:

#### **Versions:**

FreeRTOS version 9.0.0
CMSIS-RTOS version 1.02

#### Kernel settings:

USE\_PREEMPTION Enabled

CPU\_CLOCK\_HZ SystemCoreClock

TICK\_RATE\_HZ 1000
MAX\_PRIORITIES 7
MINIMAL\_STACK\_SIZE 96
MAX\_TASK\_NAME\_LEN 16

USE\_16\_BIT\_TICKS Disabled

IDLE\_SHOULD\_YIELD Enabled

USE\_MUTEXES Enabled

USE\_RECURSIVE\_MUTEXES Disabled

USE\_COUNTING\_SEMAPHORES Disabled

QUEUE\_REGISTRY\_SIZE 8

USE\_APPLICATION\_TASK\_TAG Disabled
ENABLE\_BACKWARD\_COMPATIBILITY Enabled
USE\_PORT\_OPTIMISED\_TASK\_SELECTION Disabled
USE\_TICKLESS\_IDLE Disabled
USE\_TASK\_NOTIFICATIONS Enabled

#### Memory management settings:

Memory AllocationDynamicTOTAL\_HEAP\_SIZE2048Memory Management schemeheap\_4

#### Hook function related definitions:

USE\_IDLE\_HOOK Disabled
USE\_TICK\_HOOK Disabled
USE\_MALLOC\_FAILED\_HOOK Disabled
USE\_DAEMON\_TASK\_STARTUP\_HOOK Disabled
CHECK\_FOR\_STACK\_OVERFLOW Disabled

#### Run time and task stats gathering related definitions:

GENERATE\_RUN\_TIME\_STATS Disabled
USE\_TRACE\_FACILITY Disabled
USE\_STATS\_FORMATTING\_FUNCTIONS Disabled

#### Co-routine related definitions:

USE\_CO\_ROUTINES Disabled MAX\_CO\_ROUTINE\_PRIORITIES 2

#### Software timer definitions:

USE\_TIMERS Disabled

#### Interrupt nesting behaviour configuration:

LIBRARY\_LOWEST\_INTERRUPT\_PRIORITY 3
LIBRARY\_MAX\_SYSCALL\_INTERRUPT\_PRIORITY 3

#### 5.4.2. Include parameters:

#### Include definitions:

vTaskPrioritySet Enabled uxTaskPriorityGet Enabled vTaskDelete Enabled vTaskCleanUpResources Disabled vTaskSuspend Enabled vTaskDelayUntil Disabled vTaskDelay Enabled Enabled xTaskGetSchedulerState xTaskResumeFromISR Enabled xQueueGetMutexHolder Disabled Disabled xSemaphoreGetMutexHolder pcTaskGetTaskName Disabled uxTaskGetStackHighWaterMark Disabled Disabled xTaskGetCurrentTaskHandle eTaskGetState Disabled xEventGroupSetBitFromISR Disabled xTimerPendFunctionCall Disabled xTaskAbortDelay Disabled xTaskGetHandle Disabled

#### \* User modified value

# 6. System Configuration

### 6.1. GPIO configuration

IP	Pin	Signal	GPIO mode	GPIO pull/up pull down	Max Speed	User Label
RCC	PF0-OSC_IN	RCC_OSC_IN	n/a	n/a	n/a	
	PF1- OSC_OUT	RCC_OSC_OUT	n/a	n/a	n/a	
SYS	PA13	SYS_SWDIO	n/a	n/a	n/a	
	PA14	SYS_SWCLK	n/a	n/a	n/a	
USART1	PA2	USART1_TX	Alternate Function Push Pull	No pull-up and no pull-down	High *	
	PA3	USART1_RX	Alternate Function Push Pull	No pull-up and no pull-down	High *	
GPIO	PA0	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	SYS_LED
	PA1	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	K10_GPIO
	PA4	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	K1_GPIO
	PA5	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	K2_GPIO
	PA6	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	K9_GPIO
	PA7	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	K4_GPIO
	PB1	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	K5_GPIO
	PA9	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	K7_GPIO
	PA10	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	K6_GPIO

### 6.2. DMA configuration

nothing configured in DMA service

### 6.3. NVIC configuration

Interrupt Table	Enable	Preenmption Priority	SubPriority
Non maskable interrupt	true	0	0
Hard fault interrupt	true	0	0
System service call via SWI instruction	true	0	0
Pendable request for system service	true	3	0
System tick timer	true	3	0
TIM1 break, update, trigger and commutation interrupts	true	0	0
USART1 global interrupt	true	3	0
Flash global interrupt	unused		
RCC global interrupt	unused		

<sup>\*</sup> User modified value

# 7. Power Consumption Calculator report

#### 7.1. Microcontroller Selection

Series	STM32F0
Line	STM32F0x0 Value Line
мси	STM32F030F4Px
Datasheet	024849_Rev2

#### 7.2. Parameter Selection

Temperature	25
Vdd	3.6

# 8. Software Project

### 8.1. Project Settings

Name	Value	
Project Name	INC-MBPCM1-01	
Project Folder	E:\XCP Github\STM32F_CubeMX\STM32F030F4_CubeMX\INC-MBPCM1-01	
Toolchain / IDE	MDK-ARM V5	
Firmware Package Name and Version	STM32Cube FW_F0 V1.9.0	

### 8.2. Code Generation Settings

Name	Value
STM32Cube Firmware Library Package	Copy all used libraries into the project folder
Generate peripheral initialization as a pair of '.c/.h' files	Yes
Backup previously generated files when re-generating	No
Delete previously generated files when not re-generated	Yes
Set all free pins as analog (to optimize the power consumption)	No

<b>9.</b>	Software	Pack	Report
-----------	----------	------	--------