Error of the energy delivered through each forecast day, 22 forecasters on the same test windows. For each unit and day d, the RMS over the unit's windows of the error of the mean load over days 1..d, divided by the unit's mean load; curves are geometric means over one fixed set of units, the aggregation of figure 9 applied to energy. Day 31 is the monthly energy error of figure 11. Computed after scoring. For ankyra-lite the energy to date is that of its trajectory before the continuation layer (readout rule A). ankyra-lite 0.2.0: carrier recipe Rw (trained from scratch with early stopping on the 93-day validation set, then 8 more epochs with the validation span returned and each training window's loss weighted by the inverse-noise rule; six seeds averaged; figure 1b), the anchoring layer, the state rule and the origin-continuity layer; hourly errors score the delivered trajectory after that layer, energy, level and peak are read before it (readout rule A). Linear-context: the TiDE implementation of the release, whose forecast is a linear map of the load context.

