Titel: HLG dimmer aansturing met Arduino

Auteur: Aad Slingerland

Datum: mei 2018

Versie: 1.1

# Inleiding

Het doel van dit project is het maken van een automatische regelaar voor een HLG dimmer. Deze regelaar moet op een bepaald tijdstip een zonsopgang nabootsen en op een later tijdstip een zonsondergang. De door Vincent gebruikte dimmer heeft drie manieren om de dim functie aan te sturen. De voor dit projectje gekozen manier is het gebruiken van een 10 volt PWM signaal.

Op advies van Radio Piet (Arnhem) heb ik in eerste instantie een Arduino Uno van het merk Velleman aangeschaft. Later is gebleken dat door de drie extra elektronische componenten deze Arduino net iets te klein bleek te zijn. Daarom heb ik later een Arduino Mega aangeschaft. Ook van het merk Velleman.

De wens van Vincent is om drie verschillende programma's te hebben. Programma één om de lampen constant aan te zetten. Programma twee met een zonsopkomst om 4:00 uur 's middags en een zonsondergang om 10:00 uur 's morgens (in totaal 16:00 uur licht). Programma drie met een zonsopkomst om 4:00 uur 's middags en een zonsondergang om 4:00 uur 's morgens (in totaal 12:00 uur licht). Daar heb ik zelf Programma nul aan toegevoegd waarbij de verlichting gewoon uit is.

#### Hardware


De gebruikte dimmer voor de LED verlichting is van de fabrikant Mean Well en het typenummer is HLG-185H-C1440B. Het gebruikte Arduino board is een VMA101. Deze is voorzien van een LCD keypad van het type VMA203. Verder is er een klokmodule nodig eveneens van de fabrikant Velleman. Het type is VMA301. Om de 230 volt AC voeding te kunnen schakelen wordt gebruik gemaakt van een relais van het type VMA405.

Verder bleek het nodig om het vijf volt PWM signaal (vande Arduino) op te waarderen naar 10 volt. Eén en ander volgens de specificaties van Mean Well. Op advies van Hureka (Zevenaar) heb ik hiervoor, met een handvol onderdeeltjes, een PWM versterker gemaakt.

Voor het uiteindelijke resultaat is verder gebruik gemaakt van een transformator voor 12 volt gelijkstroom en twee wandcontactdozen voor opbouw. En een plankje MDF van 18 bij 22 cenmtimeter.

Screenshots met de PIN aansluitingen:


# Overzicht



Clock aan ene kant




Clock aan de andere kant




Relais



Converter



Het schema van de converter is:



## Software

Voor het maken van het programma heb ik gebruik gemaakt van de Arduino programmeeromgeving. Zie ook één van de referenties. Voor dit project waren uiteindelijk twee verschillende programma's nodig. Het eerste programma is bedoeld om de Real Time Clock eenmalig op de juiste datum en tijd te zetten.

Daarna zorgt de stroomvoorziening, en de ingebouwde batterij, er voor dat de klok gewoon door blijft lopen. De enige reden waarom dit programma ooit nog een keer nodig zou kunnen zijn is als de batterij van de Real Time Clock vervangen moet worden. De procedure om dit uit te voeren staat in het hoofdstuk ingebruikname.

Het tweede programma, het programma dat 24 uur per dag zeven dagen in de week actief is, is bedoeld om uit de verschillende hoofdprogramma's, zoals gewenst door Vincent, te kunnen kiezen. Een prettige bijeenkomst van het gebruikte LCD shield zijn de drukknopjes waardoor ik in de software bepaalde acties kan nemen.

Er zijn in totaal zes drukknopjes waarvan ik in de huidige versie van de software er drie gebruik. De Select button is bedoeld om tussen de verschillende hoofdprogramma's te schakelen. De Up en Down buttons doen ongeveer hetzelfde.


Zoals in de inleiding al aangegeven zijn er vier hoofdprogramma's:

- PO verlichting uit.
- P1 verlichting aan.
- P2 verlichting met Sunrise om 16:00 uur en Sunset om 10:00 uur.
- P3 verlichting met Sunrise om 16:00 uur en Sunset om 04:00 uur.

## Ingebruikname

Om een programma van een desktop computer of laptop in een Arduino te plaatsen heb je de Arduino programmeeromgeving nodig en een USB kabel tussen de laptop en de Arduino. De details van dit soort werk ga ik hier niet verder beschrijven.

Het eerste programma dat nodig is bij ingebruikname is ClockInit. Alvorens het programma uit te voeren op de Arduino moet in de setup functie de juiste datum en tijd ingesteld worden. Zie onderstaand screenshot:



Het tweede programma, de aansturing van de Mean Well dimmer, kan daarna op de Arduino geplaatst worden. Eveneens weer met een laptop, of desktop computer, die met een USB-kabel aangesloten is aan de Arduino. Zie onderstaand screenshot:

```
📀 HlgController | Arduino 1.8.5
<u>F</u>ile <u>E</u>dit <u>S</u>ketch <u>T</u>ools <u>H</u>elp
   HigController
  2 // HlgController.ino, 201805, Aad Slingerland.
  3 //
  4 #define PIN CE 52
                                                // Chip Enable (VMA301)
  5 #define PIN IO 50
                                                // Input/Output (VMA301)
  6 #define PIN SC 48
                                                // Serial Clock (VMA301)
  7 #define PIN_RELAIS 40
                                                // The relais (VMA406)
  8 #define PIN PWM 3
                                               // PWM enabled pin
                                               // minimum value of duty level
  9 #define DUTY MIN 0
 10 #define DUTY_MAX 255
                                               // maximum value of duty_level
 11 //
 12 #define SUNRISE2 HOUR 16
                                               // four in the afternoon
 13 #define SUNSET2 HOUR 10
                                               // ten in the morning
 14 #define SUNRISE3_HOUR 16
                                               // four in the afternoon
 15 #define SUNSET3_HOUR 04
                                               // four in the morning
 16 //
 17 #define DELAY BUTTON 500UL
                                               // ReadLcdButtonTimed (Unsigned Long)
 18 #define DELAY_P1 3000UL
                                               // Delay for Pl before switching on
 20 const unsigned long countdown = 60 * 15; // sunrise/sunset time in seconds
                                                 Arduino/Genuino Mega or Mega 2560, ATmega2560 (Mega 2560) on COM4
```

#### Een stroomstoring

In geval van een stroomstoring is het van belang dat dit systeem zichzelf herstelt zodat de verlichting uit of aan is al naargelang het gekozen hoofdprogramma en het tijdstip van de stroomstoring. In de software is daarmee rekening gehouden omdat het gekozen hoofdprogramma (PO, P1, P2 of P3) vastgelegd wordt in een geheugenlocatie van de Real Time Clock.

Na een stroomstoring, of bij het resetten van de Arduino, wordt het juiste hoofdprogramma weer opgepakt. Daarna wordt, ingeval van de hoofdprogramma's P2 of P3, gekeken naar het tijdstip en wordt de verlichting eventueel weer ingeschakeld.

# Referenties

Dit project op github:

https://github.com/aadslingerland

De firma Velleman:

https://www.velleman.eu

Het Velleman support forum:

https://forum.vellemanprojects.eu

Arduino development software:

https://www.arduino.cc/en/Main/Software

Software voor de Real Time Clock aansturing (VMA301)

http://digitalab.org/2017/08/real-time-clock-ds1302

De 5V naar 10 V PWM converter:

http://birota.azurewebsites.net/0-5v-to-0-10v-pwm-converter-for-arduino

PWM informatie:

https://provideyourown.com/2011/analogwrite-convert-pwm-to-voltage

## Appendix A (ClockInit)

```
// ClockInit.ino, 201805, Aad Slingerland.
// http://digitalab.org/2017/08/real-time-clock-ds1302/
// Example sketch for interfacing with the DS1302 timekeeping chip.
//
#include <stdio.h>
#include <DS1302.h>
namespace
 //
  // Set the appropriate digital I/O pin connections. These are the pin
  // assignments for the Arduino as well for as the DS1302 chip.
  const int CePin = 52; // Chip Enable
  const int IoPin = 50; // Input/Output
  const int SclkPin = 48; // Serial Clock
  // Create a DS1302 object.
  DS1302 rtc (CePin, IoPin, SclkPin);
  String dayAsString (const Time::Day day)
    switch (day)
   {
     case Time::kSunday: return "Sunday";
     case Time::kMonday:
                           return "Monday";
     case Time::kTuesday: return "Tuesday";
     case Time::kWednesday: return "Wednesday";
     case Time::kThursday: return "Thursday";
                           return "Friday";
     case Time::kFriday:
     case Time::kSaturday: return "Saturday";
    return ("unknown day");
  }
  void printTime()
  {
   //
    // Get the current time and date from the chip.
   Time t = rtc.time();
    // Name the day of the week.
    const String day = dayAsString (t.day);
    // Format the time and date and insert into the temporary buffer.
    //
    char buf[50];
    snprintf (buf, sizeof(buf), "%s %04d-%02d-%02d %02d:%02d:%02d",
     day.c str (), t.yr, t.mon, t.date, t.hr, t.min, t.sec);
    // Print the formatted string to serial so we can see the time.
    //
    Serial.println (buf);
```

```
}
void setup() {
  Serial.begin(9600);
  Serial.println ("VMA101_ClockInit");
  //
  // Initialize a new chip by turning off write protection and clearing the
  // clock halt flag. These methods needn't always be called. See the DS1302
  // datasheet for details.
  //
  rtc.writeProtect(false);
  rtc.halt(false);
 //
  // Make a new time object to set the date and time.
  // This need to be done first time to set the Date and time.
 // Thursday, July 6, 2017 at 22:58:50.
  //
  Time t(2018, 05, 06, 20, 28, 0, Time::kSunday);
 //Set the time and date on the chip.
 rtc.time(t);
}
//
// Loop and print the time every second.
void loop ()
 printTime();
 delay(1000);
```

#### Appendix B (HlgController)

```
// HlgController.ino, 201805, Aad Slingerland.
#define PIN CE 52
                                          // Chip Enable (VMA301)
#define PIN IO 50
                                          // Input/Output (VMA301)
#define PIN SC 48
                                          // Serial Clock (VMA301)
                                          // The relais (VMA406)
#define PIN RELAIS 40
#define PIN PWM 3
                                          // PWM enabled pin
#define DUTY MIN 0
                                          // minimum value of duty level
#define DUTY MAX 255
                                          // maximum value of duty level
//
                                          // four in the afternoon
#define SUNRISE2 HOUR 16
                                          // ten in the morning
#define SUNSET2 HOUR 10
                                          // four in the afternoon
#define SUNRISE3 HOUR 16
#define SUNSET3 HOUR 04
                                          // four in the morning
//
#define DELAY BUTTON 500UL
                                          // ReadLcdButtonTimed (Unsigned Long)
#define DELAY P1 3000UL
                                          // Delay for P1 before switching on
//
const unsigned long countdown = 60 * 15; // sunrise/sunset time in seconds
                                          // time in milliseconds
unsigned long step time = 0;
byte duty level = DUTY MIN;
                                          // PWM duty level value
const String APP = "HlgController";
//
// For this DS1302 library see also:
// http://digitalab.org/2017/08/real-time-clock-ds1302 for the DS1302 library.
//
#include <DS1302.h>
DS1302 rtc (PIN CE, PIN IO, PIN SC);
// Make an LCD object with the standard pins used on the VMA203.
#include <LiquidCrystal.h>
LiquidCrystal 1cd (8, 9, 4, 5, 6, 7);
//
// Buttons defined.
enum Buttons : byte
 BTN NONE,
 BTN SELECT,
 BTN LEFT,
 BTN DOWN,
 BTN UP,
 BTN RIGHT
};
//
// Analogous values for buttons (VMA101 + VMA203).
enum Analogous Values : int
 BTN NONE VAL = 1023,
 BTN SELECT VAL = 640,
 BTN LEFT VAL = 409,
 BTN DOWN VAL = 254,
```

```
BTN UP VAL
              = 98,
  BTN RIGHT VAL = 0,
  BTN RANGE
                = 50
};
//
// Determine which button has been pressed.
int ReadLcdButton ()
 int btn val = analogRead (0);
  // Serial.print ("ReadLcdButton: btn val=");
  // Serial.println (btn val);
 //
  if (btn val > (BTN NONE VAL
                               - BTN RANGE)) return BTN NONE;
  if (btn val > (BTN SELECT VAL - BTN RANGE)) return BTN SELECT;
  if (btn val > (BTN LEFT VAL - BTN RANGE)) return BTN LEFT;
  if (btn_val > (BTN_DOWN_VAL - BTN_RANGE)) return BTN_DOWN;
  if (btn val > (BTN UP VAL - BTN RANGE)) return BTN UP;
  if (btn val > (BTN RIGHT VAL - BTN RANGE)) return BTN RIGHT;
 Serial.println ("LcdReadButton: this line should not occur.");
  return BTN NONE;
}
//
// This method prevents button presses to overflow the state machine
// by keeping the last button pressed noted for a short while.
//
byte ReadLcdButtonTimed ()
  static byte last button = 0;
 static unsigned long last button time = 0;
 byte button = ReadLcdButton ();
  //
  Serial.print
               ("ReadLcdButtonTimed: button=");
  Serial.println (button);
  // Only perform the timed delay for buttons other then BTN NONE.
  if (button != BTN NONE)
   if (button != last button)
     last button = button;
     last button time = millis ();
                   ("ReadLcdButtonTimed: last button time=");
     Serial.print
     Serial.println (last button time);
    }
    else
     unsigned long timed = DELAY BUTTON - (millis () - last button time);
     //
     Serial.print
                    ("ReadLcdButtonTimed: delay=");
     Serial.println (timed);
```

```
//
     delay (timed);
     last_button = BTN_NONE;
     button = BTN NONE;
    }
  else
   last_button = BTN_NONE;
  return button;
}
//
// A small class to encapsulate the operation of a VMA405 relay.
class Relay
 public:
   Relay (byte pin)
     _pin = pin;
    void On ()
     pinMode (_pin, OUTPUT);
     digitalWrite ( pin, HIGH);
   void Off ()
     pinMode (_pin, OUTPUT);
     digitalWrite ( pin, LOW);
    }
 private:
   byte _pin;
Relay rel (PIN RELAIS);
enum Main_states : byte
 STATE P0 = 0,
 STATE_P1 = 1,
 STATE P2 = 2,
 STATE P3 = 3
byte current_main_state;
enum P1 states : byte
 P1 WAITING = 0,
 P1_ON
         = 1
byte current p1 state = P1 WAITING;
enum P2_states : byte
 P2_OFF
          = 0,
 P2 SUNRISE = 1,
```

```
= 2,
  P2 ON
 P2 SUNSET = 3
byte current_p2_state = P2 OFF;
boolean dirty p2 state = true;
void setup ()
 Serial.begin (9600);
  Serial.println (" ");
  Serial.println (APP);
  //
  lcd.begin (16, 2);
 lcd.clear ();
  // The previous current main state is saved in clock module. Get it from there.
 byte b0 = rtc.readRam (0);
  if (b0 \geq= STATE P0 && b0 \leq= STATE P3)
   current main state = b0;
  }
  else
   current_main_state = STATE_P0;
  //
  Serial.print
               ("setup: restored current main state=");
  Serial.println (current main state);
  // How long takes each step (255 in total) to switch from fully on
  // (duty level = 255) to fully off (duty level = 0) or vice versa.
  step_time = (countdown * 1000 / DUTY_MAX);
  Serial.print ("setup: step time=");
  Serial.println (step time);
}
//
void loop ()
{
 //
  // Small delay for debugging in serial monitor.
  // Comment this out before running in production.
 // delay (100);
  //
  // The date and time on the first row.
  //
  lcd.setCursor (0, 0);
  Time t = rtc.time();
  char str[17];
  snprintf (str, sizeof(str), "%04d%02d%02d %02d%02d%02d",
            t.yr, t.mon, t.date, t.hr, t.min, t.sec);
  lcd.print (str);
  //
  Serial.print ("loop: date and time=");
```

```
Serial.println (str);
//
// The current main state (program) on the second row.
lcd.setCursor (7, 1);
lcd.print ("P");
lcd.print (current main state);
// The current sub-state (if applicable) just after that.
if (current main state == STATE P1)
lcd.print (current p1 state);
else if (current main state == STATE P2 || current main state == STATE P3)
 lcd.print (current p2 state);
else
 lcd.print (" ");
}
//
// The duty level expressed as a percentage on the second row.
// Note that the map function is used to inverse the duty level
// values because the PWM signal amplifier does an inversion.
int p_num = map (duty_level, 0, 255, 100, 0);
char p str[6];
snprintf (p_str, sizeof(p_str), "%3d%%", p_num);
lcd.setCursor (12, 1);
lcd.print (p str);
//
// Set the cursor for the button text.
lcd.setCursor (0, 1);
byte button = ReadLcdButtonTimed ();
switch (button)
  case BTN NONE:
     lcd.print ("NONE ");
    break;
   }
  case BTN SELECT:
   {
     lcd.print ("SELECT");
     set state select ();
    break;
   }
  case BTN LEFT:
     lcd.print ("LEFT ");
     break;
    }
```

```
case BTN DOWN:
     {
       lcd.print ("DOWN ");
       set state down ();
       break;
    case BTN UP:
     {
       lcd.print ("UP
                         ");
       set state up ();
      break;
    case BTN RIGHT:
     {
       lcd.print ("RIGHT ");
       break;
  }
  //
 run_main ();
}
//
// Switch to a next main state (program) when the SELECT button is pressed.
//
void set_state_select ()
  switch (current main state)
   case STATE P0:
     current_main_state = STATE_P1;
     break;
    case STATE P1:
     current main state = STATE P2;
     break;
    case STATE P2:
     current main state = STATE P3;
     break;
    case STATE_P3:
     current main state = STATE PO;
     break;
  }
  //
  // Save current main state for Setup ().
 rtc.writeRam (0, current main state);
 // Indicate that an initial substate for P2 P3 should be done.
 dirty_p2_state = true;
}
// Switch to a higher main state (program) when the UP button is pressed.
//
void set state up ()
```

```
switch (current main state)
   case STATE P0:
     break;
    case STATE P1:
     current main state = STATE PO;
   case STATE P2:
      current main state = STATE P1;
     break;
    case STATE P3:
     current main state = STATE P2;
     break;
  }
  //
  // Save current main state for Setup ().
 rtc.writeRam (0, current main state);
 // Indicate that an initial substate for P2 P3 should be done.
 dirty p2 state = true;
}
//
// Switch to a lower main state (program) when the DOWN button is pressed.
//
void set state down ()
  switch (current_main_state)
   case STATE P0:
     current main state = STATE P1;
     break;
    case STATE P1:
     current main state = STATE P2;
     break;
    case STATE P2:
     current_main_state = STATE_P3;
     break;
   case STATE P3:
     break;
  }
  //
  // Save current main state for Setup ().
  rtc.writeRam (0, current main state);
  // Indicate that an initial substate for P2 P3 should be done.
  dirty p2 state = true;
```

```
}
//
// Run one of the main programs (state).
void run main ()
{
  //
 // First the value of current pl state is set to Pl WAITING because the
 // run_P1 () function has no way to find out when to do so.
  if (current main state != STATE P1)
    current p1 state = P1 WAITING;
  }
  //
  switch (current main state)
    case STATE P0:
    run P0 ();
     break;
    case STATE P1:
     run P1 ();
     break;
    case STATE P2:
      run P2 (SUNRISE2 HOUR, SUNSET2 HOUR);
     break;
    case STATE P3:
      run P2 (SUNRISE3 HOUR, SUNSET3 HOUR);
     break;
  }
}
//
// Program 0. Switch off immediate.
void run PO ()
 Serial.println ("run PO");
 //
 rel.On ();
 duty_level = DUTY_MAX;
 analogWrite (PIN_PWM, duty_level);
}
//
// Program 1. Switch on but with a small delay.
//
void run P1 ()
  Serial.println ("run P1");
  static unsigned long entry time = 0;
 boolean rb = false;
  //
  switch (current p1 state)
```

```
case P1 WAITING:
     if (entry_time == 0)
        Serial.println ("run P1: switching off....");
        rel.On ();
        duty level = DUTY MAX;
        analogWrite (PIN_PWM, duty_level);
        entry_time = millis ();
        //
        Serial.print
                     ("run P1: entry time=");
       Serial.println (entry_time);
      rb = HasTimedWaitPassed (entry time, DELAY P1);
      if (rb == true)
       current p1 state = P1 ON;
       entry_time = 0;
                                          // reset this for the next time
        //
        Serial.println ("run P1: switching to P1 ON state");
     break;
    case P1 ON:
     entry time = 0;
                                          // reset this for the next time
     rel.Off ();
     duty level = DUTY MIN;
     analogWrite (PIN PWM, duty level);
     break;
  }
}
//
// Program 2. Switch on the LEDS for a number of hours per day depending on
// the parameters passed as SUNRISE and SUNSET times. This routine is used
// for both P2 and P3 but with different parameter values.
void run P2 (byte this sunrise, byte this sunset)
  Serial.print ("run P2: this sunrise=");
  Serial.print
                 (this sunrise);
  Serial.print (", this sunset=");
  Serial.println (this_sunset);
  //
 boolean rb;
  Time this time = rtc.time();
               ("run P2: millis=");
  Serial.print
  Serial.println (millis ());
  // Are we in the first (half) second that this program is runing?
  // Or, was the main program state changed from 2 to 3 or vice versa?
  // If so, proceed with adjusting the initial current p2 state.
  // Adjusting the initial state is important for the very first time this
  // program runs and, more important, in the case of a power outage.
```

```
//
if (dirty p2 state == true)
{
 dirty p2 state = false;
                               // assume this, unless proven otherwise
 current p2 state = P2 OFF;
 if (this time.hr == this sunrise) // inside the sunrise hour?
   if (this time.min < (countdown / 60))// inside the countdown?
     current p2 state = P2 SUNRISE; // a new awakening
   else
                                        // sunrise already done
     current p2 state = P2 ON;
 else if (this time.hr > this sunrise) // already between sunrise and midnight?
   current_p2_state = P2_ON;
 else if (this time.hr < this sunset) // between midnight and sunset?
   current p2 state = P2 ON;
 //
 Serial.print ("run P2: calculated initial state=");
 Serial.println (current p2 state);
}
//
switch (current p2 state)
 case P2 OFF:
   rel.On ();
   duty level = DUTY MAX;
   analogWrite (PIN PWM, duty level);
   //
   if (this time.hr == this sunrise)
    current_p2_state = P2_SUNRISE;
     Serial.println ("run P2: switching to P2 SUNRISE state");
   }
   break;
 case P2 SUNRISE:
   rel.Off ();
   rb = SunRise ();
   if (rb == true)
     current p2 state = P2 ON;
     Serial.println ("run P2: switching to P2 ON state");
   }
   break;
```

```
case P2 ON:
      rel.Off ();
      duty level = DUTY MIN;
      analogWrite (PIN_PWM, duty_level);
      //
      if (this time.hr == this sunset)
       current p2 state = P2 SUNSET;
       Serial.println ("run P2: switching to P2 SUNSET state");
      }
      break;
    case P2_SUNSET:
      rb = SunSet ();
      if (rb == true)
        current p2 state = P2 OFF;
       Serial.println ("run_P2: switching to P2_OFF state");
     break;
}
//
// Initiate or continue a SunRise event.
// Returns false when not yet done, true when done.
boolean SunRise ()
  Serial.println ("SunRise");
  static unsigned long entry time = 0;
 boolean rb = false;
  Serial.print ("SunRise: step time=");
  Serial.print (step time);
  Serial.print (". entry time=");
  Serial.println (entry_time);
  if (entry_time == 0)
   entry_time = millis ();
  //
  rb = HasTimedWaitPassed (entry_time, step_time);
  if (rb == true)
    if (duty level > DUTY MIN)
      duty_level--;
      analogWrite (PIN_PWM, duty_level);
      Serial.print ("SunRise: duty level=");
      Serial.println (duty level);
      //
      entry time = millis ();
```

```
//
      Serial.print ("SunRise: new entry time=");
      Serial.println (entry_time);
     rb = false;
                                          // SunRise still in progress
    else
     rb = true;
                                          // SunRise has just completed
   }
  }
  //
  Serial.print ("SunRise: return=");
  Serial.println (rb);
  Serial.println ("----");
 //
  return rb;
}
//
// Initiate or continue a SunSet event.
// Returns false when not yet done, true when done.
//
boolean SunSet ()
  Serial.println ("SunSet");
  static unsigned long entry time = 0;
 boolean rb = false;
  Serial.print ("SunSet: step_time=");
  Serial.print (step time);
  Serial.print (". entry time=");
  Serial.println (entry_time);
  if (entry_time == 0)
   entry time = millis ();
  }
  rb = HasTimedWaitPassed (entry time, step time);
  if (rb == true)
    if (duty level < DUTY MAX)
     duty level++;
      analogWrite (PIN_PWM, duty_level);
      Serial.print ("SunSet: duty level=");
      Serial.println (duty level);
     //
      entry_time = millis ();
      Serial.print ("SunSet: new entry time=");
      Serial.println (entry time);
     //
                                          // SunSet still in progress
      rb = false;
```

```
else
     rb = true;
                                          // SunSet has just completed
  }
  //
  Serial.print ("SunSet: return=");
  Serial.println (rb);
  Serial.println ("----");
 return rb;
}
//
// Function to determine if a certain amount of milliseconds have passed since
// a specified entry time. In case of an overflow of the result of the millis ()
// function (approximate each fifty days) this function will not fail but will
// return true so the program using this method will not stall.
//
boolean HasTimedWaitPassed (unsigned long entry time, unsigned int wait)
 boolean rb = false;
                                          // assume not yet passed
  unsigned long this time = millis ();
  Serial.print ("HasTimedWaitPassed: this time=");
  Serial.println (this_time);
  if (this time >= entry time)
  if (this time > (entry time + wait))
    rb = true;
                                          // wait has passed
    }
  }
  else
   Serial.println ("HasTimedWaitPassed: overflow detected.");
   rb = true;
                                          // wait has not passed but...
  }
  Serial.print ("HasTimedWaitPassed: rb=");
  Serial.println (rb);
  //
  return rb;
```