

IPv4-Schema
Fgz. Nr: 4734 - 004



Fahrzeugnummer: 4734-004				Fzg ID: 4				Wagen: A - 100					
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address			IPID	PoE	[W]	Beschriftung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	2	126	126				
	e1-0	Überw. Kamera A7	5	Access	172	18	130	10	10	y	5.0		
	e1-1	Überw. Kamera A2	5	Access	172	18	130	11	11	y	5.0		
	e1-2	Überw. Kamera A1	5	Access	172	18	130	12	12	y	5.0		
	e1-3	Überw. Kamera A5	5	Access	172	18	130	13	13	y	5.0		
	e1-4	Überw. Kamera A9	5	Access	172	18	130	14	14	y	5.0		
	e1-5	AFZ A1	8	Access	172	20	2	5	5	y	10.0		
	e1-6	AFZ A2	8	Access	172	20	2	6	6	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle A1	9	Access	172	20	130	5	5	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A5	90	Access	-	-	-	-	-				
	e1-13	Future use box A6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige A1	3	Access	172	17	130	25	25				
	e1-15	Seitenanzeige A3	3	Access	172	17	130	26	26				
	e2-0	Bildschirm A7	3	Access	172	17	130	50	50				
	e2-1	Bildschirm A5	3	Access	172	17	130	51	51				
	e2-2	Bildschirm A1	3	Access	172	17	130	52	52				
	e2-3	Bildschirm A3	3	Access	172	17	130	53	53				
e2-4	ADU A	9	Access	172	20	130	3	3					
e2-5	Audio Amp. A1	9	Access	172	20	130	21	21					
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera A8	5	Access	172	18	130	15	15	y	5.0		
	e1-1	Überw. Kamera A4	5	Access	172	18	130	16	16	y	5.0		
	e1-2	Überw. Kamera A3	5	Access	172	18	130	17	17	y	5.0		
	e1-3	Überw. Kamera A6	5	Access	172	18	130	18	18	y	5.0		
	e1-4	Überw. Kamera A10	5	Access	172	18	130	19	19	y	5.0		
	e1-5	AFZ A3	8	Access	172	20	2	7	7	y	10.0		
	e1-6	AFZ A4	8	Access	172	20	2	8	8	y	10.0		
	e1-7	NVR A	5	Access	172	18	130	5	5				
	e1-8	Sprechstelle A2	9	Access	172	20	130	6	6	y	7.5		
	e1-9	Sprechstelle AIR	9	Access	172	20	130	5	5	y	7.5		Redundanz A1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A2	90	Access	-	-	-	-	-				
	e1-13	Future use box A4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige A2	3	Access	172	17	130	27	27				
	e1-15	Seitenanzeige A4	3	Access	172	17	130	28	28				
	e2-0	Bildschirm A8	3	Access	172	17	130	54	54				
	e2-1	Bildschirm A6	3	Access	172	17	130	55	55				
	e2-2	Bildschirm A2	3	Access	172	17	130	56	56				
	e2-3	Bildschirm A4	3	Access	172	17	130	57	57				
	e2-4				-	-	-	-	-				
	e2-5	Audio Amp. A2	9	Access	172	20	130	22	22				
	A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
		e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
e0-2		Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
e0-3					-	-	-	-	-				
e0-4		Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
e0-5		reserved			-	-	-	-	-				
e1-0		Rücksehkamera A1	5	Access	172	18	130	80	80	y	5.0		
e1-1		Rücksehkamera A2	5	Access	172	18	130	81	81	y	5.0		
e1-2		Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
e1-3					-	-	-	-	-				
e1-4		Firewall	2	Trunk	172	17	2	1	1			Kein DHCP Statische Konfiguration STADLER	
			3		172	17	130	1					
			5		172	18	130	1					
			6		172	19	2	1					
			7		172	19	130	1					
			8		172	20	2	1					
			9		172	20	130	1					
			12		172	22	2	1					
e1-5					-	-	-	-	-				
e1-6					-	-	-	-	-				
e1-7					-	-	-	-	-				
e1-8					-	-	-	-	-				
e1-9		Sprechstelle A2R	9	Access	172	20	130	6	6	y	7.5		Redundanz A2
e1-10					-	-	-	-	-				
e1-11					-	-	-	-	-				
e1-12		Future use box A1	90	Access	-	-	-	-	-				
e1-13		Future use box A3	90	Access	-	-	-	-	-				
e1-14		Frontanzeige A	3	Access	172	17	130	23	23				
e1-15					-	-	-	-	-				
e2-0					-	-	-	-	-				
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4	ADU AR	9	Access	172	20	130	3	3					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					

G1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	130	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	2	122	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	130	30	30	y	5.0		
	e1-1	Überw. Kamera D2	5	Access	172	18	130	31	31	y	5.0		
	e1-2	Überw. Kamera D1	5	Access	172	18	130	32	32	y	5.0		
	e1-3	Überw. Kamera D5	5	Access	172	18	130	33	33	y	5.0		
	e1-4	Überw. Kamera D9	5	Access	172	18	130	34	34	y	5.0		
	e1-5	AFZ D1	8	Access	172	20	2	14	14	y	10.0		
	e1-6	AFZ D2	8	Access	172	20	2	15	15	y	10.0		
	e1-7	AFZ D5	8	Access	172	20	2	16	16	y	10.0		
	e1-8	Sprechstelle D1	9	Access	172	20	130	10	10	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
	e1-13	Future use box D6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D1	3	Access	172	17	130	33	33				
	e1-15	Seitenanzeige D3	3	Access	172	17	130	34	34				
	e2-0	Bildschirm D7	3	Access	172	17	130	68	68				
	e2-1	Bildschirm D5	3	Access	172	17	130	69	69				
e2-2	Bildschirm D1	3	Access	172	17	130	70	70					
e2-3	Bildschirm D3	3	Access	172	17	130	71	71					
e2-4	Bildschirm D	3	Access	172	17	130	72	72					
e2-5	Audio Amp. D1	9	Access	172	20	130	25	25					
G2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	130	35	35	y	5.0		
	e1-1	Überw. Kamera D4	5	Access	172	18	130	36	36	y	5.0		
	e1-2	Überw. Kamera D3	5	Access	172	18	130	37	37	y	5.0		
	e1-3	Überw. Kamera D6	5	Access	172	18	130	38	38	y	5.0		
	e1-4	Überw. Kamera D10	5	Access	172	18	130	39	39	y	5.0		
	e1-5	AFZ D3	8	Access	172	20	2	17	17	y	10.0		
	e1-6	AFZ D4	8	Access	172	20	2	18	18	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	130	11	11	y	7.5		
	e1-9	Sprechstelle D1R	9	Access	172	20	130	10	10	y	7.5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D2	3	Access	172	17	130	35	35				
	e1-15	Seitenanzeige D4	3	Access	172	17	130	36	36				
	e2-0	Bildschirm D8	3	Access	172	17	130	73	73				
	e2-1	Bildschirm D6	3	Access	172	17	130	74	74				
	e2-2	Bildschirm D2	3	Access	172	17	130	75	75				
e2-3	Bildschirm D4	3	Access	172	17	130	76	76					
e2-4	Bildschirm D11	3	Access	172	17	130	77	77					
e2-5	Audio Amp. D2	9	Access	172	20	130	26	26					
G3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	130	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	130	84	84	y	5.0		
	e1-1	Rücksehkamera D2	5	Access	172	18	130	85	85	y	5.0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	130	11	11	y	7.5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
	e1-13	Future use box D3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

IPv4-Schema

Fgz. Nr: 4734 - 004

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-2				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-3				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-5	Service FIS / CCTV	2	Access	172	17	2	123	123											
	e1-0	Überw. Kamera E7	5	Access	172	18	130	40	40	y										
	e1-1	Überw. Kamera E2	5	Access	172	18	130	41	41	y										
	e1-2	Überw. Kamera E1	5	Access	172	18	130	42	42	y										
	e1-3	Überw. Kamera E5	5	Access	172	18	130	43	43	y										
	e1-4	Überw. Kamera E9	5	Access	172	18	130	44	44	y										
	e1-5	AFZ E1	8	Access	172	20	2	19	19	y										
	e1-6	AFZ E2	8	Access	172	20	2	20	20	y										
	e1-7	AFZ E5	8	Access	172	20	2	21	21	y										
	e1-8	Sprechstelle E1	9	Access	172	20	130	12	12	y										
	e1-9				-	-	-	-	-	-										
	e1-10	Sprechstelle PRM E1	9	Access	172	20	130	13	13	y										
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	130	16	16	y										Redundanz WC
	e1-12	Future use box E5	90	Access	-	-	-	-	-	-										
	e1-13	Future use box E7	90	Access	-	-	-	-	-	-										
	e1-14	Seitenanzeige E1	3	Access	172	17	130	37	37											
E2	e1-15	Seitenanzeige E3	3	Access	172	17	130	38	38											
	e2-0	Bildschirm E7	3	Access	172	17	130	78	78											
	e2-1	Bildschirm E5	3	Access	172	17	130	79	79											
	e2-2	Bildschirm E1	3	Access	172	17	130	80	80											
	e2-3	Bildschirm E3	3	Access	172	17	130	81	81											
	e2-4	Bildschirm E	3	Access	172	17	130	82	82											
	e2-5	Audio Amp. E1	9	Access	172	20	130	27	27											
	e0-0	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-2				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-3				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-4	Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-5	reserved			-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-0	Überw. Kamera E8	5	Access	172	18	130	45	45	y										
	e1-1	Überw. Kamera E4	5	Access	172	18	130	46	46	y										
	e1-2	Überw. Kamera E3	5	Access	172	18	130	47	47	y										
	e1-3	Überw. Kamera E6	5	Access	172	18	130	48	48	y										
	e1-4				-	-	-	-	-	-										
	e1-5	AFZ E3	8	Access	172	20	2	22	22	y										
	e1-6	AFZ E4	8	Access	172	20	2	23	23	y										
	e1-7	AFZ E6	8	Access	172	20	2	24	24	y										
	e1-8	Sprechstelle E2	9	Access	172	20	130	14	14	y										
	e1-9	Sprechstelle E1R	9	Access	172	20	130	12	12	y										Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	130	15	15	y										
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	130	13	13	y										Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-	-										
	e1-13	Future use box E4	90	Access	-	-	-	-	-	-										
	e1-14	Seitenanzeige E2	3	Access	172	17	130	39	39											
	e1-15	Seitenanzeige E4	3	Access	172	17	130	40	40											
E3	e2-0	Bildschirm E8	3	Access	172	17	130	83	83											
	e2-1	Bildschirm E6	3	Access	172	17	130	84	84											
	e2-2	Bildschirm E2	3	Access	172	17	130	85	85											
	e2-3	Bildschirm E4	3	Access	172	17	130	86	86											
	e2-4	Bildschirm E11	3	Access	172	17	130	87	87											
	e2-5	Audio Amp. E2	9	Access	172	20	130	28	28											
	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-2				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-3				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e0-5	reserved			-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-0	Rücksehkamera E1	5	Access	172	18	130	86	86	y										
	e1-1	Rücksehkamera E2	5	Access	172	18	130	87	87	y										
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-3				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-4				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-5				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-6				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-7				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-8				-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	e1-9	Sprechstelle E2R	9	Access	172	20	130	14	14	y										Redundanz E2
	e1-10	Sprechstelle PRM WC	9	Access	172	20	130	16	16	y										
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	130	15	15	y										Redundanz E2
	e1-12	Future use box E1	90	Access	-	-	-	-	-	-										
	e1-13	Future use box E3	90	Access	-	-	-	-	-	-										
	e1-14				-	-	-	-	-	-										
	e1-15				-	-	-	-	-	-										
	e2-0	Energiezähler E	12	Access	172	22	2	3	3											
	e2-1				-	-	-	-	-	-										
	e2-2				-	-	-	-	-	-										
	e2-3				-	-	-	-	-	-										
	e2-4				-	-	-	-	-	-										
	e2-5				-	-	-	-	-	-										

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	2	125	125				
	e1-0	Überw. Kamera B7	5	Access	172	18	130	59	59	y	5.0		
	e1-1	Überw. Kamera B2	5	Access	172	18	130	60	60	y	5.0		
	e1-2	Überw. Kamera B1	5	Access	172	18	130	61	61	y	5.0		
	e1-3	Überw. Kamera B5	5	Access	172	18	130	62	62	y	5.0		
	e1-4	Überw. Kamera B9	5	Access	172	18	130	63	63	y	5.0		
	e1-5	AFZ B1	8	Access	172	20	2	30	30	y	10.0		
	e1-6	AFZ B2	8	Access	172	20	2	31	31	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle B1	9	Access	172	20	130	19	19	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11	ZFR R	2	Access	172	17	2	2	2				
	e1-12	Future use box B5	90	Access	-	-	-	-	-				
	e1-13	Future use box B6	90	Access	-	-	-	-	-				
B2	e1-14	Seitenanzeige B1	3	Access	172	17	130	45	45				
	e1-15	Seitenanzeige B3	3	Access	172	17	130	46	46				
	e2-0	Bildschirm B7	3	Access	172	17	130	98	98				
	e2-1	Bildschirm B5	3	Access	172	17	130	99	99				
	e2-2	Bildschirm B1	3	Access	172	17	130	100	100				
	e2-3	Bildschirm B3	3	Access	172	17	130	101	101				
	e2-4	ADU B	9	Access	172	20	130	4	4				
	e2-5	Audio Amp. B1	9	Access	172	20	130	31	31				
	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera B8	5	Access	172	18	130	64	64	y	5.0		
	e1-1	Überw. Kamera B4	5	Access	172	18	130	65	65	y	5.0		
	e1-2	Überw. Kamera B3	5	Access	172	18	130	66	66	y	5.0		
	e1-3	Überw. Kamera B6	5	Access	172	18	130	67	67	y	5.0		
	e1-4	Überw. Kamera B10	5	Access	172	18	130	68	68	y	5.0		
	B3	e1-5	AFZ B3	8	Access	172	20	2	32	32	y	10.0	
e1-6		AFZ B4	8	Access	172	20	2	33	33	y	10.0		
e1-7		NVR B	5	Access	172	18	130	6	6				
e1-8		Sprechstelle B2	9	Access	172	20	130	20	20	y	7.5		
e1-9		Sprechstelle B1R	9	Access	172	20	130	19	19	y	7.5		
e1-10					-	-	-	-	-				
e1-11					-	-	-	-	-				
e1-12		Future use box B2	90	Access	-	-	-	-	-				
e1-13		Future use box B4	90	Access	-	-	-	-	-				
e1-14		Seitenanzeige B2	3	Access	172	17	130	47	47				
e1-15		Seitenanzeige B4	3	Access	172	17	130	48	48				
e2-0		Bildschirm B8	3	Access	172	17	130	102	102				
e2-1		Bildschirm B6	3	Access	172	17	130	103	103				
e2-2		Bildschirm B2	3	Access	172	17	130	104	104				
e2-3		Bildschirm B4	3	Access	172	17	130	105	105				
e2-4					-	-	-	-	-				
e2-5		Audio Amp. B2	9	Access	172	20	130	32	32				
e0-0		FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
e0-1		FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
e0-2		Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
e0-3				-	-	-	-	-					
e0-4	Access point B3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
e0-5	reserved			-	-	-	-	-					
e1-0	Rücksehkamera B1	5	Access	172	18	130	90	90	y	5.0			
e1-1	Rücksehkamera B2	5	Access	172	18	130	91	91	y	5.0			
e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
e1-3				-	-	-	-	-					
e1-4				-	-	-	-	-					
e1-5				-	-	-	-	-					
e1-6				-	-	-	-	-					
e1-7				-	-	-	-	-					
e1-8				-	-	-	-	-					
e1-9	Sprechstelle B2R	9	Access	172	20	130	20	20	y	7.5		Redundanz B2	
e1-10				-	-	-	-	-					
e1-11	ZFR	2	Access	172	17	2	2	2					
e1-12	Future use box B1	90	Access	-	-	-	-	-					
e1-13	Future use box B3	90	Access	-	-	-	-	-					
e1-14	Frontanzeige B	3	Access	172	17	130	24	24					
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4	ADU BR	9	Access	172	20	130	4	4					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					