

IPv4-Schema
Fgz. Nr: 4734 - 004



Fahrzeugnummer: 4734-004				Fzg. ID: 4				Wagen: A - 100				
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address		IPID	PoE	[W]	Beschriftung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-				
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-				
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-				
	e0-3				-	-	-	-				
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	3, 5	Trunk	-	-	-	-	120			
	e1-0	Überw. Kamera A7	5	Access	172	18	130	10	10	y	5.0	
	e1-1	Überw. Kamera A2	5	Access	172	18	130	11	11	y	5.0	
	e1-2	Überw. Kamera A1	5	Access	172	18	130	12	12	y	5.0	
	e1-3	Überw. Kamera A5	5	Access	172	18	130	13	13	y	5.0	
	e1-4	Überw. Kamera A9	5	Access	172	18	130	14	14	y	5.0	
	e1-5	AFZ A1	8	Access	172	20	2	5	5	y	10.0	
	e1-6	AFZ A2	8	Access	172	20	2	6	6	y	10.0	
	e1-7				-	-	-	-	-			
	e1-8	Sprechstelle A1	9	Access	172	20	130	5	5	y	7.5	
	e1-9				-	-	-	-	-			
	e1-10				-	-	-	-	-			
	e1-11				-	-	-	-	-			
	e1-12	Future use box A5	90	Access	-	-	-	-	-			
	e1-13	Future use box A6	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige A1	3	Access	172	17	130	25	25			
	e1-15	Seitenanzeige A3	3	Access	172	17	130	26	26			
	e2-0	Bildschirm A7	3	Access	172	17	130	50	50			
	e2-1	Bildschirm A5	3	Access	172	17	130	51	51			
	e2-2	Bildschirm A1	3	Access	172	17	130	52	52			
	e2-3	Bildschirm A3	3	Access	172	17	130	53	53			
e2-4	ADU A	3	Access	172	17	130	5	5				
e2-5	Audio Amp. A1	3	Access	172	17	130	11	11				
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-				
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-				
	e0-2				-	-	-	-				
	e0-3				-	-	-	-				
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-				
	e1-0	Überw. Kamera A8	5	Access	172	18	130	15	15	y	5.0	
	e1-1	Überw. Kamera A4	5	Access	172	18	130	16	16	y	5.0	
	e1-2	Überw. Kamera A3	5	Access	172	18	130	17	17	y	5.0	
	e1-3	Überw. Kamera A6	5	Access	172	18	130	18	18	y	5.0	
	e1-4	Überw. Kamera A10	5	Access	172	18	130	19	19	y	5.0	
	e1-5	AFZ A3	8	Access	172	20	2	7	7	y	10.0	
	e1-6	AFZ A4	8	Access	172	20	2	8	8	y	10.0	
	e1-7	NVR A	5	Access	172	18	130	5	5			
	e1-8	Sprechstelle A2	9	Access	172	20	130	6	6	y	7.5	
	e1-9	Sprechstelle A1R	9	Access	172	20	130	5	5	y	7.5	Redundanz A1
	e1-10				-	-	-	-	-			
	e1-11				-	-	-	-	-			
	e1-12	Future use box A2	90	Access	-	-	-	-	-			
	e1-13	Future use box A4	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige A2	3	Access	172	17	130	27	27			
	e1-15	Seitenanzeige A4	3	Access	172	17	130	28	28			
	e2-0	Bildschirm A8	3	Access	172	17	130	54	54			
	e2-1	Bildschirm A6	3	Access	172	17	130	55	55			
	e2-2	Bildschirm A2	3	Access	172	17	130	56	56			
	e2-3	Bildschirm A4	3	Access	172	17	130	57	57			
e2-4				-	-	-	-	-				
e2-5	Audio Amp. A2	3	Access	172	17	130	12	12				
A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-				
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-				
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-				
	e0-3				-	-	-	-				
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-				
	e1-0	Rücksehkamera A1	5	Access	172	18	130	80	80	y	5.0	
	e1-1	Rücksehkamera A2	5	Access	172	18	130	81	81	y	5.0	
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0		
	e1-3				-	-	-	-				
	e1-4	Firewall	2	Trunk	172	17	2	1	1			
	5		172		18	130	1					
	7		172		19	130	1					
	e1-5				-	-	-	-				
	e1-6				-	-	-	-				
	e1-7				-	-	-	-				
	e1-8				-	-	-	-				
	e1-9	Sprechstelle A2R	9	Access	172	20	130	6	6	y	7.5	Redundanz A2
	e1-10				-	-	-	-				
	e1-11				-	-	-	-				
	e1-12	Future use box A1	90	Access	-	-	-	-				
	e1-13	Future use box A3	90	Access	-	-	-	-				
	e1-14	Frontanzeige A	3	Access	172	17	130	23	23			
	e1-15				-	-	-	-				
	e2-0				-	-	-	-				
	e2-1				-	-	-	-				
e2-2				-	-	-	-					
e2-3				-	-	-	-					
e2-4	ADU A	3	Access	172	17	130	5	5				
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-					

D1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	130	3	3			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	3, 5	Trunk	-	-	-	-	120				
	e1-0	Überw. Kamera D7	5	Access	172	18	130	30	30	y	5.0		
	e1-1	Überw. Kamera D2	5	Access	172	18	130	31	31	y	5.0		
	e1-2	Überw. Kamera D1	5	Access	172	18	130	32	32	y	5.0		
	e1-3	Überw. Kamera D5	5	Access	172	18	130	33	33	y	5.0		
	e1-4	Überw. Kamera D9	5	Access	172	18	130	34	34	y	5.0		
	e1-5	AFZ D1	8	Access	172	20	2	14	14	y	10.0		
	e1-6	AFZ D2	8	Access	172	20	2	15	15	y	10.0		
	e1-7	AFZ D5	8	Access	172	20	2	16	16	y	10.0		
	e1-8	Sprechstelle D1	9	Access	172	20	130	10	10	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
e1-13	Future use box D6	90	Access	-	-	-	-	-					
e1-14	Seitenanzeige D1	3	Access	172	17	130	33	33					
e1-15	Seitenanzeige D3	3	Access	172	17	130	34	34					
e2-0	Bildschirm D7	3	Access	172	17	130	68	68					
e2-1	Bildschirm D5	3	Access	172	17	130	69	69					
e2-2	Bildschirm D1	3	Access	172	17	130	70	70					
e2-3	Bildschirm D3	3	Access	172	17	130	71	71					
e2-4	Bildschirm D	3	Access	172	17	130	72	72					
e2-5	Audio Amp. D1	3	Access	172	17	130	15	15					
D2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	130	35	35	y	5.0		
	e1-1	Überw. Kamera D4	5	Access	172	18	130	36	36	y	5.0		
	e1-2	Überw. Kamera D3	5	Access	172	18	130	37	37	y	5.0		
	e1-3	Überw. Kamera D6	5	Access	172	18	130	38	38	y	5.0		
	e1-4	Überw. Kamera D10	5	Access	172	18	130	39	39	y	5.0		
	e1-5	AFZ D3	8	Access	172	20	2	17	17	y	10.0		
	e1-6	AFZ D4	8	Access	172	20	2	18	18	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	130	11	11	y	7.5		
	e1-9	Sprechstelle D1R	9	Access	172	20	130	10	10	y	7.5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
e1-14	Seitenanzeige D2	3	Access	172	17	130	35	35					
e1-15	Seitenanzeige D4	3	Access	172	17	130	36	36					
e2-0	Bildschirm D8	3	Access	172	17	130	73	73					
e2-1	Bildschirm D6	3	Access	172	17	130	74	74					
e2-2	Bildschirm D2	3	Access	172	17	130	75	75					
e2-3	Bildschirm D4	3	Access	172	17	130	76	76					
e2-4	Bildschirm D11	3	Access	172	17	130	77	77					
e2-5	Audio Amp. D2	3	Access	172	17	130	16	16					
D3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	130	3	3			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	130	84	84	y	5.0		
	e1-1	Rücksehkamera D2	5	Access	172	18	130	85	85	y	5.0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	130	11	11	y	7.5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
e1-13	Future use box D3	90	Access	-	-	-	-	-					
e1-14				-	-	-	-	-					
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	3, 5	Trunk	-	-	-	-	120				
	e1-0	Überw. Kamera E7	5	Access	172	18	130	40	40	y	5.0		
	e1-1	Überw. Kamera E2	5	Access	172	18	130	41	41	y	5.0		
	e1-2	Überw. Kamera E1	5	Access	172	18	130	42	42	y	5.0		
	e1-3	Überw. Kamera E5	5	Access	172	18	130	43	43	y	5.0		
	e1-4	Überw. Kamera E9	5	Access	172	18	130	44	44	y	5.0		
	e1-5	AFZ E1	8	Access	172	20	2	19	19	y	10.0		
	e1-6	AFZ E2	8	Access	172	20	2	20	20	y	10.0		
	e1-7	AFZ E5	8	Access	172	20	2	21	21	y	10.0		
	e1-8	Sprechstelle E1	9	Access	172	20	130	12	12	y	7.5		
	e1-9					-	-	-	-				
	e1-10	Sprechstelle PRM E1	9	Access	172	20	130	13	13	y	7.5		
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	130	16	16	y	7.5		Redundanz WC
	e1-12	Future use box E5	90	Access	-	-	-	-	-				
	e1-13	Future use box E7	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E1	3	Access	172	17	130	37	37				
	e1-15	Seitenanzeige E3	3	Access	172	17	130	38	38				
	e2-0	Bildschirm E7	3	Access	172	17	130	78	78				
e2-1	Bildschirm E5	3	Access	172	17	130	79	79					
e2-2	Bildschirm E1	3	Access	172	17	130	80	80					
e2-3	Bildschirm E3	3	Access	172	17	130	81	81					
e2-4	Bildschirm E	3	Access	172	17	130	82	82					
e2-5	Audio Amp. E1	3	Access	172	17	130	17	17					
E2	e0-0	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera E8	5	Access	172	18	130	45	45	y	5.0		
	e1-1	Überw. Kamera E4	5	Access	172	18	130	46	46	y	5.0		
	e1-2	Überw. Kamera E3	5	Access	172	18	130	47	47	y	5.0		
	e1-3	Überw. Kamera E6	5	Access	172	18	130	48	48	y	5.0		
	e1-4				-	-	-	-	-				
	e1-5	AFZ E3	8	Access	172	20	2	22	22	y	10.0		
	e1-6	AFZ E4	8	Access	172	20	2	23	23	y	10.0		
	e1-7	AFZ E6	8	Access	172	20	2	24	24	y	10.0		
	e1-8	Sprechstelle E2	9	Access	172	20	130	14	14	y	7.5		
	e1-9	Sprechstelle E1R	9	Access	172	20	130	12	12	y	7.5		Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	130	15	15	y	7.5		
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	130	13	13	y	7.5		Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-				
	e1-13	Future use box E4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E2	3	Access	172	17	130	39	39				
	e1-15	Seitenanzeige E4	3	Access	172	17	130	40	40				
	e2-0	Bildschirm E8	3	Access	172	17	130	83	83				
e2-1	Bildschirm E6	3	Access	172	17	130	84	84					
e2-2	Bildschirm E2	3	Access	172	17	130	85	85					
e2-3	Bildschirm E4	3	Access	172	17	130	86	86					
e2-4	Bildschirm E11	3	Access	172	17	130	87	87					
e2-5	Audio Amp. E2	3	Access	172	17	130	18	18					
E3	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera E1	5	Access	172	18	130	86	86	y	5.0		
	e1-1	Rücksehkamera E2	5	Access	172	18	130	87	87	y	5.0		
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle E2R	9	Access	172	20	130	14	14	y	7.5		Redundanz E2
	e1-10	Sprechstelle PRM WC	9	Access	172	20	130	16	16	y	7.5		
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	130	15	15	y	7.5		Redundanz E2
	e1-12	Future use box E1	90	Access	-	-	-	-	-				
	e1-13	Future use box E3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0	Energiezähler E	12	Access	172	22	2	2	2				
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

[illegible]