

Fahrzeugnummer: 4734-119				Fzg. ID: 19				Wagen: A - 100					
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address			IPID	PoE	[W]	Beschriftung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	9	248	120				
	e1-0	Überw. Kamera A7	5	Access	172	18	137	138	10	y	5,0		
	e1-1	Überw. Kamera A2	5	Access	172	18	137	139	11	y	5,0		
	e1-2	Überw. Kamera A1	5	Access	172	18	137	140	12	y	5,0		
	e1-3	Überw. Kamera A5	5	Access	172	18	137	141	13	y	5,0		
	e1-4	Überw. Kamera A9	5	Access	172	18	137	142	14	y	5,0		
	e1-5	AFZ A1	8	Access	172	20	9	133	5	y	10,0		
	e1-6	AFZ A2	8	Access	172	20	9	134	6	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle A1	9	Access	172	20	137	133	5	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A5	90	Access	-	-	-	-	-				
	e1-13	Future use box A6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige A1	3	Access	172	17	137	153	25				
	e1-15	Seitenanzeige A3	3	Access	172	17	137	154	26				
	e2-0	Bildschirm A7	3	Access	172	17	137	178	50				
e2-1	Bildschirm A5	3	Access	172	17	137	179	51					
e2-2	Bildschirm A1	3	Access	172	17	137	180	52					
e2-3	Bildschirm A3	3	Access	172	17	137	181	53					
e2-4	ADU A	9	Access	172	20	137	131	3					
e2-5	Audio Amp. A1	9	Access	172	20	137	149	21					
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera A8	5	Access	172	18	137	143	15	y	5,0		
	e1-1	Überw. Kamera A4	5	Access	172	18	137	144	16	y	5,0		
	e1-2	Überw. Kamera A3	5	Access	172	18	137	145	17	y	5,0		
	e1-3	Überw. Kamera A6	5	Access	172	18	137	146	18	y	5,0		
	e1-4	Überw. Kamera A10	5	Access	172	18	137	147	19	y	5,0		
	e1-5	AFZ A3	8	Access	172	20	9	135	7	y	10,0		
	e1-6	AFZ A4	8	Access	172	20	9	136	8	y	10,0		
	e1-7	NVR A	5	Access	172	18	137	133	5				
	e1-8	Sprechstelle A2	9	Access	172	20	137	134	6	y	7,5		
	e1-9	Sprechstelle AIR	9	Access	172	20	137	133	5	y	7,5		Redundanz A1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A2	90	Access	-	-	-	-	-				
	e1-13	Future use box A4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige A2	3	Access	172	17	137	155	27				
	e1-15	Seitenanzeige A4	3	Access	172	17	137	156	28				
	e2-0	Bildschirm A8	3	Access	172	17	137	182	54				
	e2-1	Bildschirm A6	3	Access	172	17	137	183	55				
	e2-2	Bildschirm A2	3	Access	172	17	137	184	56				
	e2-3	Bildschirm A4	3	Access	172	17	137	185	57				
	e2-4				-	-	-	-	-				
e2-5	Audio Amp. A2	9	Access	172	20	137	150	22					
A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera A1	5	Access	172	18	137	208	80	y	5,0		
	e1-1	Rücksehkamera A2	5	Access	172	18	137	209	81	y	5,0		
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4	Firewall	2	Trunk	172	17	9	129	1			Kein DHCP Statische Konfiguration STADLER	
			3		172	17	137	129					
			5		172	18	137	129					
			6		172	19	9	129					
			7		172	19	137	129					
			8		172	20	9	129					
			9		172	20	137	129					
			12		172	22	9	129					
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle A2R	9	Access	172	20	137	134	6	y	7,5		Redundanz A2
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A1	90	Access	-	-	-	-	-				
	e1-13	Future use box A3	90	Access	-	-	-	-	-				
	e1-14	Frontanzeige A	3	Access	172	17	137	151	23				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4	ADU AR	9	Access	172	20	137	131	3					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					

G1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202 7	Trunk	-	-	-	-	-				
					172	19	137	130	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	9	250	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	137	158	30	y	5,0		
	e1-1	Überw. Kamera D2	5	Access	172	18	137	159	31	y	5,0		
	e1-2	Überw. Kamera D1	5	Access	172	18	137	160	32	y	5,0		
	e1-3	Überw. Kamera D5	5	Access	172	18	137	161	33	y	5,0		
	e1-4	Überw. Kamera D9	5	Access	172	18	137	162	34	y	5,0		
	e1-5	AFZ D1	8	Access	172	20	9	142	14	y	10,0		
	e1-6	AFZ D2	8	Access	172	20	9	143	15	y	10,0		
	e1-7	AFZ D5	8	Access	172	20	9	144	16	y	10,0		
	e1-8	Sprechstelle D1	9	Access	172	20	137	138	10	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
e1-13	Future use box D6	90	Access	-	-	-	-	-					
e1-14	Seitenanzeige D1	3	Access	172	17	137	161	33					
e1-15	Seitenanzeige D3	3	Access	172	17	137	162	34					
e2-0	Bildschirm D7	3	Access	172	17	137	196	68					
e2-1	Bildschirm D5	3	Access	172	17	137	197	69					
e2-2	Bildschirm D1	3	Access	172	17	137	198	70					
e2-3	Bildschirm D3	3	Access	172	17	137	199	71					
e2-4	Bildschirm D	3	Access	172	17	137	200	72					
e2-5	Audio Amp. D1	9	Access	172	20	137	153	25					
G2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	137	163	35	y	5,0		
	e1-1	Überw. Kamera D4	5	Access	172	18	137	164	36	y	5,0		
	e1-2	Überw. Kamera D3	5	Access	172	18	137	165	37	y	5,0		
	e1-3	Überw. Kamera D6	5	Access	172	18	137	166	38	y	5,0		
	e1-4	Überw. Kamera D10	5	Access	172	18	137	167	39	y	5,0		
	e1-5	AFZ D3	8	Access	172	20	9	145	17	y	10,0		
	e1-6	AFZ D4	8	Access	172	20	9	146	18	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	137	139	11	y	7,5		
	e1-9	Sprechstelle D1R	9	Access	172	20	137	138	10	y	7,5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
e1-14	Seitenanzeige D2	3	Access	172	17	137	163	35					
e1-15	Seitenanzeige D4	3	Access	172	17	137	164	36					
e2-0	Bildschirm D8	3	Access	172	17	137	201	73					
e2-1	Bildschirm D6	3	Access	172	17	137	202	74					
e2-2	Bildschirm D2	3	Access	172	17	137	203	75					
e2-3	Bildschirm D4	3	Access	172	17	137	204	76					
e2-4	Bildschirm D11	3	Access	172	17	137	205	77					
e2-5	Audio Amp. D2	9	Access	172	20	137	154	26					
G3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202 7	Trunk	-	-	-	-	-				
					172	19	137	130	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	137	212	84	y	5,0		
	e1-1	Rücksehkamera D2	5	Access	172	18	137	213	85	y	5,0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	137	139	11	y	7,5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
e1-13	Future use box D3	90	Access	-	-	-	-	-					
e1-14				-	-	-	-	-					
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	9	251	123				
	e1-0	Überw. Kamera E7	5	Access	172	18	137	168	40	y	5,0		
	e1-1	Überw. Kamera E2	5	Access	172	18	137	169	41	y	5,0		
	e1-2	Überw. Kamera E1	5	Access	172	18	137	170	42	y	5,0		
	e1-3	Überw. Kamera E5	5	Access	172	18	137	171	43	y	5,0		
	e1-4	Überw. Kamera E9	5	Access	172	18	137	172	44	y	5,0		
	e1-5	AFZ E1	8	Access	172	20	9	147	19	y	10,0		
	e1-6	AFZ E2	8	Access	172	20	9	148	20	y	10,0		
	e1-7	AFZ E5	8	Access	172	20	9	149	21	y	10,0		
	e1-8	Sprechstelle E1	9	Access	172	20	137	140	12	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10	Sprechstelle PRM E1	9	Access	172	20	137	141	13	y	7,5		
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	137	144	16	y	7,5		Redundanz WC
	e1-12	Future use box E5	90	Access	-	-	-	-	-				
	e1-13	Future use box E7	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E1	3	Access	172	17	137	165	37				
	e1-15	Seitenanzeige E3	3	Access	172	17	137	166	38				
	e2-0	Bildschirm E7	3	Access	172	17	137	206	78				
	e2-1	Bildschirm E5	3	Access	172	17	137	207	79				
	e2-2	Bildschirm E1	3	Access	172	17	137	208	80				
e2-3	Bildschirm E3	3	Access	172	17	137	209	81					
e2-4	Bildschirm E	3	Access	172	17	137	210	82					
e2-5	Audio Amp. E1	9	Access	172	20	137	155	27					
E2	e0-0	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera E8	5	Access	172	18	137	173	45	y	5,0		
	e1-1	Überw. Kamera E4	5	Access	172	18	137	174	46	y	5,0		
	e1-2	Überw. Kamera E3	5	Access	172	18	137	175	47	y	5,0		
	e1-3	Überw. Kamera E6	5	Access	172	18	137	176	48	y	5,0		
	e1-4				-	-	-	-	-				
	e1-5	AFZ E3	8	Access	172	20	9	150	22	y	10,0		
	e1-6	AFZ E4	8	Access	172	20	9	151	23	y	10,0		
	e1-7	AFZ E6	8	Access	172	20	9	152	24	y	10,0		
	e1-8	Sprechstelle E2	9	Access	172	20	137	142	14	y	7,5		
	e1-9	Sprechstelle E1R	9	Access	172	20	137	140	12	y	7,5		Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	137	143	15	y	7,5		
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	137	141	13	y	7,5		Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-				
	e1-13	Future use box E4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E2	3	Access	172	17	137	167	39				
	e1-15	Seitenanzeige E4	3	Access	172	17	137	168	40				
	e2-0	Bildschirm E8	3	Access	172	17	137	211	83				
	e2-1	Bildschirm E6	3	Access	172	17	137	212	84				
	e2-2	Bildschirm E2	3	Access	172	17	137	213	85				
e2-3	Bildschirm E4	3	Access	172	17	137	214	86					
e2-4	Bildschirm E11	3	Access	172	17	137	215	87					
e2-5	Audio Amp. E2	9	Access	172	20	137	156	28					
E3	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera E1	5	Access	172	18	137	214	86	y	5,0		
	e1-1	Rücksehkamera E2	5	Access	172	18	137	215	87	y	5,0		
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle E2R	9	Access	172	20	137	142	14	y	7,5		Redundanz E2
	e1-10	Sprechstelle PRM WC	9	Access	172	20	137	144	16	y	7,5		
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	137	143	15	y	7,5		Redundanz E2
	e1-12	Future use box E1	90	Access	-	-	-	-	-				
	e1-13	Future use box E3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0	Energiezähler E	12	Access	172	22	9	131	3				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e0-5	Service FIS / CCTV	2	Access	172	17	9	253	125			
	e1-0	Überw. Kamera B7	5	Access	172	18	137	187	59	y	5,0	
	e1-1	Überw. Kamera B2	5	Access	172	18	137	188	60	y	5,0	
	e1-2	Überw. Kamera B1	5	Access	172	18	137	189	61	y	5,0	
	e1-3	Überw. Kamera B5	5	Access	172	18	137	190	62	y	5,0	
	e1-4	Überw. Kamera B9	5	Access	172	18	137	191	63	y	5,0	
	e1-5	AFZ B1	8	Access	172	20	9	158	30	y	10,0	
	e1-6	AFZ B2	8	Access	172	20	9	159	31	y	10,0	
	e1-7				-	-	-	-	-			
	e1-8	Sprechstelle B1	9	Access	172	20	137	147	19	y	7,5	
	e1-9				-	-	-	-	-			
	e1-10				-	-	-	-	-			
	e1-11	ZFR R	2	Access	172	17	9	130	2			
	e1-12	Future use box B5	90	Access	-	-	-	-	-			
	e1-13	Future use box B6	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige B1	3	Access	172	17	137	173	45			
	e1-15	Seitenanzeige B3	3	Access	172	17	137	174	46			
	e2-0	Bildschirm B7	3	Access	172	17	137	226	98			
	e2-1	Bildschirm B5	3	Access	172	17	137	227	99			
	e2-2	Bildschirm B1	3	Access	172	17	137	228	100			
e2-3	Bildschirm B3	3	Access	172	17	137	229	101				
e2-4	ADU B	9	Access	172	20	137	132	4				
e2-5	Audio Amp. B1	9	Access	172	20	137	159	31				
B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2				-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B2 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e0-5	reserved			-	-	-	-	-			
	e1-0	Überw. Kamera B8	5	Access	172	18	137	192	64	y	5,0	
	e1-1	Überw. Kamera B4	5	Access	172	18	137	193	65	y	5,0	
	e1-2	Überw. Kamera B3	5	Access	172	18	137	194	66	y	5,0	
	e1-3	Überw. Kamera B6	5	Access	172	18	137	195	67	y	5,0	
	e1-4	Überw. Kamera B10	5	Access	172	18	137	196	68	y	5,0	
	e1-5	AFZ B3	8	Access	172	20	9	160	32	y	10,0	
	e1-6	AFZ B4	8	Access	172	20	9	161	33	y	10,0	
	e1-7	NVR B	5	Access	172	18	137	134	6			
	e1-8	Sprechstelle B2	9	Access	172	20	137	148	20	y	7,5	
	e1-9	Sprechstelle B1R	9	Access	172	20	137	147	19	y	7,5	
	e1-10				-	-	-	-	-			
	e1-11				-	-	-	-	-			
	e1-12	Future use box B2	90	Access	-	-	-	-	-			
	e1-13	Future use box B4	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige B2	3	Access	172	17	137	175	47			
	e1-15	Seitenanzeige B4	3	Access	172	17	137	176	48			
	e2-0	Bildschirm B8	3	Access	172	17	137	230	102			
	e2-1	Bildschirm B6	3	Access	172	17	137	231	103			
	e2-2	Bildschirm B2	3	Access	172	17	137	232	104			
e2-3	Bildschirm B4	3	Access	172	17	137	233	105				
e2-4				-	-	-	-	-				
e2-5	Audio Amp. B2	9	Access	172	20	137	160	32				
B3	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B3 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e0-5	reserved			-	-	-	-	-			
	e1-0	Rücksehkamera B1	5	Access	172	18	137	218	90	y	5,0	
	e1-1	Rücksehkamera B2	5	Access	172	18	137	219	91	y	5,0	
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0	
	e1-3				-	-	-	-	-			
	e1-4				-	-	-	-	-			
	e1-5				-	-	-	-	-			
	e1-6				-	-	-	-	-			
	e1-7				-	-	-	-	-			
	e1-8				-	-	-	-	-			
	e1-9	Sprechstelle B2R	9	Access	172	20	137	148	20	y	7,5	Redundanz B2
	e1-10				-	-	-	-	-			
	e1-11	ZFR	2	Access	172	17	9	130	2			
	e1-12	Future use box B1	90	Access	-	-	-	-	-			
	e1-13	Future use box B3	90	Access	-	-	-	-	-			
	e1-14	Frontanzeige B	3	Access	172	17	137	152	24			
	e1-15				-	-	-	-	-			
	e2-0				-	-	-	-	-			
	e2-1				-	-	-	-	-			
	e2-2				-	-	-	-	-			
e2-3				-	-	-	-	-				
e2-4	ADU BR	9	Access	172	20	137	132	4				
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127				
Firewall		RCU	2	N/A	172	17	9	254	126		IP festgehalten fuer die RCU.	
			3	N/A	172	17	137	254	126		Diese ist mit der Firewall verbunden.	
			9	N/A	172	20	137	254	126		Anforderung von STADLER	