

IPv4-Schema
Fgz. Nr: 4736 - 102



Fahrzeugnummer: 4736-102				Fzg. ID: 130				Wagen: A - 100					
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address			IPID	PoE	[W]	Beschriftung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-					
	e0-3				-	-	-	-					
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e0-5	Service FIS / CCTV	2	Access	172	17	65	120					
	e1-0	Überw. Kamera A7	5	Access	172	18	193	10	10	y	5.0		
	e1-1	Überw. Kamera A2	5	Access	172	18	193	11	11	y	5.0		
	e1-2	Überw. Kamera A1	5	Access	172	18	193	12	12	y	5.0		
	e1-3	Überw. Kamera A5	5	Access	172	18	193	13	13	y	5.0		
	e1-4	Überw. Kamera A9	5	Access	172	18	193	14	14	y	5.0		
	e1-5	AFZ A1	8	Access	172	20	65	5	5	y	10.0		
	e1-6	AFZ A2	8	Access	172	20	65	6	6	y	10.0		
	e1-7				-	-	-	-					
	e1-8	Sprechstelle A1	9	Access	172	20	193	5	5	y	7.5		
	e1-9				-	-	-	-					
	e1-10				-	-	-	-					
	e1-11				-	-	-	-					
	e1-12	Future use box A5	90	Access	-	-	-	-					
	e1-13	Future use box A6	90	Access	-	-	-	-					
	e1-14	Seitenanzeige A1	3	Access	172	17	193	25	25				
	e1-15	Seitenanzeige A3	3	Access	172	17	193	26	26				
	e2-0	Bildschirm A7	3	Access	172	17	193	50	50				
	e2-1	Bildschirm A5	3	Access	172	17	193	51	51				
	e2-2	Bildschirm A1	3	Access	172	17	193	52	52				
	e2-3	Bildschirm A3	3	Access	172	17	193	53	53				
e2-4	ADU A	9	Access	172	20	193	3	3					
e2-5	Audio Amp. A1	9	Access	172	20	193	21	21					
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-2				-	-	-	-					
	e0-3				-	-	-	-					
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e0-5	reserved			-	-	-	-					
	e1-0	Überw. Kamera A8	5	Access	172	18	193	15	15	y	5.0		
	e1-1	Überw. Kamera A4	5	Access	172	18	193	16	16	y	5.0		
	e1-2	Überw. Kamera A3	5	Access	172	18	193	17	17	y	5.0		
	e1-3	Überw. Kamera A6	5	Access	172	18	193	18	18	y	5.0		
	e1-4	Überw. Kamera A10	5	Access	172	18	193	19	19	y	5.0		
	e1-5	AFZ A3	8	Access	172	20	65	7	7	y	10.0		
	e1-6	AFZ A4	8	Access	172	20	65	8	8	y	10.0		
	e1-7	NVR A	5	Access	172	18	193	5	5				
	e1-8	Sprechstelle A2	9	Access	172	20	193	6	6	y	7.5		
	e1-9	Sprechstelle A1R	9	Access	172	20	193	5	5	y	7.5		Redundanz A1
	e1-10				-	-	-	-					
	e1-11				-	-	-	-					
	e1-12	Future use box A2	90	Access	-	-	-	-					
	e1-13	Future use box A4	90	Access	-	-	-	-					
	e1-14	Seitenanzeige A2	3	Access	172	17	193	27	27				
	e1-15	Seitenanzeige A4	3	Access	172	17	193	28	28				
	e2-0	Bildschirm A8	3	Access	172	17	193	54	54				
	e2-1	Bildschirm A6	3	Access	172	17	193	55	55				
	e2-2	Bildschirm A2	3	Access	172	17	193	56	56				
	e2-3	Bildschirm A4	3	Access	172	17	193	57	57				
e2-4				-	-	-	-						
e2-5	Audio Amp. A2	9	Access	172	20	193	22	22					
A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-					
	e0-3				-	-	-	-					
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e0-5	reserved			-	-	-	-					
	e1-0	Rücksehkamera A1	5	Access	172	18	193	80	80	y	5.0		
	e1-1	Rücksehkamera A2	5	Access	172	18	193	81	81	y	5.0		
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e1-3				-	-	-	-					
	e1-4	Firewall	2	Trunk	172	17	65	1	1		Kein DHCP Statische Konfiguration STADLER		
			3		172	17	193	1					
			5		172	18	193	1					
			6		172	19	65	1					
			7		172	19	193	1					
			8		172	20	65	1					
			9		172	20	193	1					
	e1-5		12		172	22	65	1					
	e1-6				-	-	-	-					
	e1-7				-	-	-	-					
	e1-8				-	-	-	-					
	e1-9	Sprechstelle A2R	9	Access	172	20	193	6	6	y	7.5		Redundanz A2
	e1-10				-	-	-	-					
	e1-11				-	-	-	-					
	e1-12	Future use box A1	90	Access	-	-	-	-					
	e1-13	Future use box A3	90	Access	-	-	-	-					
e1-14	Frontanzeige A	3	Access	172	17	193	23	23					
e1-15				-	-	-	-						
e2-0				-	-	-	-						
e2-1				-	-	-	-						
e2-2				-	-	-	-						
e2-3				-	-	-	-						
e2-4	ADU AR	9	Access	172	20	193	3	3					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					

C1	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	65	121	121				
	e1-0	Überw. Kamera C7	5	Access	172	18	193	20	20	y	5.0		
	e1-1	Überw. Kamera C2	5	Access	172	18	193	21	21	y	5.0		
	e1-2	Überw. Kamera C1	5	Access	172	18	193	22	22	y	5.0		
	e1-3	Überw. Kamera C5	5	Access	172	18	193	23	23	y	5.0		
	e1-4	Überw. Kamera C9	5	Access	172	18	193	24	24	y	5.0		
	e1-5	AFZ C1	8	Access	172	20	65	9	9	y	10.0		
	e1-6	AFZ C2	8	Access	172	20	65	10	10	y	10.0		
	e1-7	AFZ C5	8	Access	172	20	65	11	11	y	10.0		
	e1-8	Sprechstelle C1	9	Access	172	20	193	7	7	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C5	90	Access	-	-	-	-	-				
	e1-13	Future use box C6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige C1	3	Access	172	17	193	29	29				
	e1-15	Seitenanzeige C3	3	Access	172	17	193	30	30				
	e2-0	Bildschrim C7	3	Access	172	17	193	58	58				
e2-1	Bildschrim C5	3	Access	172	17	193	59	59					
e2-2	Bildschrim C1	3	Access	172	17	193	60	60					
e2-3	Bildschrim C3	3	Access	172	17	193	61	61					
e2-4	Bildschrim C	3	Access	172	17	193	62	62					
e2-5	Audio Amp. C1	9	Access	172	20	193	23	23					
C2	e0-0	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-	-			
	e1-0	Überw. Kamera C8	5	Access	172	18	193	25	25	y	5.0		
	e1-1	Überw. Kamera C4	5	Access	172	18	193	26	26	y	5.0		
	e1-2	Überw. Kamera C3	5	Access	172	18	193	27	27	y	5.0		
	e1-3	Überw. Kamera C6	5	Access	172	18	193	28	28	y	5.0		
	e1-4	Überw. Kamera C10	5	Access	172	18	193	29	29	y	5.0		
	e1-5	AFZ C3	8	Access	172	20	65	12	12	y	10.0		
	e1-6	AFZ C4	8	Access	172	20	65	13	13	y	10.0		
	e1-7				-	-	-	-	-	-			
	e1-8	Sprechstelle C2	9	Access	172	20	193	8	8	y	7.5		
	e1-9	Sprechstelle C1R	9	Access	172	20	193	7	7	y	7.5		
	e1-10				-	-	-	-	-	-			
	e1-11				-	-	-	-	-	-			
	e1-12	Future use box C2	90	Access	-	-	-	-	-	-			
	e1-13	Future use box C4	90	Access	-	-	-	-	-	-			
	e1-14	Seitenanzeige C2	3	Access	172	17	193	31	31				
	e1-15	Seitenanzeige C4	3	Access	172	17	193	32	32				
	e2-0	Bildschrim C8	3	Access	172	17	193	63	63				
e2-1	Bildschrim C6	3	Access	172	17	193	64	64					
e2-2	Bildschrim C2	3	Access	172	17	193	65	65					
e2-3	Bildschrim C4	3	Access	172	17	193	66	66					
e2-4	Bildschrim C11	3	Access	172	17	193	67	67					
e2-5	Audio Amp. C2	9	Access	172	20	193	24	24					
C3	e0-0	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-	-			
	e1-0	Rücksehkamera C1	5	Access	172	18	193	82	82	y	5.0		
	e1-1	Rücksehkamera C2	5	Access	172	18	193	83	83	y	5.0		
	e1-2	Access point C4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-	-			
	e1-4				-	-	-	-	-	-			
	e1-5				-	-	-	-	-	-			
	e1-6				-	-	-	-	-	-			
	e1-7				-	-	-	-	-	-			
	e1-8				-	-	-	-	-	-			
	e1-9	Sprechstelle C2R	9	Access	172	20	193	8	8	y	7.5		Redundanz C2
	e1-10				-	-	-	-	-	-			
	e1-11				-	-	-	-	-	-			
	e1-12	Future use box C1	90	Access	-	-	-	-	-	-			
	e1-13	Future use box C3	90	Access	-	-	-	-	-	-			
	e1-14				-	-	-	-	-	-			
	e1-15				-	-	-	-	-	-			
	e2-0				-	-	-	-	-	-			
e2-1				-	-	-	-	-	-				
e2-2				-	-	-	-	-	-				
e2-3				-	-	-	-	-	-				
e2-4				-	-	-	-	-	-				
e2-5				-	-	-	-	-	-				

IPv4-Schema

Fgz. Nr: 4736 - 102

D1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
			7		172	19	193	2	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	65	122	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	193	30	30	y	5.0		
	e1-1	Überw. Kamera D2	5	Access	172	18	193	31	31	y	5.0		
	e1-2	Überw. Kamera D1	5	Access	172	18	193	32	32	y	5.0		
	e1-3	Überw. Kamera D5	5	Access	172	18	193	33	33	y	5.0		
	e1-4	Überw. Kamera D9	5	Access	172	18	193	34	34	y	5.0		
	e1-5	AFZ D1	8	Access	172	20	65	14	14	y	10.0		
	e1-6	AFZ D2	8	Access	172	20	65	15	15	y	10.0		
	e1-7	AFZ D5	8	Access	172	20	65	16	16	y	10.0		
	e1-8	Sprechstelle D1	9	Access	172	20	193	10	10	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
	e1-13	Future use box D6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D1	3	Access	172	17	193	33	33				
	e1-15	Seitenanzeige D3	3	Access	172	17	193	34	34				
	e2-0	Bildschirm D7	3	Access	172	17	193	68	68				
D2	e2-1	Bildschirm D5	3	Access	172	17	193	69	69				
	e2-2	Bildschirm D1	3	Access	172	17	193	70	70				
	e2-3	Bildschirm D3	3	Access	172	17	193	71	71				
	e2-4	Bildschirm D	3	Access	172	17	193	72	72				
	e2-5	Audio Amp. D1	9	Access	172	20	193	25	25				
	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	193	35	35	y	5.0		
	e1-1	Überw. Kamera D4	5	Access	172	18	193	36	36	y	5.0		
	e1-2	Überw. Kamera D3	5	Access	172	18	193	37	37	y	5.0		
	e1-3	Überw. Kamera D6	5	Access	172	18	193	38	38	y	5.0		
	e1-4	Überw. Kamera D10	5	Access	172	18	193	39	39	y	5.0		
	e1-5	AFZ D3	8	Access	172	20	65	17	17	y	10.0		
	e1-6	AFZ D4	8	Access	172	20	65	18	18	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	193	11	11	y	7.5		
	e1-9	Sprechstelle D1R	9	Access	172	20	193	10	10	y	7.5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D2	3	Access	172	17	193	35	35				
	e1-15	Seitenanzeige D4	3	Access	172	17	193	36	36				
D3	e2-0	Bildschirm D8	3	Access	172	17	193	73	73				
	e2-1	Bildschirm D6	3	Access	172	17	193	74	74				
	e2-2	Bildschirm D2	3	Access	172	17	193	75	75				
	e2-3	Bildschirm D4	3	Access	172	17	193	76	76				
	e2-4	Bildschirm D11	3	Access	172	17	193	77	77				
	e2-5	Audio Amp. D2	9	Access	172	20	193	26	26				
	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
			7		172	19	193	2	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	193	84	84	y	5.0		
	e1-1	Rücksehkamera D2	5	Access	172	18	193	85	85	y	5.0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	193	11	11	y	7.5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
	e1-13	Future use box D3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
	e2-3				-	-	-	-	-				
	e2-4				-	-	-	-	-				
	e2-5				-	-	-	-	-				

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2				-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e0-5	Service FIS / CCTV	2	Access	172	17	65	123	123					
	e1-0	Überw. Kamera E7	5	Access	172	18	193	40	40	y	5.0			
	e1-1	Überw. Kamera E2	5	Access	172	18	193	41	41	y	5.0			
	e1-2	Überw. Kamera E1	5	Access	172	18	193	42	42	y	5.0			
	e1-3	Überw. Kamera E5	5	Access	172	18	193	43	43	y	5.0			
	e1-4	Überw. Kamera E9	5	Access	172	18	193	44	44	y	5.0			
	e1-5	AFZ E1	8	Access	172	20	65	19	19	y	10.0			
	e1-6	AFZ E2	8	Access	172	20	65	20	20	y	10.0			
	e1-7	AFZ E5	8	Access	172	20	65	21	21	y	10.0			
	e1-8	Sprechstelle E1	9	Access	172	20	193	12	12	y	7.5			
	e1-9					-	-	-	-					
	e1-10	Sprechstelle PRM E1	9	Access	172	20	193	13	13	y	7.5			
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	193	16	16	y	7.5		Redundanz WC	
	e1-12	Future use box E5	90	Access		-	-	-	-					
	e1-13	Future use box E7	90	Access		-	-	-	-					
	e1-14	Seitenanzeige E1	3	Access	172	17	193	37	37					
	e1-15	Seitenanzeige E3	3	Access	172	17	193	38	38					
	E2	e2-0	Bildschirm E7	3	Access	172	17	193	78	78				
		e2-1	Bildschirm E5	3	Access	172	17	193	79	79				
		e2-2	Bildschirm E1	3	Access	172	17	193	80	80				
		e2-3	Bildschirm E3	3	Access	172	17	193	81	81				
		e2-4	Bildschirm E	3	Access	172	17	193	82	82				
e2-5		Audio Amp. E1	9	Access	172	20	193	27	27					
e0-0		FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
e0-1		FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
e0-2					-	-	-	-	-					
e0-3					-	-	-	-	-					
e0-4		Access point E2 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
e0-5					-	-	-	-	-					
e1-0		Überw. Kamera E8	5	Access	172	18	193	45	45	y	5.0			
e1-1		Überw. Kamera E4	5	Access	172	18	193	46	46	y	5.0			
e1-2		Überw. Kamera E3	5	Access	172	18	193	47	47	y	5.0			
e1-3		Überw. Kamera E6	5	Access	172	18	193	48	48	y	5.0			
e1-4						-	-	-	-					
e1-5		AFZ E3	8	Access	172	20	65	22	22	y	10.0			
e1-6		AFZ E4	8	Access	172	20	65	23	23	y	10.0			
e1-7		AFZ E6	8	Access	172	20	65	24	24	y	10.0			
e1-8		Sprechstelle E2	9	Access	172	20	193	14	14	y	7.5			
e1-9		Sprechstelle E1R	9	Access	172	20	193	12	12	y	7.5		Redundanz E1	
e1-10		Sprechstelle PRM E2	9	Access	172	20	193	15	15	y	7.5			
e1-11		Sprechstelle PRM E1R	9	Access	172	20	193	13	13	y	7.5		Redundanz E1	
e1-12		Future use box E2	90	Access		-	-	-	-					
e1-13		Future use box E4	90	Access		-	-	-	-					
e1-14		Seitenanzeige E2	3	Access	172	17	193	39	39					
e1-15	Seitenanzeige E4	3	Access	172	17	193	40	40						
E3	e2-0	Bildschirm E8	3	Access	172	17	193	83	83					
	e2-1	Bildschirm E6	3	Access	172	17	193	84	84					
	e2-2	Bildschirm E2	3	Access	172	17	193	85	85					
	e2-3	Bildschirm E4	3	Access	172	17	193	86	86					
	e2-4	Bildschirm E11	3	Access	172	17	193	87	87					
	e2-5	Audio Amp. E2	9	Access	172	20	193	28	28					
	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2				-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point E3 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e0-5				-	-	-	-	-					
	e1-0	Rücksehkamera E1	5	Access	172	18	193	86	86	y	5.0			
	e1-1	Rücksehkamera E2	5	Access	172	18	193	87	87	y	5.0			
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e1-3				-	-	-	-	-					
	e1-4				-	-	-	-	-					
	e1-5				-	-	-	-	-					
	e1-6				-	-	-	-	-					
	e1-7				-	-	-	-	-					
	e1-8				-	-	-	-	-					
	e1-9	Sprechstelle E2R	9	Access	172	20	193	14	14	y	7.5		Redundanz E2	
	e1-10	Sprechstelle PRM WC	9	Access	172	20	193	16	16	y	7.5			
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	193	15	15	y	7.5		Redundanz E2	
	e1-12	Future use box E1	90	Access		-	-	-	-					
	e1-13	Future use box E3	90	Access		-	-	-	-					
	e1-14				-	-	-	-	-					
e1-15				-	-	-	-	-						
e2-0	Energiezähler E	12	Access	172	22	65	3	3						
e2-1				-	-	-	-	-						
e2-2				-	-	-	-	-						
e2-3				-	-	-	-	-						
e2-4				-	-	-	-	-						
e2-5				-	-	-	-	-						

F1	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-2				-	-	-	-	-	-										
	e0-3				-	-	-	-	-	-										
	e0-4	Access point F1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0								
	e0-5	Service FIS / CCTV	2	Access	172	17	65	124	124											
	e1-0	Überw. Kamera F7	5	Access	172	18	193	49	49	y	5.0									
	e1-1	Überw. Kamera F2	5	Access	172	18	193	50	50	y	5.0									
	e1-2	Überw. Kamera F1	5	Access	172	18	193	51	51	y	5.0									
	e1-3	Überw. Kamera F5	5	Access	172	18	193	52	52	y	5.0									
	e1-4	Überw. Kamera F9	5	Access	172	18	193	53	53	y	5.0									
	e1-5	AFZ F1	8	Access	172	20	65	25	25	y	10.0									
	e1-6	AFZ F2	8	Access	172	20	65	26	26	y	10.0									
	e1-7	AFZ F5	8	Access	172	20	65	27	27	y	10.0									
	e1-8	Sprechstelle F1	9	Access	172	20	193	17	17	y	7.5									
	e1-9				-	-	-	-	-	-										
	e1-10				-	-	-	-	-	-										
	e1-11				-	-	-	-	-	-										
	e1-12	Future use box F5	90	Access	-	-	-	-	-	-										
	e1-13	Future use box F6	90	Access	-	-	-	-	-	-										
e1-14	Seitenanzeige F1	3	Access	172	17	193	41	41												
e1-15	Seitenanzeige F3	3	Access	172	17	193	42	42												
F2	e2-0	Bildschirm F7	3	Access	172	17	193	88	88											
	e2-1	Bildschirm F5	3	Access	172	17	193	89	89											
	e2-2	Bildschirm F1	3	Access	172	17	193	90	90											
	e2-3	Bildschirm F3	3	Access	172	17	193	91	91											
	e2-4	Bildschirm F	3	Access	172	17	193	92	92											
	e2-5	Audio Amp. F1	9	Access	172	20	193	29	29											
	e0-0	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-1	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-										
	e0-2				-	-	-	-	-	-										
	e0-3				-	-	-	-	-	-										
	e0-4	Access point F2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18.0								
	e0-5	reserved			-	-	-	-	-	-										
	e1-0	Überw. Kamera F8	5	Access	172	18	193	54	54	y	5.0									
	e1-1	Überw. Kamera F4	5	Access	172	18	193	55	55	y	5.0									
	e1-2	Überw. Kamera F3	5	Access	172															

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0	
	e0-5	Service FIS / CCTV	2	Access	172	17	65	125	125			
	e1-0	Überw. Kamera B7	5	Access	172	18	193	59	59	y	5.0	
	e1-1	Überw. Kamera B2	5	Access	172	18	193	60	60	y	5.0	
	e1-2	Überw. Kamera B1	5	Access	172	18	193	61	61	y	5.0	
	e1-3	Überw. Kamera B5	5	Access	172	18	193	62	62	y	5.0	
	e1-4	Überw. Kamera B9	5	Access	172	18	193	63	63	y	5.0	
	e1-5	AFZ B1	8	Access	172	20	65	30	30	y	10.0	
	e1-6	AFZ B2	8	Access	172	20	65	31	31	y	10.0	
	e1-7				-	-	-	-	-			
	e1-8	Sprechstelle B1	9	Access	172	20	193	19	19	y	7.5	
	e1-9				-	-	-	-	-			
	e1-10				-	-	-	-	-			
	e1-11	ZFR R	2	Access	172	17	65	2	2			
	e1-12	Future use box B5	90	Access	-	-	-	-	-			
	e1-13	Future use box B6	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige B1	3	Access	172	17	193	45	45			
	e1-15	Seitenanzeige B3	3	Access	172	17	193	46	46			
	e2-0	Bildschirm B7	3	Access	172	17	193	98	98			
	e2-1	Bildschirm B5	3	Access	172	17	193	99	99			
	e2-2	Bildschirm B1	3	Access	172	17	193	100	100			
	e2-3	Bildschirm B3	3	Access	172	17	193	101	101			
	e2-4	ADU B	9	Access	172	20	193	4	4			
	e2-5	Audio Amp. B1	9	Access	172	20	193	31	31			
B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2				-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B2 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0	
	e0-5				-	-	-	-	-			
	e1-0	Überw. Kamera B8	5	Access	172	18	193	64	64	y	5.0	
	e1-1	Überw. Kamera B4	5	Access	172	18	193	65	65	y	5.0	
	e1-2	Überw. Kamera B3	5	Access	172	18	193	66	66	y	5.0	
	e1-3	Überw. Kamera B6	5	Access	172	18	193	67	67	y	5.0	
	e1-4	Überw. Kamera B10	5	Access	172	18	193	68	68	y	5.0	
	e1-5	AFZ B3	8	Access	172	20	65	32	32	y	10.0	
	e1-6	AFZ B4	8	Access	172	20	65	33	33	y	10.0	
	e1-7	NVR B	5	Access	172	18	193	6	6			
	e1-8	Sprechstelle B2	9	Access	172	20	193	20	20	y	7.5	
	e1-9	Sprechstelle B1R	9	Access	172	20	193	19	19	y	7.5	
	e1-10				-	-	-	-	-			
	e1-11				-	-	-	-	-			
	e1-12	Future use box B2	90	Access	-	-	-	-	-			
	e1-13	Future use box B4	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige B2	3	Access	172	17	193	47	47			
	e1-15	Seitenanzeige B4	3	Access	172	17	193	48	48			
	e2-0	Bildschirm B8	3	Access	172	17	193	102	102			
	e2-1	Bildschirm B6	3	Access	172	17	193	103	103			
	e2-2	Bildschirm B2	3	Access	172	17	193	104	104			
	e2-3	Bildschirm B4	3	Access	172	17	193	105	105			
	e2-4				-	-	-	-	-			
	e2-5	Audio Amp. B2	9	Access	172	20	193	32	32			
B3	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B3 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0	
	e0-5				-	-	-	-	-			
	e1-0	Rücksehkamera B1	5	Access	172	18	193	90	90	y	5.0	
	e1-1	Rücksehkamera B2	5	Access	172	18	193	91	91	y	5.0	
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0	
	e1-3				-	-	-	-	-			
	e1-4				-	-	-	-	-			
	e1-5				-	-	-	-	-			
	e1-6				-	-	-	-	-			
	e1-7				-	-	-	-	-			
	e1-8				-	-	-	-	-			
	e1-9	Sprechstelle B2R	9	Access	172	20	193	20	20	y	7.5	Redundanz B2
	e1-10				-	-	-	-	-			
	e1-11	ZFR	2	Access	172	17	65	2	2			
	e1-12	Future use box B1	90	Access	-	-	-	-	-			
	e1-13	Future use box B3	90	Access	-	-	-	-	-			
	e1-14	Frontanzeige B	3	Access	172	17	193	24	24			
	e1-15				-	-	-	-	-			
	e2-0				-	-	-	-	-			
	e2-1				-	-	-	-	-			
	e2-2				-	-	-	-	-			
	e2-3				-	-	-	-	-			
	e2-4	ADU BR	9	Access	172	20	193	4	4			
	e2-5	Service VI AN PWI AN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127			