

Fahrzeugnummer: 4736-106				Fzg. ID: 134				Wagen: A - 100			
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address		IPID	PoE	[W]	Beschreibung TS	Comment
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-			
	e0-3				-	-	-	-			
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18,0	
	e0-5	Service FIS / CCTV	2	Access	172	17	67	120	120		
	e1-0	Überw. Kamera A7	5	Access	172	18	195	10	10	y	5,0
	e1-1	Überw. Kamera A2	5	Access	172	18	195	11	11	y	5,0
	e1-2	Überw. Kamera A1	5	Access	172	18	195	12	12	y	5,0
	e1-3	Überw. Kamera A5	5	Access	172	18	195	13	13	y	5,0
	e1-4	Überw. Kamera A9	5	Access	172	18	195	14	14	y	5,0
	e1-5	AFZ A1	8	Access	172	20	67	5	5	y	10,0
	e1-6	AFZ A2	8	Access	172	20	67	6	6	y	10,0
	e1-7				-	-	-	-			
	e1-8	Sprechstelle A1	9	Access	172	20	195	5	5	y	7,5
	e1-9				-	-	-	-			
	e1-10				-	-	-	-			
	e1-11				-	-	-	-			
	e1-12	Future use box A5	90	Access	-	-	-	-			
	e1-13	Future use box A6	90	Access	-	-	-	-			
	e1-14	Seitenanzeige A1	3	Access	172	17	195	25	25		
	e1-15	Seitenanzeige A3	3	Access	172	17	195	26	26		
	e2-0	Bildschirm A7	3	Access	172	17	195	50	50		
	e2-1	Bildschirm A5	3	Access	172	17	195	51	51		
	e2-2	Bildschirm A1	3	Access	172	17	195	52	52		
	e2-3	Bildschirm A3	3	Access	172	17	195	53	53		
A2	e2-4	ADU A	9	Access	172	20	195	3	3		
	e2-5	Audio Amp. A1	9	Access	172	20	195	21	21		
	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-2				-	-	-	-			
	e0-3				-	-	-	-			
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18,0	
	e0-5	reserved			-	-	-	-			
	e1-0	Überw. Kamera A8	5	Access	172	18	195	15	15	y	5,0
	e1-1	Überw. Kamera A4	5	Access	172	18	195	16	16	y	5,0
	e1-2	Überw. Kamera A3	5	Access	172	18	195	17	17	y	5,0
	e1-3	Überw. Kamera A6	5	Access	172	18	195	18	18	y	5,0
	e1-4	Überw. Kamera A10	5	Access	172	18	195	19	19	y	5,0
	e1-5	AFZ A3	8	Access	172	20	67	7	7	y	10,0
	e1-6	AFZ A4	8	Access	172	20	67	8	8	y	10,0
	e1-7	NVR A	5	Access	172	18	195	5	5		
	e1-8	Sprechstelle A2	9	Access	172	20	195	6	6	y	7,5
	e1-9	Sprechstelle A1R	9	Access	172	20	195	5	5	y	7,5
	e1-10				-	-	-	-			Redundanz A1
	e1-11				-	-	-	-			
	e1-12	Future use box A2	90	Access	-	-	-	-			
	e1-13	Future use box A4	90	Access	-	-	-	-			
	e1-14	Seitenanzeige A2	3	Access	172	17	195	27	27		
	e1-15	Seitenanzeige A4	3	Access	172	17	195	28	28		
	e2-0	Bildschirm A8	3	Access	172	17	195	54	54		
	e2-1	Bildschirm A6	3	Access	172	17	195	55	55		
	e2-2	Bildschirm A2	3	Access	172	17	195	56	56		
	e2-3	Bildschirm A4	3	Access	172	17	195	57	57		
	e2-4				-	-	-	-			
	e2-5	Audio Amp. A2	9	Access	172	20	195	22	22		
A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-			
	e0-3				-	-	-	-			
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18,0	
	e0-5	reserved			-	-	-	-			
	e1-0	Rücksehkamera A1	5	Access	172	18	195	80	80	y	5,0
	e1-1	Rücksehkamera A2	5	Access	172	18	195	81	81	y	5,0
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18,0	
	e1-3				-	-	-	-			
	e1-4	Firewall	2	Trunk	172	17	67	1	1		Kein DHCP Statische Konfiguration STADLER
			3		172	17	195	1			
			5		172	18	195	1			
			6		172	19	67	1			
			7		172	19	195	1			
			8		172	20	67	1			
			9		172	20	195	1			
			12		172	22	67	1			
	e1-5				-	-	-	-			
	e1-6				-	-	-	-			
	e1-7				-	-	-	-			
	e1-8				-	-	-	-			
	e1-9	Sprechstelle A2R	9	Access	172	20	195	6	6	y	7,5
	e1-10				-	-	-	-			Redundanz A2
	e1-11				-	-	-	-			
	e1-12	Future use box A1	90	Access	-	-	-	-			
	e1-13	Future use box A3	90	Access	-	-	-	-			
	e1-14	Frontanzeige A	3	Access	172	17	195	23	23		
	e1-15				-	-	-	-			
	e2-0				-	-	-	-			
	e2-1				-	-	-	-			
	e2-2				-	-	-	-			
	e2-3				-	-	-	-			
	e2-4	ADU AR	9	Access	172	20	195	3	3		
	e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127		

C1	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point C1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	67	121	121					
	e1-0	Überw. Kamera C7	5	Access	172	18	195	20	20	y	5,0			
	e1-1	Überw. Kamera C2	5	Access	172	18	195	21	21	y	5,0			
	e1-2	Überw. Kamera C1	5	Access	172	18	195	22	22	y	5,0			
	e1-3	Überw. Kamera C5	5	Access	172	18	195	23	23	y	5,0			
	e1-4	Überw. Kamera C9	5	Access	172	18	195	24	24	y	5,0			
	e1-5	AFZ C1	8	Access	172	20	67	9	9	y	10,0			
	e1-6	AFZ C2	8	Access	172	20	67	10	10	y	10,0			
	e1-7	AFZ C5	8	Access	172	20	67	11	11	y	10,0			
	e1-8	Sprechstelle C1	9	Access	172	20	195	7	7	y	7,5			
	e1-9				-	-	-	-	-	-				
	e1-10				-	-	-	-	-	-				
	e1-11				-	-	-	-	-	-				
	e1-12	Future use box C5	90	Access	-	-	-	-	-	-				
	e1-13	Future use box C6	90	Access	-	-	-	-	-	-				
	e1-14	Seitenanzeige C1	3	Access	172	17	195	29	29					
	e1-15	Seitenanzeige C3	3	Access	172	17	195	30	30					
	e2-0	Bildschirm C7	3	Access	172	17	195	58	58					
e2-1	Bildschirm C5	3	Access	172	17	195	59	59						
e2-2	Bildschirm C1	3	Access	172	17	195	60	60						
e2-3	Bildschirm C3	3	Access	172	17	195	61	61						
e2-4	Bildschirm C	3	Access	172	17	195	62	62						
e2-5	Audio Amp. C1	9	Access	172	20	195	23	23						
C2	e0-0	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point C2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-	-				
	e1-0	Überw. Kamera C8	5	Access	172	18	195	25	25	y	5,0			
	e1-1	Überw. Kamera C4	5	Access	172	18	195	26	26	y	5,0			
	e1-2	Überw. Kamera C3	5	Access	172	18	195	27	27	y	5,0			
	e1-3	Überw. Kamera C6	5	Access	172	18	195	28	28	y	5,0			
	e1-4	Überw. Kamera C10	5	Access	172	18	195	29	29	y	5,0			
	e1-5	AFZ C3	8	Access	172	20	67	12	12	y	10,0			
	e1-6	AFZ C4	8	Access	172	20	67	13	13	y	10,0			
	e1-7				-	-	-	-	-	-				
	e1-8	Sprechstelle C2	9	Access	172	20	195	8	8	y	7,5			
	e1-9	Sprechstelle C1R	9	Access	172	20	195	7	7	y	7,5			
	e1-10				-	-	-	-	-	-				
	e1-11				-	-	-	-	-	-				
	e1-12	Future use box C2	90	Access	-	-	-	-	-	-				
	e1-13	Future use box C4	90	Access	-	-	-	-	-	-				
	e1-14	Seitenanzeige C2	3	Access	172	17	195	31	31					
	e1-15	Seitenanzeige C4	3	Access	172	17	195	32	32					
	e2-0	Bildschirm C8	3	Access	172	17	195	63	63					
e2-1	Bildschirm C6	3	Access	172	17	195	64	64						
e2-2	Bildschirm C2	3	Access	172	17	195	65	65						
e2-3	Bildschirm C4	3	Access	172	17	195	66	66						
e2-4	Bildschirm C11	3	Access	172	17	195	67	67						
e2-5	Audio Amp. C2	9	Access	172	20	195	24	24						
C3	e0-0	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point C3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-	-				
	e1-0	Rücksehkamera C1	5	Access	172	18	195	82	82	y	5,0			
	e1-1	Rücksehkamera C2	5	Access	172	18	195	83	83	y	5,0			
	e1-2	Access point C4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-	-				
	e1-4				-	-	-	-	-	-				
	e1-5				-	-	-	-	-	-				
	e1-6				-	-	-	-	-	-				
	e1-7				-	-	-	-	-	-				
	e1-8				-	-	-	-	-	-				
	e1-9	Sprechstelle C2R	9	Access	172	20	195	8	8	y	7,5			Redundanz C2
	e1-10				-	-	-	-	-	-				
	e1-11				-	-	-	-	-	-				
	e1-12	Future use box C1	90	Access	-	-	-	-	-	-				
	e1-13	Future use box C3	90	Access	-	-	-	-	-	-				
	e1-14				-	-	-	-	-	-				
	e1-15				-	-	-	-	-	-				
	e2-0				-	-	-	-	-	-				
e2-1				-	-	-	-	-	-					
e2-2				-	-	-	-	-	-					
e2-3				-	-	-	-	-	-					
e2-4				-	-	-	-	-	-					
e2-5				-	-	-	-	-	-					

D1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	195	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	67	122	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	195	30	30	y	5,0		
	e1-1	Überw. Kamera D2	5	Access	172	18	195	31	31	y	5,0		
	e1-2	Überw. Kamera D1	5	Access	172	18	195	32	32	y	5,0		
	e1-3	Überw. Kamera D5	5	Access	172	18	195	33	33	y	5,0		
	e1-4	Überw. Kamera D9	5	Access	172	18	195	34	34	y	5,0		
	e1-5	AFZ D1	8	Access	172	20	67	14	14	y	10,0		
	e1-6	AFZ D2	8	Access	172	20	67	15	15	y	10,0		
	e1-7	AFZ D5	8	Access	172	20	67	16	16	y	10,0		
	e1-8	Sprechstelle D1	9	Access	172	20	195	10	10	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
	e1-13	Future use box D6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D1	3	Access	172	17	195	33	33				
	e1-15	Seitenanzeige D3	3	Access	172	17	195	34	34				
	e2-0	Bildschirm D7	3	Access	172	17	195	68	68				
	e2-1	Bildschirm D5	3	Access	172	17	195	69	69				
e2-2	Bildschirm D1	3	Access	172	17	195	70	70					
e2-3	Bildschirm D3	3	Access	172	17	195	71	71					
e2-4	Bildschirm D	3	Access	172	17	195	72	72					
e2-5	Audio Amp. D1	9	Access	172	20	195	25	25					
D2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	195	35	35	y	5,0		
	e1-1	Überw. Kamera D4	5	Access	172	18	195	36	36	y	5,0		
	e1-2	Überw. Kamera D3	5	Access	172	18	195	37	37	y	5,0		
	e1-3	Überw. Kamera D6	5	Access	172	18	195	38	38	y	5,0		
	e1-4	Überw. Kamera D10	5	Access	172	18	195	39	39	y	5,0		
	e1-5	AFZ D3	8	Access	172	20	67	17	17	y	10,0		
	e1-6	AFZ D4	8	Access	172	20	67	18	18	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	195	11	11	y	7,5		
	e1-9	Sprechstelle D1R	9	Access	172	20	195	10	10	y	7,5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D2	3	Access	172	17	195	35	35				
	e1-15	Seitenanzeige D4	3	Access	172	17	195	36	36				
	e2-0	Bildschirm D8	3	Access	172	17	195	73	73				
	e2-1	Bildschirm D6	3	Access	172	17	195	74	74				
	e2-2	Bildschirm D2	3	Access	172	17	195	75	75				
e2-3	Bildschirm D4	3	Access	172	17	195	76	76					
e2-4	Bildschirm D11	3	Access	172	17	195	77	77					
e2-5	Audio Amp. D2	9	Access	172	20	195	26	26					
D3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	195	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	195	84	84	y	5,0		
	e1-1	Rücksehkamera D2	5	Access	172	18	195	85	85	y	5,0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	195	11	11	y	7,5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
	e1-13	Future use box D3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	67	123	123					
	e1-0	Überw. Kamera E7	5	Access	172	18	195	40	40	y	5,0			
	e1-1	Überw. Kamera E2	5	Access	172	18	195	41	41	y	5,0			
	e1-2	Überw. Kamera E1	5	Access	172	18	195	42	42	y	5,0			
	e1-3	Überw. Kamera E5	5	Access	172	18	195	43	43	y	5,0			
	e1-4	Überw. Kamera E9	5	Access	172	18	195	44	44	y	5,0			
	e1-5	AFZ E1	8	Access	172	20	67	19	19	y	10,0			
	e1-6	AFZ E2	8	Access	172	20	67	20	20	y	10,0			
	e1-7	AFZ E5	8	Access	172	20	67	21	21	y	10,0			
	e1-8	Sprechstelle E1	9	Access	172	20	195	12	12	y	7,5			
	e1-9					-	-	-	-	-				
	e1-10	Sprechstelle PRM E1	9	Access	172	20	195	13	13	y	7,5			
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	195	16	16	y	7,5			Redundanz WC
	e1-12	Future use box E5	90	Access	-	-	-	-	-	-				
	e1-13	Future use box E7	90	Access	-	-	-	-	-	-				
	e1-14	Seitenanzeige E1	3	Access	172	17	195	37	37					
	e1-15	Seitenanzeige E3	3	Access	172	17	195	38	38					
	e2-0	Bildschirm E7	3	Access	172	17	195	78	78					
	e2-1	Bildschirm E5	3	Access	172	17	195	79	79					
e2-2	Bildschirm E1	3	Access	172	17	195	80	80						
e2-3	Bildschirm E3	3	Access	172	17	195	81	81						
e2-4	Bildschirm E	3	Access	172	17	195	82	82						
e2-5	Audio Amp. E1	9	Access	172	20	195	27	27						
E2	e0-0	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-	-				
	e1-0	Überw. Kamera E8	5	Access	172	18	195	45	45	y	5,0			
	e1-1	Überw. Kamera E4	5	Access	172	18	195	46	46	y	5,0			
	e1-2	Überw. Kamera E3	5	Access	172	18	195	47	47	y	5,0			
	e1-3	Überw. Kamera E6	5	Access	172	18	195	48	48	y	5,0			
	e1-4				-	-	-	-	-	-				
	e1-5	AFZ E3	8	Access	172	20	67	22	22	y	10,0			
	e1-6	AFZ E4	8	Access	172	20	67	23	23	y	10,0			
	e1-7	AFZ E6	8	Access	172	20	67	24	24	y	10,0			
	e1-8	Sprechstelle E2	9	Access	172	20	195	14	14	y	7,5			
	e1-9	Sprechstelle E1R	9	Access	172	20	195	12	12	y	7,5			Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	195	15	15	y	7,5			
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	195	13	13	y	7,5			Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-	-				
	e1-13	Future use box E4	90	Access	-	-	-	-	-	-				
	e1-14	Seitenanzeige E2	3	Access	172	17	195	39	39					
	e1-15	Seitenanzeige E4	3	Access	172	17	195	40	40					
	e2-0	Bildschirm E8	3	Access	172	17	195	83	83					
	e2-1	Bildschirm E6	3	Access	172	17	195	84	84					
e2-2	Bildschirm E2	3	Access	172	17	195	85	85						
e2-3	Bildschirm E4	3	Access	172	17	195	86	86						
e2-4	Bildschirm E11	3	Access	172	17	195	87	87						
e2-5	Audio Amp. E2	9	Access	172	20	195	28	28						
E3	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-	-				
	e1-0	Rücksehkamera E1	5	Access	172	18	195	86	86	y	5,0			
	e1-1	Rücksehkamera E2	5	Access	172	18	195	87	87	y	5,0			
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-	-				
	e1-4				-	-	-	-	-	-				
	e1-5				-	-	-	-	-	-				
	e1-6				-	-	-	-	-	-				
	e1-7				-	-	-	-	-	-				
	e1-8				-	-	-	-	-	-				
	e1-9	Sprechstelle E2R	9	Access	172	20	195	14	14	y	7,5			Redundanz E2
	e1-10	Sprechstelle PRM WC	9	Access	172	20	195	16	16	y	7,5			
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	195	15	15	y	7,5			Redundanz E2
	e1-12	Future use box E1	90	Access	-	-	-	-	-	-				
	e1-13	Future use box E3	90	Access	-	-	-	-	-	-				
	e1-14				-	-	-	-	-	-				
	e1-15				-	-	-	-	-	-				
	e2-0	Energiezähler E	12	Access	172	22	67	3	3					
	e2-1				-	-	-	-	-	-				
e2-2				-	-	-	-	-	-					
e2-3				-	-	-	-	-	-					
e2-4				-	-	-	-	-	-					
e2-5				-	-	-	-	-	-					

IPv4-Schema
Fgz. Nr: 4736 - 106



F1	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	67	124	124				
	e1-0	Überw. Kamera F7	5	Access	172	18	195	49	49	y	5,0		
	e1-1	Überw. Kamera F2	5	Access	172	18	195	50	50	y	5,0		
	e1-2	Überw. Kamera F1	5	Access	172	18	195	51	51	y	5,0		
	e1-3	Überw. Kamera F5	5	Access	172	18	195	52	52	y	5,0		
	e1-4	Überw. Kamera F9	5	Access	172	18	195	53	53	y	5,0		
	e1-5	AFZ F1	8	Access	172	20	67	25	25	y	10,0		
	e1-6	AFZ F2	8	Access	172	20	67	26	26	y	10,0		
	e1-7	AFZ F5	8	Access	172	20	67	27	27	y	10,0		
	e1-8	Sprechstelle F1	9	Access	172	20	195	17	17	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F5	90	Access	-	-	-	-	-				
	e1-13	Future use box F6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige F1	3	Access	172	17	195	41	41				
	e1-15	Seitenanzeige F3	3	Access	172	17	195	42	42				
	e2-0	Bildschirm F7	3	Access	172	17	195	88	88				
F2	e2-1	Bildschirm F5	3	Access	172	17	195	89	89				
	e2-2	Bildschirm F1	3	Access	172	17	195	90	90				
	e2-3	Bildschirm F3	3	Access	172	17	195	91	91				
	e2-4	Bildschirm F	3	Access	172	17	195	92	92				
	e2-5	Audio Amp. F1	9	Access	172	20	195	29	29				
	e0-0	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera F8	5	Access	172	18	195	54	54	y	5,0		
	e1-1	Überw. Kamera F4	5	Access	172	18	195	55	55	y	5,0		
	e1-2	Überw. Kamera F3	5	Access	172	18	195	56	56	y	5,0		
	e1-3	Überw. Kamera F6	5	Access	172	18	195	57	57	y	5,0		
	e1-4	Überw. Kamera F10	5	Access	172	18	195	58	58	y	5,0		
	e1-5	AFZ F3	8	Access	172	20	67	28	28	y	10,0		
	e1-6	AFZ F4	8	Access	172	20	67	29	29	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle F2	9	Access	172	20	195	18	18	y	7,5		
	e1-9	Sprechstelle FIR	9	Access	172	20	195	17	17	y	7,5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F2	90	Access	-	-	-	-	-				
	e1-13	Future use box F4	90	Access	-	-	-	-	-				
F3	e1-14	Seitenanzeige F2	3	Access	172	17	195	43	43				
	e1-15	Seitenanzeige F4	3	Access	172	17	195	44	44				
	e2-0	Bildschirm F8	3	Access	172	17	195	93	93				
	e2-1	Bildschirm F6	3	Access	172	17	195	94	94				
	e2-2	Bildschirm F2	3	Access	172	17	195	95	95				
	e2-3	Bildschirm F	3	Access	172	17	195	96	96				
	e2-4	Bildschirm F11	3	Access	172	17	195	97	97				
	e2-5	Audio Amp. F2	9	Access	172	20	195	30	30				
	e0-0	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera F1	5	Access	172	18	195	88	88	y	5,0		
	e1-1	Rücksehkamera F2	5	Access	172	18	195	89	89	y	5,0		
	e1-2	Access point F4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle F2R	9	Access	172	20	195	18	18	y	7,5		Redundanz F2
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F1	90	Access	-	-	-	-	-				
	e1-13	Future use box F3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
	e2-3				-	-	-	-	-				
	e2-4				-	-	-	-	-				
	e2-5				-	-	-	-	-				

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	67	125	125				
	e1-0	Überw. Kamera B7	5	Access	172	18	195	59	59	y	5,0		
	e1-1	Überw. Kamera B2	5	Access	172	18	195	60	60	y	5,0		
	e1-2	Überw. Kamera B1	5	Access	172	18	195	61	61	y	5,0		
	e1-3	Überw. Kamera B5	5	Access	172	18	195	62	62	y	5,0		
	e1-4	Überw. Kamera B9	5	Access	172	18	195	63	63	y	5,0		
	e1-5	AFZ B1	8	Access	172	20	67	30	30	y	10,0		
	e1-6	AFZ B2	8	Access	172	20	67	31	31	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle B1	9	Access	172	20	195	19	19	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11	ZFR R	2	Access	172	17	67	2	2				
	e1-12	Future use box B5	90	Access	-	-	-	-	-				
	e1-13	Future use box B6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B1	3	Access	172	17	195	45	45				
e1-15	Seitenanzeige B3	3	Access	172	17	195	46	46					
e2-0	Bildschirm B7	3	Access	172	17	195	98	98					
e2-1	Bildschirm B5	3	Access	172	17	195	99	99					
e2-2	Bildschirm B1	3	Access	172	17	195	100	100					
e2-3	Bildschirm B3	3	Access	172	17	195	101	101					
e2-4	ADU B	9	Access	172	20	195	4	4					
e2-5	Audio Amp. B1	9	Access	172	20	195	31	31					
B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera B8	5	Access	172	18	195	64	64	y	5,0		
	e1-1	Überw. Kamera B4	5	Access	172	18	195	65	65	y	5,0		
	e1-2	Überw. Kamera B3	5	Access	172	18	195	66	66	y	5,0		
	e1-3	Überw. Kamera B6	5	Access	172	18	195	67	67	y	5,0		
	e1-4	Überw. Kamera B10	5	Access	172	18	195	68	68	y	5,0		
	e1-5	AFZ B3	8	Access	172	20	67	32	32	y	10,0		
	e1-6	AFZ B4	8	Access	172	20	67	33	33	y	10,0		
	e1-7	NVR B	5	Access	172	18	195	6	6				
	e1-8	Sprechstelle B2	9	Access	172	20	195	20	20	y	7,5		
	e1-9	Sprechstelle B1R	9	Access	172	20	195	19	19	y	7,5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box B2	90	Access	-	-	-	-	-				
	e1-13	Future use box B4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B2	3	Access	172	17	195	47	47				
e1-15	Seitenanzeige B4	3	Access	172	17	195	48	48					
e2-0	Bildschirm B8	3	Access	172	17	195	102	102					
e2-1	Bildschirm B6	3	Access	172	17	195	103	103					
e2-2	Bildschirm B2	3	Access	172	17	195	104	104					
e2-3	Bildschirm B4	3	Access	172	17	195	105	105					
e2-4				-	-	-	-	-					
e2-5	Audio Amp. B2	9	Access	172	20	195	32	32					
B3	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera B1	5	Access	172	18	195	90	90	y	5,0		
	e1-1	Rücksehkamera B2	5	Access	172	18	195	91	91	y	5,0		
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle B2R	9	Access	172	20	195	20	20	y	7,5		Redundanz B2
	e1-10				-	-	-	-	-				
	e1-11	ZFR	2	Access	172	17	67	2	2				
	e1-12	Future use box B1	90	Access	-	-	-	-	-				
	e1-13	Future use box B3	90	Access	-	-	-	-	-				
	e1-14	Frontanzeige B	3	Access	172	17	195	24	24				
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4	ADU BR	9	Access	172	20	195	4	4					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					