

IPv4-Schema
Fgz. Nr: 4736 - 108



Fahrzeugnummer: 4736-108				Fzg ID: 136				Wagen:			A - 100		
Switch	Switchport	Usage	VLAN ID	Port Type	IP Adress			IPID	PoE	[W]	Beschriftung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-					
	e0-3				-	-	-	-					
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e0-5	Service FIS / CCTV	2	Access	172	17	68	120					
	e1-0	Überw. Kamera A7	5	Access	172	18	196	10	10	y	5.0		
	e1-1	Überw. Kamera A2	5	Access	172	18	196	11	11	y	5.0		
	e1-2	Überw. Kamera A1	5	Access	172	18	196	12	12	y	5.0		
	e1-3	Überw. Kamera A5	5	Access	172	18	196	13	13	y	5.0		
	e1-4	Überw. Kamera A9	5	Access	172	18	196	14	14	y	5.0		
	e1-5	AFZ A1	8	Access	172	20	68	5	5	y	10.0		
	e1-6	AFZ A2	8	Access	172	20	68	6	6	y	10.0		
	e1-7				-	-	-	-					
	e1-8	Sprechstelle A1	9	Access	172	20	196	5	5	y	7.5		
	e1-9				-	-	-	-					
	e1-10				-	-	-	-					
	e1-11				-	-	-	-					
	e1-12	Future use box A5	90	Access	-	-	-	-					
	e1-13	Future use box A6	90	Access	-	-	-	-					
	e1-14	Seitenanzeige A1	3	Access	172	17	196	25	25				
	e1-15	Seitenanzeige A3	3	Access	172	17	196	26	26				
	e2-0	Bildschrim A7	3	Access	172	17	196	50	50				
	e2-1	Bildschrim A5	3	Access	172	17	196	51	51				
	e2-2	Bildschrim A1	3	Access	172	17	196	52	52				
	e2-3	Bildschrim A3	3	Access	172	17	196	53	53				
e2-4	ADU A	9	Access	172	20	196	3	3					
e2-5	Audio Amp. A1	9	Access	172	20	196	21	21					
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-2				-	-	-	-					
	e0-3				-	-	-	-					
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e0-5	reserved			-	-	-	-					
	e1-0	Überw. Kamera A8	5	Access	172	18	196	15	15	y	5.0		
	e1-1	Überw. Kamera A4	5	Access	172	18	196	16	16	y	5.0		
	e1-2	Überw. Kamera A3	5	Access	172	18	196	17	17	y	5.0		
	e1-3	Überw. Kamera A6	5	Access	172	18	196	18	18	y	5.0		
	e1-4	Überw. Kamera A10	5	Access	172	18	196	19	19	y	5.0		
	e1-5	AFZ A3	8	Access	172	20	68	7	7	y	10.0		
	e1-6	AFZ A4	8	Access	172	20	68	8	8	y	10.0		
	e1-7	NVR A	5	Access	172	18	196	5	5				
	e1-8	Sprechstelle A2	9	Access	172	20	196	6	6	y	7.5		
	e1-9	Sprechstelle A1R	9	Access	172	20	196	5	5	y	7.5		Redundanz A1
	e1-10				-	-	-	-					
	e1-11				-	-	-	-					
	e1-12	Future use box A2	90	Access	-	-	-	-					
	e1-13	Future use box A4	90	Access	-	-	-	-					
	e1-14	Seitenanzeige A2	3	Access	172	17	196	27	27				
	e1-15	Seitenanzeige A4	3	Access	172	17	196	28	28				
	e2-0	Bildschrim A8	3	Access	172	17	196	54	54				
	e2-1	Bildschrim A6	3	Access	172	17	196	55	55				
	e2-2	Bildschrim A2	3	Access	172	17	196	56	56				
	e2-3	Bildschrim A4	3	Access	172	17	196	57	57				
e2-4				-	-	-	-						
e2-5	Audio Amp. A2	9	Access	172	20	196	22	22					
A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-					
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-					
	e0-3				-	-	-	-					
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e0-5	reserved			-	-	-	-					
	e1-0	Rücksehkamera A1	5	Access	172	18	196	80	80	y	5.0		
	e1-1	Rücksehkamera A2	5	Access	172	18	196	81	81	y	5.0		
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18.0			
	e1-3				-	-	-	-					
	e1-4	Firewall	2	Trunk	172	17	68	1	1		Kein DHCP Statische Konfiguration STADLER		
			3		172	17	196	1					
			5		172	18	196	1					
			6		172	19	68	1					
			7		172	19	196	1					
			8		172	20	68	1					
			9		172	20	196	1					
	e1-5				-	-	-	-					
	e1-6				-	-	-	-					
	e1-7				-	-	-	-					
	e1-8				-	-	-	-					
	e1-9	Sprechstelle A2R	9	Access	172	20	196	6	6	y	7.5		Redundanz A2
	e1-10				-	-	-	-					
	e1-11				-	-	-	-					
	e1-12	Future use box A1	90	Access	-	-	-	-					
	e1-13	Future use box A3	90	Access	-	-	-	-					
e1-14	Frontanzeige A	3	Access	172	17	196	23	23					
e1-15				-	-	-	-						
e2-0				-	-	-	-						
e2-1				-	-	-	-						
e2-2				-	-	-	-						
e2-3				-	-	-	-						
e2-4	ADU AR	9	Access	172	20	196	3	3					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					

C1	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	68	121	121				
	e1-0	Überw. Kamera C7	5	Access	172	18	196	20	20	y	5.0		
	e1-1	Überw. Kamera C2	5	Access	172	18	196	21	21	y	5.0		
	e1-2	Überw. Kamera C1	5	Access	172	18	196	22	22	y	5.0		
	e1-3	Überw. Kamera C5	5	Access	172	18	196	23	23	y	5.0		
	e1-4	Überw. Kamera C9	5	Access	172	18	196	24	24	y	5.0		
	e1-5	AFZ C1	8	Access	172	20	68	9	9	y	10.0		
	e1-6	AFZ C2	8	Access	172	20	68	10	10	y	10.0		
	e1-7	AFZ C5	8	Access	172	20	68	11	11	y	10.0		
	e1-8	Sprechstelle C1	9	Access	172	20	196	7	7	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C5	90	Access	-	-	-	-	-				
	e1-13	Future use box C6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige C1	3	Access	172	17	196	29	29				
	e1-15	Seitenanzeige C3	3	Access	172	17	196	30	30				
	e2-0	Bildschirm C7	3	Access	172	17	196	58	58				
e2-1	Bildschirm C5	3	Access	172	17	196	59	59					
e2-2	Bildschirm C1	3	Access	172	17	196	60	60					
e2-3	Bildschirm C3	3	Access	172	17	196	61	61					
e2-4	Bildschirm C	3	Access	172	17	196	62	62					
e2-5	Audio Amp. C1	9	Access	172	20	196	23	23					
C2	e0-0	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-	-			
	e1-0	Überw. Kamera C8	5	Access	172	18	196	25	25	y	5.0		
	e1-1	Überw. Kamera C4	5	Access	172	18	196	26	26	y	5.0		
	e1-2	Überw. Kamera C3	5	Access	172	18	196	27	27	y	5.0		
	e1-3	Überw. Kamera C6	5	Access	172	18	196	28	28	y	5.0		
	e1-4	Überw. Kamera C10	5	Access	172	18	196	29	29	y	5.0		
	e1-5	AFZ C3	8	Access	172	20	68	12	12	y	10.0		
	e1-6	AFZ C4	8	Access	172	20	68	13	13	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle C2	9	Access	172	20	196	8	8	y	7.5		
	e1-9	Sprechstelle C1R	9	Access	172	20	196	7	7	y	7.5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C2	90	Access	-	-	-	-	-				
	e1-13	Future use box C4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige C2	3	Access	172	17	196	31	31				
	e1-15	Seitenanzeige C4	3	Access	172	17	196	32	32				
	e2-0	Bildschirm C8	3	Access	172	17	196	63	63				
e2-1	Bildschirm C6	3	Access	172	17	196	64	64					
e2-2	Bildschirm C2	3	Access	172	17	196	65	65					
e2-3	Bildschirm C4	3	Access	172	17	196	66	66					
e2-4	Bildschirm C11	3	Access	172	17	196	67	67					
e2-5	Audio Amp. C2	9	Access	172	20	196	24	24					
C3	e0-0	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-	-			
	e1-0	Rücksehkamera C1	5	Access	172	18	196	82	82	y	5.0		
	e1-1	Rücksehkamera C2	5	Access	172	18	196	83	83	y	5.0		
	e1-2	Access point C4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-	-			
	e1-4				-	-	-	-	-	-			
	e1-5				-	-	-	-	-	-			
	e1-6				-	-	-	-	-	-			
	e1-7				-	-	-	-	-	-			
	e1-8				-	-	-	-	-	-			
	e1-9	Sprechstelle C2R	9	Access	172	20	196	8	8	y	7.5		Redundanz C2
	e1-10				-	-	-	-	-	-			
	e1-11				-	-	-	-	-	-			
	e1-12	Future use box C1	90	Access	-	-	-	-	-	-			
	e1-13	Future use box C3	90	Access	-	-	-	-	-	-			
	e1-14				-	-	-	-	-	-			
	e1-15				-	-	-	-	-	-			
	e2-0				-	-	-	-	-	-			
e2-1				-	-	-	-	-	-				
e2-2				-	-	-	-	-	-				
e2-3				-	-	-	-	-	-				
e2-4				-	-	-	-	-	-				
e2-5				-	-	-	-	-	-				

IPv4-Schema

Fgz. Nr: 4736 - 108

D1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					172	19	196	2	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	68	122	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	196	30	30	y	5.0		
	e1-1	Überw. Kamera D2	5	Access	172	18	196	31	31	y	5.0		
	e1-2	Überw. Kamera D1	5	Access	172	18	196	32	32	y	5.0		
	e1-3	Überw. Kamera D5	5	Access	172	18	196	33	33	y	5.0		
	e1-4	Überw. Kamera D9	5	Access	172	18	196	34	34	y	5.0		
	e1-5	AFZ D1	8	Access	172	20	68	14	14	y	10.0		
	e1-6	AFZ D2	8	Access	172	20	68	15	15	y	10.0		
	e1-7	AFZ D5	8	Access	172	20	68	16	16	y	10.0		
	e1-8	Sprechstelle D1	9	Access	172	20	196	10	10	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
	e1-13	Future use box D6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D1	3	Access	172	17	196	33	33				
	e1-15	Seitenanzeige D3	3	Access	172	17	196	34	34				
D2	e2-0	Bildschirm D7	3	Access	172	17	196	68	68				
	e2-1	Bildschirm D5	3	Access	172	17	196	69	69				
	e2-2	Bildschirm D1	3	Access	172	17	196	70	70				
	e2-3	Bildschirm D3	3	Access	172	17	196	71	71				
	e2-4	Bildschirm D	3	Access	172	17	196	72	72				
	e2-5	Audio Amp. D1	9	Access	172	20	196	25	25				
	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	196	35	35	y	5.0		
	e1-1	Überw. Kamera D4	5	Access	172	18	196	36	36	y	5.0		
	e1-2	Überw. Kamera D3	5	Access	172	18	196	37	37	y	5.0		
	e1-3	Überw. Kamera D6	5	Access	172	18	196	38	38	y	5.0		
	e1-4	Überw. Kamera D10	5	Access	172	18	196	39	39	y	5.0		
	e1-5	AFZ D3	8	Access	172	20	68	17	17	y	10.0		
	e1-6	AFZ D4	8	Access	172	20	68	18	18	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	196	11	11	y	7.5		
	e1-9	Sprechstelle D1R	9	Access	172	20	196	10	10	y	7.5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
D3	e1-14	Seitenanzeige D2	3	Access	172	17	196	35	35				
	e1-15	Seitenanzeige D4	3	Access	172	17	196	36	36				
	e2-0	Bildschirm D8	3	Access	172	17	196	73	73				
	e2-1	Bildschirm D6	3	Access	172	17	196	74	74				
	e2-2	Bildschirm D2	3	Access	172	17	196	75	75				
	e2-3	Bildschirm D4	3	Access	172	17	196	76	76				
	e2-4	Bildschirm D11	3	Access	172	17	196	77	77				
	e2-5	Audio Amp. D2	9	Access	172	20	196	26	26				
	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					172	19	196	2	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	196	84	84	y	5.0		
	e1-1	Rücksehkamera D2	5	Access	172	18	196	85	85	y	5.0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	196	11	11	y	7.5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
	e1-13	Future use box D3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
	e2-3				-	-	-	-	-				
	e2-4				-	-	-	-	-				
	e2-5				-	-	-	-	-				

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2				-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e0-5	Service FIS / CCTV	2	Access	172	17	68	123	123					
	e1-0	Überw. Kamera E7	5	Access	172	18	196	40	40	y	5.0			
	e1-1	Überw. Kamera E2	5	Access	172	18	196	41	41	y	5.0			
	e1-2	Überw. Kamera E1	5	Access	172	18	196	42	42	y	5.0			
	e1-3	Überw. Kamera E5	5	Access	172	18	196	43	43	y	5.0			
	e1-4	Überw. Kamera E9	5	Access	172	18	196	44	44	y	5.0			
	e1-5	AFZ E1	8	Access	172	20	68	19	19	y	10.0			
	e1-6	AFZ E2	8	Access	172	20	68	20	20	y	10.0			
	e1-7	AFZ E5	8	Access	172	20	68	21	21	y	10.0			
	e1-8	Sprechstelle E1	9	Access	172	20	196	12	12	y	7.5			
	e1-9					-	-	-	-					
	e1-10	Sprechstelle PRM E1	9	Access	172	20	196	13	13	y	7.5			
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	196	16	16	y	7.5		Redundanz WC	
	e1-12	Future use box E5	90	Access	-	-	-	-	-					
	e1-13	Future use box E7	90	Access	-	-	-	-	-					
	e1-14	Seitenanzeige E1	3	Access	172	17	196	37	37					
	e1-15	Seitenanzeige E3	3	Access	172	17	196	38	38					
	e2-0	Bildschirm E7	3	Access	172	17	196	78	78					
	e2-1	Bildschirm E5	3	Access	172	17	196	79	79					
	e2-2	Bildschirm E1	3	Access	172	17	196	80	80					
	e2-3	Bildschirm E3	3	Access	172	17	196	81	81					
	e2-4	Bildschirm E	3	Access	172	17	196	82	82					
	e2-5	Audio Amp. E1	9	Access	172	20	196	27	27					
	E2	e0-0	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
		e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
		e0-2				-	-	-	-	-				
		e0-3				-	-	-	-	-				
e0-4		Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
e0-5		reserved			-	-	-	-	-					
e1-0		Überw. Kamera E8	5	Access	172	18	196	45	45	y	5.0			
e1-1		Überw. Kamera E4	5	Access	172	18	196	46	46	y	5.0			
e1-2		Überw. Kamera E3	5	Access	172	18	196	47	47	y	5.0			
e1-3		Überw. Kamera E6	5	Access	172	18	196	48	48	y	5.0			
e1-4					-	-	-	-	-					
e1-5		AFZ E3	8	Access	172	20	68	22	22	y	10.0			
e1-6		AFZ E4	8	Access	172	20	68	23	23	y	10.0			
e1-7		AFZ E6	8	Access	172	20	68	24	24	y	10.0			
e1-8		Sprechstelle E2	9	Access	172	20	196	14	14	y	7.5			
e1-9		Sprechstelle E1R	9	Access	172	20	196	12	12	y	7.5		Redundanz E1	
e1-10		Sprechstelle PRM E2	9	Access	172	20	196	15	15	y	7.5			
e1-11		Sprechstelle PRM E1R	9	Access	172	20	196	13	13	y	7.5		Redundanz E1	
e1-12		Future use box E2	90	Access	-	-	-	-	-					
e1-13		Future use box E4	90	Access	-	-	-	-	-					
e1-14		Seitenanzeige E2	3	Access	172	17	196	39	39					
e1-15		Seitenanzeige E4	3	Access	172	17	196	40	40					
e2-0		Bildschirm E8	3	Access	172	17	196	83	83					
e2-1		Bildschirm E6	3	Access	172	17	196	84	84					
e2-2		Bildschirm E2	3	Access	172	17	196	85	85					
e2-3	Bildschirm E4	3	Access	172	17	196	86	86						
e2-4	Bildschirm E11	3	Access	172	17	196	87	87						
e2-5	Audio Amp. E2	9	Access	172	20	196	28	28						
E3	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2				-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e0-5	reserved			-	-	-	-	-					
	e1-0	Rücksehkamera E1	5	Access	172	18	196	86	86	y	5.0			
	e1-1	Rücksehkamera E2	5	Access	172	18	196	87	87	y	5.0			
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e1-3				-	-	-	-	-					
	e1-4				-	-	-	-	-					
	e1-5				-	-	-	-	-					
	e1-6				-	-	-	-	-					
	e1-7				-	-	-	-	-					
	e1-8				-	-	-	-	-					
	e1-9	Sprechstelle E2R	9	Access	172	20	196	14	14	y	7.5		Redundanz E2	
	e1-10	Sprechstelle PRM WC	9	Access	172	20	196	16	16	y	7.5			
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	196	15	15	y	7.5		Redundanz E2	
	e1-12	Future use box E1	90	Access	-	-	-	-	-					
	e1-13	Future use box E3	90	Access	-	-	-	-	-					
	e1-14				-	-	-	-	-					
	e1-15				-	-	-	-	-					
	e2-0	Energiezähler E	12	Access	172	22	68	3	3					
	e2-1				-	-	-	-	-					
	e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-						
e2-4				-	-	-	-	-						
e2-5				-	-	-	-	-						

F1	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	68	124	124				
	e1-0	Überw. Kamera F7	5	Access	172	18	196	49	49	y	5.0		
	e1-1	Überw. Kamera F2	5	Access	172	18	196	50	50	y	5.0		
	e1-2	Überw. Kamera F1	5	Access	172	18	196	51	51	y	5.0		
	e1-3	Überw. Kamera F5	5	Access	172	18	196	52	52	y	5.0		
	e1-4	Überw. Kamera F9	5	Access	172	18	196	53	53	y	5.0		
	e1-5	AFZ F1	8	Access	172	20	68	25	25	y	10.0		
	e1-6	AFZ F2	8	Access	172	20	68	26	26	y	10.0		
	e1-7	AFZ F5	8	Access	172	20	68	27	27	y	10.0		
	e1-8	Sprechstelle F1	9	Access	172	20	196	17	17	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F5	90	Access	-	-	-	-	-				
	e1-13	Future use box F6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige F1	3	Access	172	17	196	41	41				
	e1-15	Seitenanzeige F3	3	Access	172	17	196	42	42				
	e2-0	Bildschirm F7	3	Access	172	17	196	88	88				
e2-1	Bildschirm F5	3	Access	172	17	196	89	89					
e2-2	Bildschirm F1	3	Access	172	17	196	90	90					
e2-3	Bildschirm F3	3	Access	172	17	196	91	91					
e2-4	Bildschirm F	3	Access	172	17	196	92	92					
e2-5	Audio Amp. F1	9	Access	172	20	196	29	29					
F2	e0-0	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera F8	5	Access	172	18	196	54	54	y	5.0		
	e1-1	Überw. Kamera F4	5	Access	172	18	196	55	55	y	5.0		
	e1-2	Überw. Kamera F3	5	Access	172	18	196	56	56	y	5.0		
	e1-3	Überw. Kamera F6	5	Access	172	18	196	57	57	y	5.0		
	e1-4	Überw. Kamera F10	5	Access	172	18	196	58	58	y	5.0		
	e1-5	AFZ F3	8	Access	172	20	68	28	28	y	10.0		
	e1-6	AFZ F4	8	Access	172	20	68	29	29	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle F2	9	Access	172	20	196	18	18	y	7.5		
	e1-9	Sprechstelle F1R	9	Access	172	20	196	17	17	y	7.5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F2	90	Access	-	-	-	-	-				
	e1-13	Future use box F4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige F2	3	Access	172	17	196	43	43				
	e1-15	Seitenanzeige F4	3	Access	172	17	196	44	44				
	e2-0	Bildschirm F8	3	Access	172	17	196	93	93				
e2-1	Bildschirm F6	3	Access	172	17	196	94	94					
e2-2	Bildschirm F2	3	Access	172	17	196	95	95					
e2-3	Bildschirm F	3	Access	172	17	196	96	96					
e2-4	Bildschirm F11	3	Access	172	17	196	97	97					
e2-5	Audio Amp. F2	9	Access	172	20	196	30	30					
F3	e0-0	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera F1	5	Access	172	18	196	88	88	y	5.0		
	e1-1	Rücksehkamera F2	5	Access	172	18	196	89	89	y	5.0		
	e1-2	Access point F4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle F2R	9	Access	172	20	196	18	18	y	7.5		Redundanz F2
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F1	90	Access	-	-	-	-	-				
	e1-13	Future use box F3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e0-5	Service FIS / CCTV	2	Access	172	17	68	125	125					
	e1-0	Überw. Kamera B7	5	Access	172	18	196	59	59	y	5.0			
	e1-1	Überw. Kamera B2	5	Access	172	18	196	60	60	y	5.0			
	e1-2	Überw. Kamera B1	5	Access	172	18	196	61	61	y	5.0			
	e1-3	Überw. Kamera B5	5	Access	172	18	196	62	62	y	5.0			
	e1-4	Überw. Kamera B9	5	Access	172	18	196	63	63	y	5.0			
	e1-5	AFZ B1	8	Access	172	20	68	30	30	y	10.0			
	e1-6	AFZ B2	8	Access	172	20	68	31	31	y	10.0			
	e1-7				-	-	-	-	-					
	e1-8	Sprechstelle B1	9	Access	172	20	196	19	19	y	7.5			
	e1-9				-	-	-	-	-					
	e1-10				-	-	-	-	-					
	e1-11	ZFR R	2	Access	172	17	68	2	2					
	e1-12	Future use box B5	90	Access	-	-	-	-	-					
	e1-13	Future use box B6	90	Access	-	-	-	-	-					
	e1-14	Seitenanzeige B1	3	Access	172	17	196	45	45					
	e1-15	Seitenanzeige B3	3	Access	172	17	196	46	46					
	B2	e2-0	Bildschirm B7	3	Access	172	17	196	98	98				
		e2-1	Bildschirm B5	3	Access	172	17	196	99	99				
		e2-2	Bildschirm B1	3	Access	172	17	196	100	100				
e2-3		Bildschirm B3	3	Access	172	17	196	101	101					
e2-4		ADU B	9	Access	172	20	196	4	4					
e2-5		Audio Amp. B1	9	Access	172	20	196	31	31					
e0-0		FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
e0-1		FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
e0-2					-	-	-	-	-					
e0-3					-	-	-	-	-					
e0-4		Access point B2 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
e0-5					-	-	-	-	-					
e1-0		Überw. Kamera B8	5	Access	172	18	196	64	64	y	5.0			
e1-1		Überw. Kamera B4	5	Access	172	18	196	65	65	y	5.0			
e1-2		Überw. Kamera B3	5	Access	172	18	196	66	66	y	5.0			
e1-3		Überw. Kamera B6	5	Access	172	18	196	67	67	y	5.0			
e1-4		Überw. Kamera B10	5	Access	172	18	196	68	68	y	5.0			
e1-5		AFZ B3	8	Access	172	20	68	32	32	y	10.0			
e1-6		AFZ B4	8	Access	172	20	68	33	33	y	10.0			
e1-7		NVR B	5	Access	172	18	196	6	6					
e1-8		Sprechstelle B2	9	Access	172	20	196	20	20	y	7.5			
e1-9		Sprechstelle B1R	9	Access	172	20	196	19	19	y	7.5			
e1-10					-	-	-	-	-					
e1-11					-	-	-	-	-					
e1-12		Future use box B2	90	Access	-	-	-	-	-					
e1-13	Future use box B4	90	Access	-	-	-	-	-						
e1-14	Seitenanzeige B2	3	Access	172	17	196	47	47						
e1-15	Seitenanzeige B4	3	Access	172	17	196	48	48						
B3	e2-0	Bildschirm B8	3	Access	172	17	196	102	102					
	e2-1	Bildschirm B6	3	Access	172	17	196	103	103					
	e2-2	Bildschirm B2	3	Access	172	17	196	104	104					
	e2-3	Bildschirm B4	3	Access	172	17	196	105	105					
	e2-4				-	-	-	-	-					
	e2-5	Audio Amp. B2	9	Access	172	20	196	32	32					
	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point B3 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e0-5				-	-	-	-	-					
	e1-0	Rücksehkamera B1	5	Access	172	18	196	90	90	y	5.0			
	e1-1	Rücksehkamera B2	5	Access	172	18	196	91	91	y	5.0			
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0			
	e1-3				-	-	-	-	-					
	e1-4				-	-	-	-	-					
	e1-5				-	-	-	-	-					
	e1-6				-	-	-	-	-					
	e1-7				-	-	-	-	-					
	e1-8				-	-	-	-	-					
	e1-9	Sprechstelle B2R	9	Access	172	20	196	20	20	y	7.5		Redundanz B2	
	e1-10				-	-	-	-	-					
	e1-11	ZFR	2	Access	172	17	68	2	2					
	e1-12	Future use box B1	90	Access	-	-	-	-	-					
e1-13	Future use box B3	90	Access	-	-	-	-	-						
e1-14	Frontanzeige B	3	Access	172	17	196	24	24						
e1-15				-	-	-	-	-						
e2-0				-	-	-	-	-						
e2-1				-	-	-	-	-						
e2-2				-	-	-	-	-						
e2-3				-	-	-	-	-						
e2-4	ADU BR	9	Access	172	20	196	4	4						
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127						