

Fahrzeugnummer: 4736-116				Fzg ID: 144				Wagen: A - 100						
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address				IPID	PoE	[W]	Beschreibung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
	e0-5	Service FIS / CCTV	2	Access	172	17	72	120	120					
	e1-0	Überw. Kamera A7	5	Access	172	18	200	10	10	y	5,0			
	e1-1	Überw. Kamera A2	5	Access	172	18	200	11	11	y	5,0			
	e1-2	Überw. Kamera A1	5	Access	172	18	200	12	12	y	5,0			
	e1-3	Überw. Kamera A5	5	Access	172	18	200	13	13	y	5,0			
	e1-4	Überw. Kamera A9	5	Access	172	18	200	14	14	y	5,0			
	e1-5	AFZ A1	8	Access	172	20	72	5	5	y	10,0			
	e1-6	AFZ A2	8	Access	172	20	72	6	6	y	10,0			
	e1-7				-	-	-	-	-					
	e1-8	Sprechstelle A1	9	Access	172	20	200	5	5	y	7,5			
	e1-9				-	-	-	-	-					
	e1-10				-	-	-	-	-					
	e1-11				-	-	-	-	-					
	e1-12	Future use box A5	90	Access	-	-	-	-	-					
	e1-13	Future use box A6	90	Access	-	-	-	-	-					
	e1-14	Seitenanzeige A1	3	Access	172	17	200	25	25					
	e1-15	Seitenanzeige A3	3	Access	172	17	200	26	26					
	e2-0	Bildschirm A7	3	Access	172	17	200	50	50					
	e2-1	Bildschirm A5	3	Access	172	17	200	51	51					
	e2-2	Bildschirm A1	3	Access	172	17	200	52	52					
e2-3	Bildschirm A3	3	Access	172	17	200	53	53						
e2-4	ADU A	9	Access	172	20	200	3	3						
e2-5	Audio Amp. A1	9	Access	172	20	200	21	21						
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2				-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
	e0-5	reserved			-	-	-	-	-					
	e1-0	Überw. Kamera A8	5	Access	172	18	200	15	15	y	5,0			
	e1-1	Überw. Kamera A4	5	Access	172	18	200	16	16	y	5,0			
	e1-2	Überw. Kamera A3	5	Access	172	18	200	17	17	y	5,0			
	e1-3	Überw. Kamera A6	5	Access	172	18	200	18	18	y	5,0			
	e1-4	Überw. Kamera A10	5	Access	172	18	200	19	19	y	5,0			
	e1-5	AFZ A3	8	Access	172	20	72	7	7	y	10,0			
	e1-6	AFZ A4	8	Access	172	20	72	8	8	y	10,0			
	e1-7	NVR A	5	Access	172	18	200	5	5					
	e1-8	Sprechstelle A2	9	Access	172	20	200	6	6	y	7,5			
	e1-9	Sprechstelle A1R	9	Access	172	20	200	5	5	y	7,5		Redundanz A1	
	e1-10				-	-	-	-	-					
	e1-11				-	-	-	-	-					
	e1-12	Future use box A2	90	Access	-	-	-	-	-					
	e1-13	Future use box A4	90	Access	-	-	-	-	-					
	e1-14	Seitenanzeige A2	3	Access	172	17	200	27	27					
	e1-15	Seitenanzeige A4	3	Access	172	17	200	28	28					
	e2-0	Bildschirm A8	3	Access	172	17	200	54	54					
	e2-1	Bildschirm A6	3	Access	172	17	200	55	55					
	e2-2	Bildschirm A2	3	Access	172	17	200	56	56					
	e2-3	Bildschirm A4	3	Access	172	17	200	57	57					
	e2-4				-	-	-	-	-					
	e2-5	Audio Amp. A2	9	Access	172	20	200	22	22					
	A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
		e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
e0-2		Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-					
e0-3					-	-	-	-	-					
e0-4		Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
e0-5		reserved			-	-	-	-	-					
e1-0		Rücksehkamera A1	5	Access	172	18	200	80	80	y	5,0			
e1-1		Rücksehkamera A2	5	Access	172	18	200	81	81	y	5,0			
e1-2		Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
e1-3					-	-	-	-	-					
e1-4		Firewall	2	Trunk	172	17	72	1	1			Kein DHCP Statische Konfiguration STADLER		
		3	172		17	200	1							
		5	172		18	200	1							
		6	172		19	72	1							
		7	172		19	200	1							
		8	172		20	72	1							
		9	172		20	200	1							
		12	172	22	72	1								
e1-5					-	-	-	-	-					
e1-6					-	-	-	-	-					
e1-7					-	-	-	-	-					
e1-8					-	-	-	-	-					
e1-9		Sprechstelle A2R	9	Access	172	20	200	6	6	y	7,5		Redundanz A2	
e1-10					-	-	-	-	-					
e1-11					-	-	-	-	-					
e1-12		Future use box A1	90	Access	-	-	-	-	-					
e1-13		Future use box A3	90	Access	-	-	-	-	-					
e1-14		Frontanzeige A	3	Access	172	17	200	23	23					
e1-15					-	-	-	-	-					
e2-0					-	-	-	-	-					
e2-1				-	-	-	-	-						
e2-2				-	-	-	-	-						
e2-3				-	-	-	-	-						
e2-4	ADU AR	9	Access	172	20	200	3	3						
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127						

C1	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point C1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	72	121	121					
	e1-0	Überw. Kamera C7	5	Access	172	18	200	20	20	y	5,0			
	e1-1	Überw. Kamera C2	5	Access	172	18	200	21	21	y	5,0			
	e1-2	Überw. Kamera C1	5	Access	172	18	200	22	22	y	5,0			
	e1-3	Überw. Kamera C5	5	Access	172	18	200	23	23	y	5,0			
	e1-4	Überw. Kamera C9	5	Access	172	18	200	24	24	y	5,0			
	e1-5	AFZ C1	8	Access	172	20	72	9	9	y	10,0			
	e1-6	AFZ C2	8	Access	172	20	72	10	10	y	10,0			
	e1-7	AFZ C5	8	Access	172	20	72	11	11	y	10,0			
	e1-8	Sprechstelle C1	9	Access	172	20	200	7	7	y	7,5			
	e1-9				-	-	-	-	-	-				
	e1-10				-	-	-	-	-	-				
	e1-11				-	-	-	-	-	-				
	e1-12	Future use box C5	90	Access	-	-	-	-	-	-				
	e1-13	Future use box C6	90	Access	-	-	-	-	-	-				
	e1-14	Seitenanzeige C1	3	Access	172	17	200	29	29					
	e1-15	Seitenanzeige C3	3	Access	172	17	200	30	30					
	e2-0	Bildschirm C7	3	Access	172	17	200	58	58					
	e2-1	Bildschirm C5	3	Access	172	17	200	59	59					
	e2-2	Bildschirm C1	3	Access	172	17	200	60	60					
e2-3	Bildschirm C3	3	Access	172	17	200	61	61						
e2-4	Bildschirm C	3	Access	172	17	200	62	62						
e2-5	Audio Amp. C1	9	Access	172	20	200	23	23						
C2	e0-0	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point C2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-	-				
	e1-0	Überw. Kamera C8	5	Access	172	18	200	25	25	y	5,0			
	e1-1	Überw. Kamera C4	5	Access	172	18	200	26	26	y	5,0			
	e1-2	Überw. Kamera C3	5	Access	172	18	200	27	27	y	5,0			
	e1-3	Überw. Kamera C6	5	Access	172	18	200	28	28	y	5,0			
	e1-4	Überw. Kamera C10	5	Access	172	18	200	29	29	y	5,0			
	e1-5	AFZ C3	8	Access	172	20	72	12	12	y	10,0			
	e1-6	AFZ C4	8	Access	172	20	72	13	13	y	10,0			
	e1-7				-	-	-	-	-	-				
	e1-8	Sprechstelle C2	9	Access	172	20	200	8	8	y	7,5			
	e1-9	Sprechstelle C1R	9	Access	172	20	200	7	7	y	7,5			
	e1-10				-	-	-	-	-	-				
	e1-11				-	-	-	-	-	-				
	e1-12	Future use box C2	90	Access	-	-	-	-	-	-				
	e1-13	Future use box C4	90	Access	-	-	-	-	-	-				
	e1-14	Seitenanzeige C2	3	Access	172	17	200	31	31					
	e1-15	Seitenanzeige C4	3	Access	172	17	200	32	32					
	e2-0	Bildschirm C8	3	Access	172	17	200	63	63					
	e2-1	Bildschirm C6	3	Access	172	17	200	64	64					
	e2-2	Bildschirm C2	3	Access	172	17	200	65	65					
e2-3	Bildschirm C4	3	Access	172	17	200	66	66						
e2-4	Bildschirm C11	3	Access	172	17	200	67	67						
e2-5	Audio Amp. C2	9	Access	172	20	200	24	24						
C3	e0-0	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-1	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-				
	e0-2				-	-	-	-	-	-				
	e0-3				-	-	-	-	-	-				
	e0-4	Access point C3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-	-				
	e1-0	Rücksehkamera C1	5	Access	172	18	200	82	82	y	5,0			
	e1-1	Rücksehkamera C2	5	Access	172	18	200	83	83	y	5,0			
	e1-2	Access point C4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-	-				
	e1-4				-	-	-	-	-	-				
	e1-5				-	-	-	-	-	-				
	e1-6				-	-	-	-	-	-				
	e1-7				-	-	-	-	-	-				
	e1-8				-	-	-	-	-	-				
	e1-9	Sprechstelle C2R	9	Access	172	20	200	8	8	y	7,5			Redundanz C2
	e1-10				-	-	-	-	-	-				
	e1-11				-	-	-	-	-	-				
	e1-12	Future use box C1	90	Access	-	-	-	-	-	-				
	e1-13	Future use box C3	90	Access	-	-	-	-	-	-				
	e1-14				-	-	-	-	-	-				
	e1-15				-	-	-	-	-	-				
	e2-0				-	-	-	-	-	-				
	e2-1				-	-	-	-	-	-				
	e2-2				-	-	-	-	-	-				
e2-3				-	-	-	-	-	-					
e2-4				-	-	-	-	-	-					
e2-5				-	-	-	-	-	-					

IPv4-Schema
Fgz. Nr: 4736-116

D1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-							
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-							
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-							
			7		172	19	200	2	2							
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-							
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0					
	e0-5	Service FIS / CCTV	2	Access	172	17	72	122	122							
	e1-0	Überw. Kamera D7	5	Access	172	18	200	30	30	y	5,0					
	e1-1	Überw. Kamera D2	5	Access	172	18	200	31	31	y	5,0					
	e1-2	Überw. Kamera D1	5	Access	172	18	200	32	32	y	5,0					
	e1-3	Überw. Kamera D5	5	Access	172	18	200	33	33	y	5,0					
	e1-4	Überw. Kamera D9	5	Access	172	18	200	34	34	y	5,0					
	e1-5	AFZ D1	8	Access	172	20	72	14	14	y	10,0					
	e1-6	AFZ D2	8	Access	172	20	72	15	15	y	10,0					
	e1-7	AFZ D5	8	Access	172	20	72	16	16	y	10,0					
	e1-8	Sprechstelle D1	9	Access	172	20	200	10	10	y	7,5					
	e1-9				-	-	-	-	-							
	e1-10				-	-	-	-	-							
	e1-11				-	-	-	-	-							
	e1-12	Future use box D5	90	Access	-	-	-	-	-							
	e1-13	Future use box D6	90	Access	-	-	-	-	-							
	e1-14	Seitenanzeige D1	3	Access	172	17	200	33	33							
	e1-15	Seitenanzeige D3	3	Access	172	17	200	34	34							
	e2-0	Bildschrim D7	3	Access	172	17	200	68	68							
	e2-1	Bildschrim D5	3	Access	172	17	200	69	69							
	e2-2	Bildschrim D1	3	Access	172	17	200	70	70							
	e2-3	Bildschrim D3	3	Access	172	17	200	71	71							
	e2-4	Bildschirm D	3	Access	172	17	200	72	72							
e2-5	Audio Amp. D1	9	Access	172	20	200	25	25								
D2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-							
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-							
	e0-2	OBS Reserve D2			-	-	-	-	-							
	e0-3	RDC Reserve D2			-	-	-	-	-							
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0					
	e0-5	reserved			-	-	-	-	-							
	e1-0	Überw. Kamera D8	5	Access	172	18	200	35	35	y	5,0					
	e1-1	Überw. Kamera D4	5	Access	172	18	200	36	36	y	5,0					
	e1-2	Überw. Kamera D3	5	Access	172	18	200	37	37	y	5,0					
	e1-3	Überw. Kamera D6	5	Access	172	18	200	38	38	y	5,0					
	e1-4	Überw. Kamera D10	5	Access	172	18	200	39	39	y	5,0					
	e1-5	AFZ D3	8	Access	172	20	72	17	17	y	10,0					
	e1-6	AFZ D4	8	Access	172	20	72	18	18	y	10,0					
	e1-7				-	-	-	-	-							
	e1-8	Sprechstelle D2	9	Access	172	20	200	11	11	y	7,5					
	e1-9	Sprechstelle DIR	9	Access	172	20	200	10	10	y	7,5				Redundanz D1	
	e1-10				-	-	-	-	-							
	e1-11				-	-	-	-	-							
	e1-12	Future use box D2	90	Access	-	-	-	-	-							
	e1-13	Future use box D4	90	Access	-	-	-	-	-							
	e1-14	Seitenanzeige D2	3	Access	172	17	200	35	35							
	e1-15	Seitenanzeige D4	3	Access	172	17	200	36	36							
	e2-0	Bildschrim D8	3	Access	172	17	200	73	73							
	e2-1	Bildschrim D6	3	Access	172	17	200	74	74							
	e2-2	Bildschrim D2	3	Access	172	17	200	75	75							
	e2-3	Bildschrim D4	3	Access	172	17	200	76	76							
	e2-4	Bildschrim D11	3	Access	172	17	200	77	77							
	e2-5	Audio Amp. D2	9	Access	172	20	200	26	26							
D3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-							
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-							
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-							
			7		172	19	200	2	2							
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-							
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0					
	e0-5	reserved			-	-	-	-	-							
	e1-0	Rücksehkamera D1	5	Access	172	18	200	84	84	y	5,0					
	e1-1	Rücksehkamera D2	5	Access	172	18	200	85	85	y	5,0					
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0					
	e1-3				-	-	-	-	-							
	e1-4				-	-	-	-	-							
	e1-5				-	-	-	-	-							
	e1-6				-	-	-	-	-							
	e1-7				-	-	-	-	-							
	e1-8				-	-	-	-	-							
	e1-9	Sprechstelle D2R	9	Access	172	20	200	11	11	y	7,5				Redundanz D2	
	e1-10	OBS Reserve D2			-	-	-	-	-							
	e1-11	RDC Reserve D2			-	-	-	-	-							
	e1-12	Future use box D1	90	Access	-	-	-	-	-							
	e1-13	Future use box D3	90	Access	-	-	-	-	-							
	e1-14				-	-	-	-	-							
	e1-15				-	-	-	-	-							
	e2-0				-	-	-	-	-							
	e2-1				-	-	-	-	-							
	e2-2				-	-	-	-	-							
	e2-3				-	-	-	-	-							
	e2-4				-	-	-	-	-							
	e2-5				-	-	-	-	-							

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	72	123	123				
	e1-0	Überw. Kamera E7	5	Access	172	18	200	40	40	y	5,0		
	e1-1	Überw. Kamera E2	5	Access	172	18	200	41	41	y	5,0		
	e1-2	Überw. Kamera E1	5	Access	172	18	200	42	42	y	5,0		
	e1-3	Überw. Kamera E5	5	Access	172	18	200	43	43	y	5,0		
	e1-4	Überw. Kamera E9	5	Access	172	18	200	44	44	y	5,0		
	e1-5	AFZ E1	8	Access	172	20	72	19	19	y	10,0		
	e1-6	AFZ E2	8	Access	172	20	72	20	20	y	10,0		
	e1-7	AFZ E5	8	Access	172	20	72	21	21	y	10,0		
	e1-8	Sprechstelle E1	9	Access	172	20	200	12	12	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10	Sprechstelle PRM E1	9	Access	172	20	200	13	13	y	7,5		
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	200	16	16	y	7,5		Redundanz WC
	e1-12	Future use box E5	90	Access	-	-	-	-	-				
	E2	e1-13	Future use box E7	90	Access	-	-	-	-	-			
e1-14		Seitenanzeige E1	3	Access	172	17	200	37	37				
e1-15		Seitenanzeige E3	3	Access	172	17	200	38	38				
e2-0		Bildschirm E7	3	Access	172	17	200	78	78				
e2-1		Bildschirm E5	3	Access	172	17	200	79	79				
e2-2		Bildschirm E1	3	Access	172	17	200	80	80				
e2-3		Bildschirm E3	3	Access	172	17	200	81	81				
e2-4		Bildschirm E	3	Access	172	17	200	82	82				
e2-5		Audio Amp. E1	9	Access	172	20	200	27	27				
e0-0		FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
e0-1		FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
e0-2					-	-	-	-	-				
e0-3					-	-	-	-	-				
e0-4		Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
e0-5		reserved			-	-	-	-	-				
e1-0		Überw. Kamera E8	5	Access	172	18	200	45	45	y	5,0		
e1-1		Überw. Kamera E4	5	Access	172	18	200	46	46	y	5,0		
e1-2		Überw. Kamera E3	5	Access	172	18	200	47	47	y	5,0		
e1-3		Überw. Kamera E6	5	Access	172	18	200	48	48	y	5,0		
E3		e1-4				-	-	-	-	-			
	e1-5	AFZ E3	8	Access	172	20	72	22	22	y	10,0		
	e1-6	AFZ E4	8	Access	172	20	72	23	23	y	10,0		
	e1-7	AFZ E6	8	Access	172	20	72	24	24	y	10,0		
	e1-8	Sprechstelle E2	9	Access	172	20	200	14	14	y	7,5		
	e1-9	Sprechstelle E1R	9	Access	172	20	200	12	12	y	7,5		Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	200	15	15	y	7,5		
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	200	13	13	y	7,5		Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-				
	e1-13	Future use box E4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E2	3	Access	172	17	200	39	39				
	e1-15	Seitenanzeige E4	3	Access	172	17	200	40	40				
	e2-0	Bildschirm E8	3	Access	172	17	200	83	83				
	e2-1	Bildschirm E6	3	Access	172	17	200	84	84				
	e2-2	Bildschirm E2	3	Access	172	17	200	85	85				
	e2-3	Bildschirm E4	3	Access	172	17	200	86	86				
	e2-4	Bildschirm E11	3	Access	172	17	200	87	87				
	e2-5	Audio Amp. E2	9	Access	172	20	200	28	28				
	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
e0-2				-	-	-	-	-					
e0-3				-	-	-	-	-					
e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
e0-5	reserved			-	-	-	-	-					
e1-0	Rücksehkamera E1	5	Access	172	18	200	86	86	y	5,0			
e1-1	Rücksehkamera E2	5	Access	172	18	200	87	87	y	5,0			
e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
e1-3				-	-	-	-	-					
e1-4				-	-	-	-	-					
e1-5				-	-	-	-	-					
e1-6				-	-	-	-	-					
e1-7				-	-	-	-	-					
e1-8				-	-	-	-	-					
e1-9	Sprechstelle E2R	9	Access	172	20	200	14	14	y	7,5		Redundanz E2	
e1-10	Sprechstelle PRM WC	9	Access	172	20	200	16	16	y	7,5			
e1-11	Sprechstelle PRM E2R	9	Access	172	20	200	15	15	y	7,5		Redundanz E2	
e1-12	Future use box E1	90	Access	-	-	-	-	-					
e1-13	Future use box E3	90	Access	-	-	-	-	-					
e1-14				-	-	-	-	-					
e1-15				-	-	-	-	-					
e2-0	Energiezähler E	12	Access	172	22	72	3	3					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

F1	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	72	124	124				
	e1-0	Überw. Kamera F7	5	Access	172	18	200	49	49	y	5,0		
	e1-1	Überw. Kamera F2	5	Access	172	18	200	50	50	y	5,0		
	e1-2	Überw. Kamera F1	5	Access	172	18	200	51	51	y	5,0		
	e1-3	Überw. Kamera F5	5	Access	172	18	200	52	52	y	5,0		
	e1-4	Überw. Kamera F9	5	Access	172	18	200	53	53	y	5,0		
	e1-5	AFZ F1	8	Access	172	20	72	25	25	y	10,0		
	e1-6	AFZ F2	8	Access	172	20	72	26	26	y	10,0		
	e1-7	AFZ F5	8	Access	172	20	72	27	27	y	10,0		
	e1-8	Sprechstelle F1	9	Access	172	20	200	17	17	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F5	90	Access	-	-	-	-	-				
	e1-13	Future use box F6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige F1	3	Access	172	17	200	41	41				
	e1-15	Seitenanzeige F3	3	Access	172	17	200	42	42				
	e2-0	Bildschirm F7	3	Access	172	17	200	88	88				
e2-1	Bildschirm F5	3	Access	172	17	200	89	89					
e2-2	Bildschirm F1	3	Access	172	17	200	90	90					
e2-3	Bildschirm F3	3	Access	172	17	200	91	91					
e2-4	Bildschirm F	3	Access	172	17	200	92	92					
e2-5	Audio Amp. F1	9	Access	172	20	200	29	29					
F2	e0-0	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera F8	5	Access	172	18	200	54	54	y	5,0		
	e1-1	Überw. Kamera F4	5	Access	172	18	200	55	55	y	5,0		
	e1-2	Überw. Kamera F3	5	Access	172	18	200	56	56	y	5,0		
	e1-3	Überw. Kamera F6	5	Access	172	18	200	57	57	y	5,0		
	e1-4	Überw. Kamera F10	5	Access	172	18	200	58	58	y	5,0		
	e1-5	AFZ F3	8	Access	172	20	72	28	28	y	10,0		
	e1-6	AFZ F4	8	Access	172	20	72	29	29	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle F2	9	Access	172	20	200	18	18	y	7,5		
	e1-9	Sprechstelle FIR	9	Access	172	20	200	17	17	y	7,5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F2	90	Access	-	-	-	-	-				
	e1-13	Future use box F4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige F2	3	Access	172	17	200	43	43				
	e1-15	Seitenanzeige F4	3	Access	172	17	200	44	44				
	e2-0	Bildschirm F8	3	Access	172	17	200	93	93				
e2-1	Bildschirm F6	3	Access	172	17	200	94	94					
e2-2	Bildschirm F2	3	Access	172	17	200	95	95					
e2-3	Bildschirm F	3	Access	172	17	200	96	96					
e2-4	Bildschirm F11	3	Access	172	17	200	97	97					
e2-5	Audio Amp. F2	9	Access	172	20	200	30	30					
F3	e0-0	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera F1	5	Access	172	18	200	88	88	y	5,0		
	e1-1	Rücksehkamera F2	5	Access	172	18	200	89	89	y	5,0		
	e1-2	Access point F4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle F2R	9	Access	172	20	200	18	18	y	7,5		Redundanz F2
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box F1	90	Access	-	-	-	-	-				
	e1-13	Future use box F3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	72	125	125				
	e1-0	Überw. Kamera B7	5	Access	172	18	200	59	59	y	5,0		
	e1-1	Überw. Kamera B2	5	Access	172	18	200	60	60	y	5,0		
	e1-2	Überw. Kamera B1	5	Access	172	18	200	61	61	y	5,0		
	e1-3	Überw. Kamera B5	5	Access	172	18	200	62	62	y	5,0		
	e1-4	Überw. Kamera B9	5	Access	172	18	200	63	63	y	5,0		
	e1-5	AFZ B1	8	Access	172	20	72	30	30	y	10,0		
	e1-6	AFZ B2	8	Access	172	20	72	31	31	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle B1	9	Access	172	20	200	19	19	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11	ZFR R	2	Access	172	17	72	2	2				
	e1-12	Future use box B5	90	Access	-	-	-	-	-				
	e1-13	Future use box B6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B1	3	Access	172	17	200	45	45				
	e1-15	Seitenanzeige B3	3	Access	172	17	200	46	46				
	e2-0	Bildschrim B7	3	Access	172	17	200	98	98				
	e2-1	Bildschrim B5	3	Access	172	17	200	99	99				
	e2-2	Bildschrim B1	3	Access	172	17	200	100	100				
e2-3	Bildschrim B3	3	Access	172	17	200	101	101					
e2-4	ADU B	9	Access	172	20	200	4	4					
e2-5	Audio Amp. B1	9	Access	172	20	200	31	31					
B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera B8	5	Access	172	18	200	64	64	y	5,0		
	e1-1	Überw. Kamera B4	5	Access	172	18	200	65	65	y	5,0		
	e1-2	Überw. Kamera B3	5	Access	172	18	200	66	66	y	5,0		
	e1-3	Überw. Kamera B6	5	Access	172	18	200	67	67	y	5,0		
	e1-4	Überw. Kamera B10	5	Access	172	18	200	68	68	y	5,0		
	e1-5	AFZ B3	8	Access	172	20	72	32	32	y	10,0		
	e1-6	AFZ B4	8	Access	172	20	72	33	33	y	10,0		
	e1-7	NVR B	5	Access	172	18	200	6	6				
	e1-8	Sprechstelle B2	9	Access	172	20	200	20	20	y	7,5		
	e1-9	Sprechstelle B1R	9	Access	172	20	200	19	19	y	7,5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box B2	90	Access	-	-	-	-	-				
	e1-13	Future use box B4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B2	3	Access	172	17	200	47	47				
	e1-15	Seitenanzeige B4	3	Access	172	17	200	48	48				
	e2-0	Bildschrim B8	3	Access	172	17	200	102	102				
	e2-1	Bildschrim B6	3	Access	172	17	200	103	103				
	e2-2	Bildschrim B2	3	Access	172	17	200	104	104				
e2-3	Bildschrim B4	3	Access	172	17	200	105	105					
e2-4				-	-	-	-	-					
e2-5	Audio Amp. B2	9	Access	172	20	200	32	32					
B3	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera B1	5	Access	172	18	200	90	90	y	5,0		
	e1-1	Rücksehkamera B2	5	Access	172	18	200	91	91	y	5,0		
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle B2R	9	Access	172	20	200	20	20	y	7,5		Redundanz B2
	e1-10				-	-	-	-	-				
	e1-11	ZFR	2	Access	172	17	72	2	2				
	e1-12	Future use box B1	90	Access	-	-	-	-	-				
	e1-13	Future use box B3	90	Access	-	-	-	-	-				
	e1-14	Frontanzeige B	3	Access	172	17	200	24	24				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
e2-3				-	-	-	-	-					
e2-4	ADU BR	9	Access	172	20	200	4	4					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					
Firewall		2	N/A	172	17	72	126	126				IP festgehalten fuer die RCU.	
		3	N/A	172	17	200	126	126				Diese ist mit der Firewall verbunden.	
		9	N/A	172	20	200	126	126				Anforderung von STADLER	