

IPv4-Schema
Fgz. Nr: 4736-019



Fahrzeugnummer: 4736-019				Fzg. ID: 147				Wagen:			A - 100		
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address			IPID	PoE	[W]	Beschriftung TS	Comment	
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	73	248	120				
	e1-0	Überw. Kamera A7	5	Access	172	18	201	138	10	y	5.0		
	e1-1	Überw. Kamera A2	5	Access	172	18	201	139	11	y	5.0		
	e1-2	Überw. Kamera A1	5	Access	172	18	201	140	12	y	5.0		
	e1-3	Überw. Kamera A5	5	Access	172	18	201	141	13	y	5.0		
	e1-4	Überw. Kamera A9	5	Access	172	18	201	142	14	y	5.0		
	e1-5	AFZ A1	8	Access	172	20	73	133	5	y	10.0		
	e1-6	AFZ A2	8	Access	172	20	73	134	6	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle A1	9	Access	172	20	201	133	5	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A5	90	Access	-	-	-	-	-				
	e1-13	Future use box A6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige A1	3	Access	172	17	201	153	25				
	e1-15	Seitenanzeige A3	3	Access	172	17	201	154	26				
	e2-0	Bildschirm A7	3	Access	172	17	201	178	50				
	e2-1	Bildschirm A5	3	Access	172	17	201	179	51				
	e2-2	Bildschirm A1	3	Access	172	17	201	180	52				
	e2-3	Bildschirm A3	3	Access	172	17	201	181	53				
e2-4	ADU A	9	Access	172	20	201	131	3					
e2-5	Audio Amp. A1	9	Access	172	20	201	149	21					
A2	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera A8	5	Access	172	18	201	143	15	y	5.0		
	e1-1	Überw. Kamera A4	5	Access	172	18	201	144	16	y	5.0		
	e1-2	Überw. Kamera A3	5	Access	172	18	201	145	17	y	5.0		
	e1-3	Überw. Kamera A6	5	Access	172	18	201	146	18	y	5.0		
	e1-4	Überw. Kamera A10	5	Access	172	18	201	147	19	y	5.0		
	e1-5	AFZ A3	8	Access	172	20	73	135	7	y	10.0		
	e1-6	AFZ A4	8	Access	172	20	73	136	8	y	10.0		
	e1-7	NVR A	5	Access	172	18	201	133	5				
	e1-8	Sprechstelle A2	9	Access	172	20	201	134	6	y	7.5		
	e1-9	Sprechstelle A1R	9	Access	172	20	201	133	5	y	7.5		Redundanz A1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box A2	90	Access	-	-	-	-	-				
	e1-13	Future use box A4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige A2	3	Access	172	17	201	155	27				
	e1-15	Seitenanzeige A4	3	Access	172	17	201	156	28				
	e2-0	Bildschirm A8	3	Access	172	17	201	182	54				
	e2-1	Bildschirm A6	3	Access	172	17	201	183	55				
	e2-2	Bildschirm A2	3	Access	172	17	201	184	56				
	e2-3	Bildschirm A4	3	Access	172	17	201	185	57				
	e2-4				-	-	-	-	-				
	e2-5	Audio Amp. A2	9	Access	172	20	201	150	22				
	A3	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
		e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
e0-2		Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
e0-3					-	-	-	-	-				
e0-4		Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
e0-5		reserved			-	-	-	-	-				
e1-0		Rücksehkamera A1	5	Access	172	18	201	208	80	y	5.0		
e1-1		Rücksehkamera A2	5	Access	172	18	201	209	81	y	5.0		
e1-2		Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
e1-3					-	-	-	-	-				
e1-4		Firewall	2	Trunk	172	17	73	129	1			Kein DHCP Statische Konfiguration STADLER	
			3		172	17	201	129					
			5		172	18	201	129					
			6		172	19	73	129					
			7		172	19	201	129					
			8		172	20	73	129					
			9		172	20	201	129					
e1-5			12		172	22	73	129					
e1-6					-	-	-	-	-				
e1-7					-	-	-	-	-				
e1-8					-	-	-	-	-				
e1-9		Sprechstelle A2R	9	Access	172	20	201	134	6	y	7.5		Redundanz A2
e1-10					-	-	-	-	-				
e1-11					-	-	-	-	-				
e1-12		Future use box A1	90	Access	-	-	-	-	-				
e1-13		Future use box A3	90	Access	-	-	-	-	-				
e1-14		Frontanzeige A	3	Access	172	17	201	151	23				
e1-15					-	-	-	-	-				
e2-0					-	-	-	-	-				
e2-1					-	-	-	-	-				
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4	ADU AR	9	Access	172	20	201	131	3					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					

C1	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	73	249	121				
	e1-0	Überw. Kamera C7	5	Access	172	18	201	148	20	y	5.0		
	e1-1	Überw. Kamera C2	5	Access	172	18	201	149	21	y	5.0		
	e1-2	Überw. Kamera C1	5	Access	172	18	201	150	22	y	5.0		
	e1-3	Überw. Kamera C5	5	Access	172	18	201	151	23	y	5.0		
	e1-4	Überw. Kamera C9	5	Access	172	18	201	152	24	y	5.0		
	e1-5	AFZ C1	8	Access	172	20	73	137	9	y	10.0		
	e1-6	AFZ C2	8	Access	172	20	73	138	10	y	10.0		
	e1-7	AFZ C5	8	Access	172	20	73	139	11	y	10.0		
	e1-8	Sprechstelle C1	9	Access	172	20	201	135	7	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C5	90	Access	-	-	-	-	-				
	e1-13	Future use box C6	90	Access	-	-	-	-	-				
e1-14	Seitenanzeige C1	3	Access	172	17	201	157	29					
e1-15	Seitenanzeige C3	3	Access	172	17	201	158	30					
e2-0	Bildschrim C7	3	Access	172	17	201	186	58					
e2-1	Bildschrim C5	3	Access	172	17	201	187	59					
e2-2	Bildschrim C1	3	Access	172	17	201	188	60					
e2-3	Bildschrim C3	3	Access	172	17	201	189	61					
e2-4	Bildschirm C	3	Access	172	17	201	190	62					
e2-5	Audio Amp. C1	9	Access	172	20	201	151	23					
C2	e0-0	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-	-			
	e1-0	Überw. Kamera C8	5	Access	172	18	201	153	25	y	5.0		
	e1-1	Überw. Kamera C4	5	Access	172	18	201	154	26	y	5.0		
	e1-2	Überw. Kamera C3	5	Access	172	18	201	155	27	y	5.0		
	e1-3	Überw. Kamera C6	5	Access	172	18	201	156	28	y	5.0		
	e1-4	Überw. Kamera C10	5	Access	172	18	201	157	29	y	5.0		
	e1-5	AFZ C3	8	Access	172	20	73	140	12	y	10.0		
	e1-6	AFZ C4	8	Access	172	20	73	141	13	y	10.0		
	e1-7				-	-	-	-	-	-			
	e1-8	Sprechstelle C2	9	Access	172	20	201	136	8	y	7.5		
	e1-9	Sprechstelle C1R	9	Access	172	20	201	135	7	y	7.5		
	e1-10				-	-	-	-	-	-			
	e1-11				-	-	-	-	-	-			
	e1-12	Future use box C2	90	Access	-	-	-	-	-	-			
	e1-13	Future use box C4	90	Access	-	-	-	-	-	-			
e1-14	Seitenanzeige C2	3	Access	172	17	201	159	31					
e1-15	Seitenanzeige C4	3	Access	172	17	201	160	32					
e2-0	Bildschrim C8	3	Access	172	17	201	191	63					
e2-1	Bildschrim C6	3	Access	172	17	201	192	64					
e2-2	Bildschrim C2	3	Access	172	17	201	193	65					
e2-3	Bildschrim C4	3	Access	172	17	201	194	66					
e2-4	Bildschrim C11	3	Access	172	17	201	195	67					
e2-5	Audio Amp. C2	9	Access	172	20	201	152	24					
C3	e0-0	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-1	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-	-			
	e0-2				-	-	-	-	-	-			
	e0-3				-	-	-	-	-	-			
	e0-4	Access point C3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-	-			
	e1-0	Rücksehkamera C1	5	Access	172	18	201	210	82	y	5.0		
	e1-1	Rücksehkamera C2	5	Access	172	18	201	211	83	y	5.0		
	e1-2	Access point C4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-	-			
	e1-4				-	-	-	-	-	-			
	e1-5				-	-	-	-	-	-			
	e1-6				-	-	-	-	-	-			
	e1-7				-	-	-	-	-	-			
	e1-8				-	-	-	-	-	-			
	e1-9	Sprechstelle C2R	9	Access	172	20	201	136	8	y	7.5		Redundanz C2
	e1-10				-	-	-	-	-	-			
	e1-11				-	-	-	-	-	-			
	e1-12	Future use box C1	90	Access	-	-	-	-	-	-			
	e1-13	Future use box C3	90	Access	-	-	-	-	-	-			
e1-14				-	-	-	-	-	-				
e1-15				-	-	-	-	-	-				
e2-0				-	-	-	-	-	-				
e2-1				-	-	-	-	-	-				
e2-2				-	-	-	-	-	-				
e2-3				-	-	-	-	-	-				
e2-4				-	-	-	-	-	-				
e2-5				-	-	-	-	-	-				

IPv4-Schema

Fgz. Nr: 4736-019

D1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					172	19	201	130	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	73	250	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	201	158	30	y	5.0		
	e1-1	Überw. Kamera D2	5	Access	172	18	201	159	31	y	5.0		
	e1-2	Überw. Kamera D1	5	Access	172	18	201	160	32	y	5.0		
	e1-3	Überw. Kamera D5	5	Access	172	18	201	161	33	y	5.0		
	e1-4	Überw. Kamera D9	5	Access	172	18	201	162	34	y	5.0		
	e1-5	AFZ D1	8	Access	172	20	73	142	14	y	10.0		
	e1-6	AFZ D2	8	Access	172	20	73	143	15	y	10.0		
	e1-7	AFZ D5	8	Access	172	20	73	144	16	y	10.0		
	e1-8	Sprechstelle D1	9	Access	172	20	201	138	10	y	7.5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
	e1-13	Future use box D6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D1	3	Access	172	17	201	161	33				
	e1-15	Seitenanzeige D3	3	Access	172	17	201	162	34				
D2	e2-0	Bildschirm D7	3	Access	172	17	201	196	68				
	e2-1	Bildschirm D5	3	Access	172	17	201	197	69				
	e2-2	Bildschirm D1	3	Access	172	17	201	198	70				
	e2-3	Bildschirm D3	3	Access	172	17	201	199	71				
	e2-4	Bildschirm D	3	Access	172	17	201	200	72				
	e2-5	Audio Amp. D1	9	Access	172	20	201	153	25				
	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	201	163	35	y	5.0		
	e1-1	Überw. Kamera D4	5	Access	172	18	201	164	36	y	5.0		
	e1-2	Überw. Kamera D3	5	Access	172	18	201	165	37	y	5.0		
	e1-3	Überw. Kamera D6	5	Access	172	18	201	166	38	y	5.0		
	e1-4	Überw. Kamera D10	5	Access	172	18	201	167	39	y	5.0		
	e1-5	AFZ D3	8	Access	172	20	73	145	17	y	10.0		
	e1-6	AFZ D4	8	Access	172	20	73	146	18	y	10.0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	201	139	11	y	7.5		
	e1-9	Sprechstelle D1R	9	Access	172	20	201	138	10	y	7.5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige D2	3	Access	172	17	201	163	35				
	e1-15	Seitenanzeige D4	3	Access	172	17	201	164	36				
D3	e2-0	Bildschirm D8	3	Access	172	17	201	201	73				
	e2-1	Bildschirm D6	3	Access	172	17	201	202	74				
	e2-2	Bildschirm D2	3	Access	172	17	201	203	75				
	e2-3	Bildschirm D4	3	Access	172	17	201	204	76				
	e2-4	Bildschirm D11	3	Access	172	17	201	205	77				
	e2-5	Audio Amp. D2	9	Access	172	20	201	154	26				
	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					172	19	201	130	2				
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	201	212	84	y	5.0		
	e1-1	Rücksehkamera D2	5	Access	172	18	201	213	85	y	5.0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	201	139	11	y	7.5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
	e1-13	Future use box D3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
	e2-3				-	-	-	-	-				
	e2-4				-	-	-	-	-				
	e2-5				-	-	-	-	-				

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	73	251	123				
	e1-0	Überw. Kamera E7	5	Access	172	18	201	168	40	y	5.0		
	e1-1	Überw. Kamera E2	5	Access	172	18	201	169	41	y	5.0		
	e1-2	Überw. Kamera E1	5	Access	172	18	201	170	42	y	5.0		
	e1-3	Überw. Kamera E5	5	Access	172	18	201	171	43	y	5.0		
	e1-4	Überw. Kamera E9	5	Access	172	18	201	172	44	y	5.0		
	e1-5	AFZ E1	8	Access	172	20	73	147	19	y	10.0		
	e1-6	AFZ E2	8	Access	172	20	73	148	20	y	10.0		
	e1-7	AFZ E5	8	Access	172	20	73	149	21	y	10.0		
	e1-8	Sprechstelle E1	9	Access	172	20	201	140	12	y	7.5		
	e1-9					-	-	-	-	-			
	e1-10	Sprechstelle PRM E1	9	Access	172	20	201	141	13	y	7.5		
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	201	144	16	y	7.5		Redundanz WC
	e1-12	Future use box E5	90	Access		-	-	-	-	-			
	e1-13	Future use box E7	90	Access		-	-	-	-	-			
	e1-14	Seitenanzeige E1	3	Access	172	17	201	165	37				
	e1-15	Seitenanzeige E3	3	Access	172	17	201	166	38				
	e2-0	Bildschirm E7	3	Access	172	17	201	206	78				
	e2-1	Bildschirm E5	3	Access	172	17	201	207	79				
	e2-2	Bildschirm E1	3	Access	172	17	201	208	80				
	e2-3	Bildschirm E3	3	Access	172	17	201	209	81				
	e2-4	Bildschirm E	3	Access	172	17	201	210	82				
e2-5	Audio Amp. E1	9	Access	172	20	201	155	27					
E2	e0-0	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E2 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5				-	-	-	-	-				
	e1-0	Überw. Kamera E8	5	Access	172	18	201	173	45	y	5.0		
	e1-1	Überw. Kamera E4	5	Access	172	18	201	174	46	y	5.0		
	e1-2	Überw. Kamera E3	5	Access	172	18	201	175	47	y	5.0		
	e1-3	Überw. Kamera E6	5	Access	172	18	201	176	48	y	5.0		
	e1-4				-	-	-	-	-				
	e1-5	AFZ E3	8	Access	172	20	73	150	22	y	10.0		
	e1-6	AFZ E4	8	Access	172	20	73	151	23	y	10.0		
	e1-7	AFZ E6	8	Access	172	20	73	152	24	y	10.0		
	e1-8	Sprechstelle E2	9	Access	172	20	201	142	14	y	7.5		
	e1-9	Sprechstelle E1R	9	Access	172	20	201	140	12	y	7.5		Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	201	143	15	y	7.5		
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	201	141	13	y	7.5		Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-				
	e1-13	Future use box E4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E2	3	Access	172	17	201	167	39				
	e1-15	Seitenanzeige E4	3	Access	172	17	201	168	40				
	e2-0	Bildschirm E8	3	Access	172	17	201	211	83				
	e2-1	Bildschirm E6	3	Access	172	17	201	212	84				
	e2-2	Bildschirm E2	3	Access	172	17	201	213	85				
	e2-3	Bildschirm E4	3	Access	172	17	201	214	86				
	e2-4	Bildschirm E11	3	Access	172	17	201	215	87				
e2-5	Audio Amp. E2	9	Access	172	20	201	156	28					
E3	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E3 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5				-	-	-	-	-				
	e1-0	Rücksehkamera E1	5	Access	172	18	201	214	86	y	5.0		
	e1-1	Rücksehkamera E2	5	Access	172	18	201	215	87	y	5.0		
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle E2R	9	Access	172	20	201	142	14	y	7.5		Redundanz E2
	e1-10	Sprechstelle PRM WC	9	Access	172	20	201	144	16	y	7.5		
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	201	143	15	y	7.5		Redundanz E2
	e1-12	Future use box E1	90	Access	-	-	-	-	-				
	e1-13	Future use box E3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0	Energiezähler E	12	Access	172	22	73	131	3				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
	e2-3				-	-	-	-	-				
	e2-4				-	-	-	-	-				
e2-5				-	-	-	-	-					

F1	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5	Service FIS / CCTV	2	Access	172	17	73	252	124				
	e1-0	Überw. Kamera F7	5	Access	172	18	201	177	49	y	5.0		
	e1-1	Überw. Kamera F2	5	Access	172	18	201	178	50	y	5.0		
	e1-2	Überw. Kamera F1	5	Access	172	18	201	179	51	y	5.0		
	e1-3	Überw. Kamera F5	5	Access	172	18	201	180	52	y	5.0		
	e1-4	Überw. Kamera F9	5	Access	172	18	201	181	53	y	5.0		
	e1-5	AFZ F1	8	Access	172	20	73	153	25	y	10.0		
	e1-6	AFZ F2	8	Access	172	20	73	154	26	y	10.0		
	e1-7	AFZ F5	8	Access	172	20	73	155	27	y	10.0		
	e1-8	Sprechstelle F1	9	Access	172	20	201	145	17	y	7.5		
	e1-9					-	-	-	-	-			
	e1-10					-	-	-	-	-			
	e1-11					-	-	-	-	-			
	e1-12	Future use box F5	90	Access		-	-	-	-	-			
	e1-13	Future use box F6	90	Access		-	-	-	-	-			
e1-14	Seitenanzeige F1	3	Access	172	17	201	169	41					
e1-15	Seitenanzeige F3	3	Access	172	17	201	170	42					
F2	e2-0	Bildschirm F7	3	Access	172	17	201	216	88				
	e2-1	Bildschirm F5	3	Access	172	17	201	217	89				
	e2-2	Bildschirm F1	3	Access	172	17	201	218	90				
	e2-3	Bildschirm F3	3	Access	172	17	201	219	91				
	e2-4	Bildschirm F	3	Access	172	17	201	220	92				
	e2-5	Audio Amp. F1	9	Access	172	20	201	157	29				
	e0-0	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F2 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5				-	-	-	-	-				
	e1-0	Überw. Kamera F8	5	Access	172	18	201	182	54	y	5.0		
	e1-1	Überw. Kamera F4	5	Access	172	18	201	183	55	y	5.0		
	e1-2	Überw. Kamera F3	5	Access	172	18	201	184	56	y	5.0		
	e1-3	Überw. Kamera F6	5	Access	172	18	201	185	57	y	5.0		
	e1-4	Überw. Kamera F10	5	Access	172	18	201	186	58	y	5.0		
	e1-5	AFZ F3	8	Access	172	20	73	156	28	y	10.0		
	e1-6	AFZ F4	8	Access	172	20	73	157	29	y	10.0		
	e1-7				-	-	-	-	-				
e1-8	Sprechstelle F2	9	Access	172	20	201	146	18	y	7.5			
e1-9	Sprechstelle FIR	9	Access	172	20	201	145	17	y	7.5			
e1-10				-	-	-	-	-					
e1-11				-	-	-	-	-					
e1-12	Future use box F2	90	Access	-	-	-	-	-					
e1-13	Future use box F4	90	Access	-	-	-	-	-					
e1-14	Seitenanzeige F2	3	Access	172	17	201	171	43					
e1-15	Seitenanzeige F4	3	Access	172	17	201	172	44					
F3	e2-0	Bildschirm F8	3	Access	172	17	201	221	93				
	e2-1	Bildschirm F6	3	Access	172	17	201	222	94				
	e2-2	Bildschirm F2	3	Access	172	17	201	223	95				
	e2-3	Bildschirm F	3	Access	172	17	201	224	96				
	e2-4	Bildschirm F11	3	Access	172	17	201	225	97				
	e2-5	Audio Amp. F2	9	Access	172	20	201	158	30				
	e0-0	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point F3 reserved	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e0-5				-	-	-	-	-				
	e1-0	Rücksehkamera F1	5	Access	172	18	201	216	88	y	5.0		
	e1-1	Rücksehkamera F2	5	Access	172	18	201	217	89	y	5.0		
	e1-2	Access point F4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
e1-8				-	-	-	-	-					
e1-9	Sprechstelle F2R	9	Access	172	20	201	146	18	y	7.5		Redundanz F2	
e1-10				-	-	-	-	-					
e1-11				-	-	-	-	-					
e1-12	Future use box F1	90	Access	-	-	-	-	-					
e1-13	Future use box F3	90	Access	-	-	-	-	-					
e1-14				-	-	-	-	-					
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0	
	e0-5	Service FIS / CCTV	2	Access	172	17	73	253	125			
	e1-0	Überw. Kamera B7	5	Access	172	18	201	187	59	y	5.0	
	e1-1	Überw. Kamera B2	5	Access	172	18	201	188	60	y	5.0	
	e1-2	Überw. Kamera B1	5	Access	172	18	201	189	61	y	5.0	
	e1-3	Überw. Kamera B5	5	Access	172	18	201	190	62	y	5.0	
	e1-4	Überw. Kamera B9	5	Access	172	18	201	191	63	y	5.0	
	e1-5	AFZ B1	8	Access	172	20	73	158	30	y	10.0	
	e1-6	AFZ B2	8	Access	172	20	73	159	31	y	10.0	
	e1-7				-	-	-	-	-			
	e1-8	Sprechstelle B1	9	Access	172	20	201	147	19	y	7.5	
	e1-9				-	-	-	-	-			
	e1-10				-	-	-	-	-			
	e1-11	ZFR R	2	Access	172	17	73	130	2			
	e1-12	Future use box B5	90	Access	-	-	-	-	-			
	e1-13	Future use box B6	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige B1	3	Access	172	17	201	173	45			
	e1-15	Seitenanzeige B3	3	Access	172	17	201	174	46			
	e2-0	Bildschrim B7	3	Access	172	17	201	226	98			
	e2-1	Bildschrim B5	3	Access	172	17	201	227	99			
	e2-2	Bildschrim B1	3	Access	172	17	201	228	100			
e2-3	Bildschrim B3	3	Access	172	17	201	229	101				
e2-4	ADU B	9	Access	172	20	201	132	4				
e2-5	Audio Amp. B1	9	Access	172	20	201	159	31				
B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2				-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0	
	e0-5	reserved			-	-	-	-	-			
	e1-0	Überw. Kamera B8	5	Access	172	18	201	192	64	y	5.0	
	e1-1	Überw. Kamera B4	5	Access	172	18	201	193	65	y	5.0	
	e1-2	Überw. Kamera B3	5	Access	172	18	201	194	66	y	5.0	
	e1-3	Überw. Kamera B6	5	Access	172	18	201	195	67	y	5.0	
	e1-4	Überw. Kamera B10	5	Access	172	18	201	196	68	y	5.0	
	e1-5	AFZ B3	8	Access	172	20	73	160	32	y	10.0	
	e1-6	AFZ B4	8	Access	172	20	73	161	33	y	10.0	
	e1-7	NVR B	5	Access	172	18	201	134	6			
	e1-8	Sprechstelle B2	9	Access	172	20	201	148	20	y	7.5	
	e1-9	Sprechstelle B1R	9	Access	172	20	201	147	19	y	7.5	
	e1-10				-	-	-	-	-			
	e1-11				-	-	-	-	-			
	e1-12	Future use box B2	90	Access	-	-	-	-	-			
	e1-13	Future use box B4	90	Access	-	-	-	-	-			
	e1-14	Seitenanzeige B2	3	Access	172	17	201	175	47			
	e1-15	Seitenanzeige B4	3	Access	172	17	201	176	48			
	e2-0	Bildschrim B8	3	Access	172	17	201	230	102			
	e2-1	Bildschrim B6	3	Access	172	17	201	231	103			
	e2-2	Bildschrim B2	3	Access	172	17	201	232	104			
e2-3	Bildschrim B4	3	Access	172	17	201	233	105				
e2-4				-	-	-	-	-				
e2-5	Audio Amp. B2	9	Access	172	20	201	160	32				
B3	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-			
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-			
	e0-3				-	-	-	-	-			
	e0-4	Access point B3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0	
	e0-5	reserved			-	-	-	-	-			
	e1-0	Rücksehkamera B1	5	Access	172	18	201	218	90	y	5.0	
	e1-1	Rücksehkamera B2	5	Access	172	18	201	219	91	y	5.0	
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18.0	
	e1-3				-	-	-	-	-			
	e1-4				-	-	-	-	-			
	e1-5				-	-	-	-	-			
	e1-6				-	-	-	-	-			
	e1-7				-	-	-	-	-			
	e1-8				-	-	-	-	-			
	e1-9	Sprechstelle B2R	9	Access	172	20	201	148	20	y	7.5	Redundanz B2
	e1-10				-	-	-	-	-			
	e1-11	ZFR	2	Access	172	17	73	130	2			
	e1-12	Future use box B1	90	Access	-	-	-	-	-			
	e1-13	Future use box B3	90	Access	-	-	-	-	-			
	e1-14	Frontanzeige B	3	Access	172	17	201	152	24			
	e1-15				-	-	-	-	-			
	e2-0				-	-	-	-	-			
	e2-1				-	-	-	-	-			
	e2-2				-	-	-	-	-			
e2-3				-	-	-	-	-				
e2-4	ADU BR	9	Access	172	20	201	132	4				
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127				
Firewall		2	N/A	172	17	73	254	126			IP festgehalten fuer die RCU.	
		3	N/A	172	17	201	254	126			Diese ist mit der Firewall verbunden.	
		9	N/A	172	20	201	254	126			Anforderung von STADLER	