

Fahrzeugnummer: 4736-124				Fzg. ID: 252				Wagen: A - 100			
Switch	Switchport	Usage	VLAN ID	Port Type	IP Address		IPID	PoE	[W]	Beschreibung TS	Comment
A1	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-1	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-2	Frontkupplung A1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-			
	e0-3				-	-	-	-			
	e0-4	Access point A1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18,0	
	e0-5	Service FIS / CCTV	2	Access	172	17	126	120	120		
	e1-0	Überw. Kamera A7	5	Access	172	18	254	10	10	y	5,0
	e1-1	Überw. Kamera A2	5	Access	172	18	254	11	11	y	5,0
	e1-2	Überw. Kamera A1	5	Access	172	18	254	12	12	y	5,0
	e1-3	Überw. Kamera A5	5	Access	172	18	254	13	13	y	5,0
	e1-4	Überw. Kamera A9	5	Access	172	18	254	14	14	y	5,0
	e1-5	AFZ A1	8	Access	172	20	126	5	5	y	10,0
	e1-6	AFZ A2	8	Access	172	20	126	6	6	y	10,0
	e1-7				-	-	-	-			
	e1-8	Sprechstelle A1	9	Access	172	20	254	5	5	y	7,5
	e1-9				-	-	-	-			
	e1-10				-	-	-	-			
	e1-11				-	-	-	-			
	e1-12	Future use box A5	90	Access	-	-	-	-			
	e1-13	Future use box A6	90	Access	-	-	-	-			
	e1-14	Seitenanzeige A1	3	Access	172	17	254	25	25		
	e1-15	Seitenanzeige A3	3	Access	172	17	254	26	26		
	e2-0	Bildschirm A7	3	Access	172	17	254	50	50		
	e2-1	Bildschirm A5	3	Access	172	17	254	51	51		
	e2-2	Bildschirm A1	3	Access	172	17	254	52	52		
A2	e2-3	Bildschirm A3	3	Access	172	17	254	53	53		
	e2-4	ADU A	9	Access	172	20	254	3	3		
	e2-5	Audio Amp. A1	9	Access	172	20	254	21	21		
	e0-0	FIS Switch A3	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-1	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-2				-	-	-	-			
	e0-3				-	-	-	-			
	e0-4	Access point A2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18,0	
	e0-5	reserved			-	-	-	-			
	e1-0	Überw. Kamera A8	5	Access	172	18	254	15	15	y	5,0
	e1-1	Überw. Kamera A4	5	Access	172	18	254	16	16	y	5,0
	e1-2	Überw. Kamera A3	5	Access	172	18	254	17	17	y	5,0
	e1-3	Überw. Kamera A6	5	Access	172	18	254	18	18	y	5,0
	e1-4	Überw. Kamera A10	5	Access	172	18	254	19	19	y	5,0
	e1-5	AFZ A3	8	Access	172	20	126	7	7	y	10,0
	e1-6	AFZ A4	8	Access	172	20	126	8	8	y	10,0
	e1-7	NVR A	5	Access	172	18	254	5	5		
	e1-8	Sprechstelle A2	9	Access	172	20	254	6	6	y	7,5
	e1-9	Sprechstelle A1R	9	Access	172	20	254	5	5	y	7,5
	e1-10				-	-	-	-			Redundanz A1
	e1-11				-	-	-	-			
	e1-12	Future use box A2	90	Access	-	-	-	-			
	e1-13	Future use box A4	90	Access	-	-	-	-			
	e1-14	Seitenanzeige A2	3	Access	172	17	254	27	27		
	e1-15	Seitenanzeige A4	3	Access	172	17	254	28	28		
A3	e2-0	Bildschirm A8	3	Access	172	17	254	54	54		
	e2-1	Bildschirm A6	3	Access	172	17	254	55	55		
	e2-2	Bildschirm A2	3	Access	172	17	254	56	56		
	e2-3	Bildschirm A4	3	Access	172	17	254	57	57		
	e2-4				-	-	-	-			
	e2-5	Audio Amp. A2	9	Access	172	20	254	22	22		
	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-1	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-			
	e0-2	Frontkupplung A2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-			
	e0-3				-	-	-	-			
	e0-4	Access point A3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18,0	
	e0-5	reserved			-	-	-	-			
	e1-0	Rücksehkamera A1	5	Access	172	18	254	80	80	y	5,0
	e1-1	Rücksehkamera A2	5	Access	172	18	254	81	81	y	5,0
	e1-2	Access point A4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	y	18,0	
	e1-3				-	-	-	-			
	e1-4	Firewall	2	Trunk	172	17	126	1	1		Kein DHCP Statische Konfiguration STADLER
			3		172	17	254	1			
			5		172	18	254	1			
			6		172	19	126	1			
			7		172	19	254	1			
			8		172	20	126	1			
			9		172	20	254	1			
			12		172	22	126	1			
	e1-5				-	-	-	-			
	e1-6				-	-	-	-			
	e1-7				-	-	-	-			
	e1-8				-	-	-	-			
	e1-9	Sprechstelle A2R	9	Access	172	20	254	6	6	y	7,5
	e1-10				-	-	-	-			Redundanz A2
	e1-11				-	-	-	-			
	e1-12	Future use box A1	90	Access	-	-	-	-			
	e1-13	Future use box A3	90	Access	-	-	-	-			
	e1-14	Frontanzeige A	3	Access	172	17	254	23	23		
	e1-15				-	-	-	-			
	e2-0				-	-	-	-			
	e2-1				-	-	-	-			
	e2-2				-	-	-	-			
	e2-3				-	-	-	-			
	e2-4	ADU AR	9	Access	172	20	254	3	3		
	e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127		

C1	e0-0	FIS Switch A1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point C1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	126	121	121				
	e1-0	Überw. Kamera C7	5	Access	172	18	254	20	20	y	5,0		
	e1-1	Überw. Kamera C2	5	Access	172	18	254	21	21	y	5,0		
	e1-2	Überw. Kamera C1	5	Access	172	18	254	22	22	y	5,0		
	e1-3	Überw. Kamera C5	5	Access	172	18	254	23	23	y	5,0		
	e1-4	Überw. Kamera C9	5	Access	172	18	254	24	24	y	5,0		
	e1-5	AFZ C1	8	Access	172	20	126	9	9	y	10,0		
	e1-6	AFZ C2	8	Access	172	20	126	10	10	y	10,0		
	e1-7	AFZ C5	8	Access	172	20	126	11	11	y	10,0		
	e1-8	Sprechstelle C1	9	Access	172	20	254	7	7	y	7,5		
	e1-9					-	-	-	-	-			
	e1-10					-	-	-	-	-			
	e1-11					-	-	-	-	-			
	e1-12	Future use box C5	90	Access		-	-	-	-	-			
	e1-13	Future use box C6	90	Access		-	-	-	-	-			
	e1-14	Seitenanzeige C1	3	Access	172	17	254	29	29				
	e1-15	Seitenanzeige C3	3	Access	172	17	254	30	30				
	e2-0	Bildschirm C7	3	Access	172	17	254	58	58				
e2-1	Bildschirm C5	3	Access	172	17	254	59	59					
e2-2	Bildschirm C1	3	Access	172	17	254	60	60					
e2-3	Bildschirm C3	3	Access	172	17	254	61	61					
e2-4	Bildschirm C	3	Access	172	17	254	62	62					
e2-5	Audio Amp. C1	9	Access	172	20	254	23	23					
C2	e0-0	FIS Switch C3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point C2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera C8	5	Access	172	18	254	25	25	y	5,0		
	e1-1	Überw. Kamera C4	5	Access	172	18	254	26	26	y	5,0		
	e1-2	Überw. Kamera C3	5	Access	172	18	254	27	27	y	5,0		
	e1-3	Überw. Kamera C6	5	Access	172	18	254	28	28	y	5,0		
	e1-4	Überw. Kamera C10	5	Access	172	18	254	29	29	y	5,0		
	e1-5	AFZ C3	8	Access	172	20	126	12	12	y	10,0		
	e1-6	AFZ C4	8	Access	172	20	126	13	13	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle C2	9	Access	172	20	254	8	8	y	7,5		
	e1-9	Sprechstelle C1R	9	Access	172	20	254	7	7	y	7,5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C2	90	Access	-	-	-	-	-				
	e1-13	Future use box C4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige C2	3	Access	172	17	254	31	31				
	e1-15	Seitenanzeige C4	3	Access	172	17	254	32	32				
	e2-0	Bildschirm C8	3	Access	172	17	254	63	63				
e2-1	Bildschirm C6	3	Access	172	17	254	64	64					
e2-2	Bildschirm C2	3	Access	172	17	254	65	65					
e2-3	Bildschirm C4	3	Access	172	17	254	66	66					
e2-4	Bildschirm C11	3	Access	172	17	254	67	67					
e2-5	Audio Amp. C2	9	Access	172	20	254	24	24					
C3	e0-0	FIS Switch A2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point C3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera C1	5	Access	172	18	254	82	82	y	5,0		
	e1-1	Rücksehkamera C2	5	Access	172	18	254	83	83	y	5,0		
	e1-2	Access point C4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle C2R	9	Access	172	20	254	8	8	y	7,5		Redundanz C2
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box C1	90	Access	-	-	-	-	-				
	e1-13	Future use box C3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

D1	e0-0	FIS Switch C1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	254	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	126	122	122				
	e1-0	Überw. Kamera D7	5	Access	172	18	254	30	30	y	5,0		
	e1-1	Überw. Kamera D2	5	Access	172	18	254	31	31	y	5,0		
	e1-2	Überw. Kamera D1	5	Access	172	18	254	32	32	y	5,0		
	e1-3	Überw. Kamera D5	5	Access	172	18	254	33	33	y	5,0		
	e1-4	Überw. Kamera D9	5	Access	172	18	254	34	34	y	5,0		
	e1-5	AFZ D1	8	Access	172	20	126	14	14	y	10,0		
	e1-6	AFZ D2	8	Access	172	20	126	15	15	y	10,0		
	e1-7	AFZ D5	8	Access	172	20	126	16	16	y	10,0		
	e1-8	Sprechstelle D1	9	Access	172	20	254	10	10	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D5	90	Access	-	-	-	-	-				
e1-13	Future use box D6	90	Access	-	-	-	-	-					
e1-14	Seitenanzeige D1	3	Access	172	17	254	33	33					
e1-15	Seitenanzeige D3	3	Access	172	17	254	34	34					
e2-0	Bildschirm D7	3	Access	172	17	254	68	68					
e2-1	Bildschirm D5	3	Access	172	17	254	69	69					
e2-2	Bildschirm D1	3	Access	172	17	254	70	70					
e2-3	Bildschirm D3	3	Access	172	17	254	71	71					
e2-4	Bildschirm D	3	Access	172	17	254	72	72					
e2-5	Audio Amp. D1	9	Access	172	20	254	25	25					
D2	e0-0	FIS Switch D3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS Reserve D2			-	-	-	-	-				
	e0-3	RDC Reserve D2			-	-	-	-	-				
	e0-4	Access point D2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera D8	5	Access	172	18	254	35	35	y	5,0		
	e1-1	Überw. Kamera D4	5	Access	172	18	254	36	36	y	5,0		
	e1-2	Überw. Kamera D3	5	Access	172	18	254	37	37	y	5,0		
	e1-3	Überw. Kamera D6	5	Access	172	18	254	38	38	y	5,0		
	e1-4	Überw. Kamera D10	5	Access	172	18	254	39	39	y	5,0		
	e1-5	AFZ D3	8	Access	172	20	126	17	17	y	10,0		
	e1-6	AFZ D4	8	Access	172	20	126	18	18	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle D2	9	Access	172	20	254	11	11	y	7,5		
	e1-9	Sprechstelle D1R	9	Access	172	20	254	10	10	y	7,5		Redundanz D1
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box D2	90	Access	-	-	-	-	-				
	e1-13	Future use box D4	90	Access	-	-	-	-	-				
e1-14	Seitenanzeige D2	3	Access	172	17	254	35	35					
e1-15	Seitenanzeige D4	3	Access	172	17	254	36	36					
e2-0	Bildschirm D8	3	Access	172	17	254	73	73					
e2-1	Bildschirm D6	3	Access	172	17	254	74	74					
e2-2	Bildschirm D2	3	Access	172	17	254	75	75					
e2-3	Bildschirm D4	3	Access	172	17	254	76	76					
e2-4	Bildschirm D11	3	Access	172	17	254	77	77					
e2-5	Audio Amp. D2	9	Access	172	20	254	26	26					
D3	e0-0	FIS Switch C2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	OBS D1	100, 10, 20, 21, 22, 23, 24, 30, 31, 46, 48, 90, 131, 150, 200, 202	Trunk	-	-	-	-	-				
					7	172	19	254	2	2			
	e0-3	RDC D1	200, 202	Trunk	-	-	-	-	-				
	e0-4	Access point D3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera D1	5	Access	172	18	254	84	84	y	5,0		
	e1-1	Rücksehkamera D2	5	Access	172	18	254	85	85	y	5,0		
	e1-2	Access point D4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle D2R	9	Access	172	20	254	11	11	y	7,5		Redundanz D2
	e1-10	OBS Reserve D2			-	-	-	-	-				
	e1-11	RDC Reserve D2			-	-	-	-	-				
	e1-12	Future use box D1	90	Access	-	-	-	-	-				
e1-13	Future use box D3	90	Access	-	-	-	-	-					
e1-14				-	-	-	-	-					
e1-15				-	-	-	-	-					
e2-0				-	-	-	-	-					
e2-1				-	-	-	-	-					
e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

E1	e0-0	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	126	123	123				
	e1-0	Überw. Kamera E7	5	Access	172	18	254	40	40	y	5,0		
	e1-1	Überw. Kamera E2	5	Access	172	18	254	41	41	y	5,0		
	e1-2	Überw. Kamera E1	5	Access	172	18	254	42	42	y	5,0		
	e1-3	Überw. Kamera E5	5	Access	172	18	254	43	43	y	5,0		
	e1-4	Überw. Kamera E9	5	Access	172	18	254	44	44	y	5,0		
	e1-5	AFZ E1	8	Access	172	20	126	19	19	y	10,0		
	e1-6	AFZ E2	8	Access	172	20	126	20	20	y	10,0		
	e1-7	AFZ E5	8	Access	172	20	126	21	21	y	10,0		
	e1-8	Sprechstelle E1	9	Access	172	20	254	12	12	y	7,5		
	e1-9					-	-	-	-				
	e1-10	Sprechstelle PRM E1	9	Access	172	20	254	13	13	y	7,5		
	e1-11	Sprechstelle PRM WCR	9	Access	172	20	254	16	16	y	7,5		Redundanz WC
	e1-12	Future use box E5	90	Access	-	-	-	-	-				
	e1-13	Future use box E7	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E1	3	Access	172	17	254	37	37				
	e1-15	Seitenanzeige E3	3	Access	172	17	254	38	38				
	e2-0	Bildschirm E7	3	Access	172	17	254	78	78				
	e2-1	Bildschirm E5	3	Access	172	17	254	79	79				
	e2-2	Bildschirm E1	3	Access	172	17	254	80	80				
e2-3	Bildschirm E3	3	Access	172	17	254	81	81					
e2-4	Bildschirm E	3	Access	172	17	254	82	82					
e2-5	Audio Amp. E1	9	Access	172	20	254	27	27					
E2	e0-0	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch D1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera E8	5	Access	172	18	254	45	45	y	5,0		
	e1-1	Überw. Kamera E4	5	Access	172	18	254	46	46	y	5,0		
	e1-2	Überw. Kamera E3	5	Access	172	18	254	47	47	y	5,0		
	e1-3	Überw. Kamera E6	5	Access	172	18	254	48	48	y	5,0		
	e1-4				-	-	-	-	-				
	e1-5	AFZ E3	8	Access	172	20	126	22	22	y	10,0		
	e1-6	AFZ E4	8	Access	172	20	126	23	23	y	10,0		
	e1-7	AFZ E6	8	Access	172	20	126	24	24	y	10,0		
	e1-8	Sprechstelle E2	9	Access	172	20	254	14	14	y	7,5		
	e1-9	Sprechstelle E1R	9	Access	172	20	254	12	12	y	7,5		Redundanz E1
	e1-10	Sprechstelle PRM E2	9	Access	172	20	254	15	15	y	7,5		
	e1-11	Sprechstelle PRM E1R	9	Access	172	20	254	13	13	y	7,5		Redundanz E1
	e1-12	Future use box E2	90	Access	-	-	-	-	-				
	e1-13	Future use box E4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige E2	3	Access	172	17	254	39	39				
	e1-15	Seitenanzeige E4	3	Access	172	17	254	40	40				
	e2-0	Bildschirm E8	3	Access	172	17	254	83	83				
	e2-1	Bildschirm E6	3	Access	172	17	254	84	84				
	e2-2	Bildschirm E2	3	Access	172	17	254	85	85				
e2-3	Bildschirm E4	3	Access	172	17	254	86	86					
e2-4	Bildschirm E11	3	Access	172	17	254	87	87					
e2-5	Audio Amp. E2	9	Access	172	20	254	28	28					
E3	e0-0	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch E2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point E3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera E1	5	Access	172	18	254	86	86	y	5,0		
	e1-1	Rücksehkamera E2	5	Access	172	18	254	87	87	y	5,0		
	e1-2	Access point E4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle E2R	9	Access	172	20	254	14	14	y	7,5		Redundanz E2
	e1-10	Sprechstelle PRM WC	9	Access	172	20	254	16	16	y	7,5		
	e1-11	Sprechstelle PRM E2R	9	Access	172	20	254	15	15	y	7,5		Redundanz E2
	e1-12	Future use box E1	90	Access	-	-	-	-	-				
	e1-13	Future use box E3	90	Access	-	-	-	-	-				
	e1-14				-	-	-	-	-				
	e1-15				-	-	-	-	-				
	e2-0	Energiezähler E	12	Access	172	22	126	3	3				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
e2-3				-	-	-	-	-					
e2-4				-	-	-	-	-					
e2-5				-	-	-	-	-					

F1	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch E1	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2				-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point F1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
	e0-5	Service FIS / CCTV	2	Access	172	17	126	124	124					
	e1-0	Überw. Kamera F7	5	Access	172	18	254	49	49	y	5,0			
	e1-1	Überw. Kamera F2	5	Access	172	18	254	50	50	y	5,0			
	e1-2	Überw. Kamera F1	5	Access	172	18	254	51	51	y	5,0			
	e1-3	Überw. Kamera F5	5	Access	172	18	254	52	52	y	5,0			
	e1-4	Überw. Kamera F9	5	Access	172	18	254	53	53	y	5,0			
	e1-5	AFZ F1	8	Access	172	20	126	25	25	y	10,0			
	e1-6	AFZ F2	8	Access	172	20	126	26	26	y	10,0			
	e1-7	AFZ F5	8	Access	172	20	126	27	27	y	10,0			
	e1-8	Sprechstelle F1	9	Access	172	20	254	17	17	y	7,5			
	e1-9					-	-	-	-	-				
	e1-10					-	-	-	-	-				
	e1-11					-	-	-	-	-				
	e1-12	Future use box F5	90	Access		-	-	-	-	-				
	e1-13	Future use box F6	90	Access		-	-	-	-	-				
	e1-14	Seitenanzeige F1	3	Access	172	17	254	41	41					
	e1-15	Seitenanzeige F3	3	Access	172	17	254	42	42					
	e2-0	Bildschirm F7	3	Access	172	17	254	88	88					
	e2-1	Bildschirm F5	3	Access	172	17	254	89	89					
	e2-2	Bildschirm F1	3	Access	172	17	254	90	90					
e2-3	Bildschirm F3	3	Access	172	17	254	91	91						
e2-4	Bildschirm F	3	Access	172	17	254	92	92						
e2-5	Audio Amp. F1	9	Access	172	20	254	29	29						
F2	e0-0	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch E3	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2				-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point F2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
	e0-5	reserved			-	-	-	-	-					
	e1-0	Überw. Kamera F8	5	Access	172	18	254	54	54	y	5,0			
	e1-1	Überw. Kamera F4	5	Access	172	18	254	55	55	y	5,0			
	e1-2	Überw. Kamera F3	5	Access	172	18	254	56	56	y	5,0			
	e1-3	Überw. Kamera F6	5	Access	172	18	254	57	57	y	5,0			
	e1-4	Überw. Kamera F10	5	Access	172	18	254	58	58	y	5,0			
	e1-5	AFZ F3	8	Access	172	20	126	28	28	y	10,0			
	e1-6	AFZ F4	8	Access	172	20	126	29	29	y	10,0			
	e1-7					-	-	-	-	-				
	e1-8	Sprechstelle F2	9	Access	172	20	254	18	18	y	7,5			
	e1-9	Sprechstelle FIR	9	Access	172	20	254	17	17	y	7,5			
	e1-10					-	-	-	-	-				
	e1-11					-	-	-	-	-				
	e1-12	Future use box F2	90	Access		-	-	-	-	-				
	e1-13	Future use box F4	90	Access		-	-	-	-	-				
	e1-14	Seitenanzeige F2	3	Access	172	17	254	43	43					
	e1-15	Seitenanzeige F4	3	Access	172	17	254	44	44					
	e2-0	Bildschirm F8	3	Access	172	17	254	93	93					
	e2-1	Bildschirm F6	3	Access	172	17	254	94	94					
	e2-2	Bildschirm F2	3	Access	172	17	254	95	95					
e2-3	Bildschirm F	3	Access	172	17	254	96	96						
e2-4	Bildschirm F11	3	Access	172	17	254	97	97						
e2-5	Audio Amp. F2	9	Access	172	20	254	30	30						
F3	e0-0	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-1	FIS Switch F2	All (except OBS Intercon)	Trunk	-	-	-	-	-					
	e0-2				-	-	-	-	-					
	e0-3				-	-	-	-	-					
	e0-4	Access point F3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
	e0-5	reserved			-	-	-	-	-					
	e1-0	Rücksehkamera F1	5	Access	172	18	254	88	88	y	5,0			
	e1-1	Rücksehkamera F2	5	Access	172	18	254	89	89	y	5,0			
	e1-2	Access point F4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0			
	e1-3				-	-	-	-	-					
	e1-4				-	-	-	-	-					
	e1-5				-	-	-	-	-					
	e1-6				-	-	-	-	-					
	e1-7				-	-	-	-	-					
	e1-8				-	-	-	-	-					
	e1-9	Sprechstelle F2R	9	Access	172	20	254	18	18	y	7,5		Redundanz F2	
	e1-10				-	-	-	-	-					
	e1-11				-	-	-	-	-					
	e1-12	Future use box F1	90	Access	-	-	-	-	-					
	e1-13	Future use box F3	90	Access	-	-	-	-	-					
	e1-14				-	-	-	-	-					
	e1-15				-	-	-	-	-					
	e2-0				-	-	-	-	-					
	e2-1				-	-	-	-	-					
	e2-2				-	-	-	-	-					
e2-3				-	-	-	-	-						
e2-4				-	-	-	-	-						
e2-5				-	-	-	-	-						

B1	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B1	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B1	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	Service FIS / CCTV	2	Access	172	17	126	125	125				
	e1-0	Überw. Kamera B7	5	Access	172	18	254	59	59	y	5,0		
	e1-1	Überw. Kamera B2	5	Access	172	18	254	60	60	y	5,0		
	e1-2	Überw. Kamera B1	5	Access	172	18	254	61	61	y	5,0		
	e1-3	Überw. Kamera B5	5	Access	172	18	254	62	62	y	5,0		
	e1-4	Überw. Kamera B9	5	Access	172	18	254	63	63	y	5,0		
	e1-5	AFZ B1	8	Access	172	20	126	30	30	y	10,0		
	e1-6	AFZ B2	8	Access	172	20	126	31	31	y	10,0		
	e1-7				-	-	-	-	-				
	e1-8	Sprechstelle B1	9	Access	172	20	254	19	19	y	7,5		
	e1-9				-	-	-	-	-				
	e1-10				-	-	-	-	-				
	e1-11	ZFR R	2	Access	172	17	126	2	2				
	e1-12	Future use box B5	90	Access	-	-	-	-	-				
	e1-13	Future use box B6	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B1	3	Access	172	17	254	45	45				
	e1-15	Seitenanzeige B3	3	Access	172	17	254	46	46				
	e2-0	Bildschirm B7	3	Access	172	17	254	98	98				
	e2-1	Bildschirm B5	3	Access	172	17	254	99	99				
	e2-2	Bildschirm B1	3	Access	172	17	254	100	100				
e2-3	Bildschirm B3	3	Access	172	17	254	101	101					
e2-4	ADU B	9	Access	172	20	254	4	4					
e2-5	Audio Amp. B1	9	Access	172	20	254	31	31					
B2	e0-0	FIS Switch B3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch F3	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2				-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B2	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Überw. Kamera B8	5	Access	172	18	254	64	64	y	5,0		
	e1-1	Überw. Kamera B4	5	Access	172	18	254	65	65	y	5,0		
	e1-2	Überw. Kamera B3	5	Access	172	18	254	66	66	y	5,0		
	e1-3	Überw. Kamera B6	5	Access	172	18	254	67	67	y	5,0		
	e1-4	Überw. Kamera B10	5	Access	172	18	254	68	68	y	5,0		
	e1-5	AFZ B3	8	Access	172	20	126	32	32	y	10,0		
	e1-6	AFZ B4	8	Access	172	20	126	33	33	y	10,0		
	e1-7	NVR B	5	Access	172	18	254	6	6				
	e1-8	Sprechstelle B2	9	Access	172	20	254	20	20	y	7,5		
	e1-9	Sprechstelle B1R	9	Access	172	20	254	19	19	y	7,5		
	e1-10				-	-	-	-	-				
	e1-11				-	-	-	-	-				
	e1-12	Future use box B2	90	Access	-	-	-	-	-				
	e1-13	Future use box B4	90	Access	-	-	-	-	-				
	e1-14	Seitenanzeige B2	3	Access	172	17	254	47	47				
	e1-15	Seitenanzeige B4	3	Access	172	17	254	48	48				
	e2-0	Bildschirm B8	3	Access	172	17	254	102	102				
	e2-1	Bildschirm B6	3	Access	172	17	254	103	103				
	e2-2	Bildschirm B2	3	Access	172	17	254	104	104				
e2-3	Bildschirm B4	3	Access	172	17	254	105	105					
e2-4				-	-	-	-	-					
e2-5	Audio Amp. B2	9	Access	172	20	254	32	32					
B3	e0-0	FIS Switch B1	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-1	FIS Switch B2	All (except OBS Intercon)	Trunk	-	-	-	-	-				
	e0-2	Frontkupplung B2	100, 2, 3, 5, 6, 7, 8, 9, 12	Trunk	-	-	-	-	-				
	e0-3				-	-	-	-	-				
	e0-4	Access point B3	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e0-5	reserved			-	-	-	-	-				
	e1-0	Rücksehkamera B1	5	Access	172	18	254	90	90	y	5,0		
	e1-1	Rücksehkamera B2	5	Access	172	18	254	91	91	y	5,0		
	e1-2	Access point B4	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	-	y	18,0		
	e1-3				-	-	-	-	-				
	e1-4				-	-	-	-	-				
	e1-5				-	-	-	-	-				
	e1-6				-	-	-	-	-				
	e1-7				-	-	-	-	-				
	e1-8				-	-	-	-	-				
	e1-9	Sprechstelle B2R	9	Access	172	20	254	20	20	y	7,5		Redundanz B2
	e1-10				-	-	-	-	-				
	e1-11	ZFR	2	Access	172	17	126	2	2				
	e1-12	Future use box B1	90	Access	-	-	-	-	-				
	e1-13	Future use box B3	90	Access	-	-	-	-	-				
	e1-14	Frontanzeige B	3	Access	172	17	254	24	24				
	e1-15				-	-	-	-	-				
	e2-0				-	-	-	-	-				
	e2-1				-	-	-	-	-				
	e2-2				-	-	-	-	-				
e2-3				-	-	-	-	-					
e2-4	ADU BR	9	Access	172	20	254	4	4					
e2-5	Service VLAN PWLAN	100, 10, 20, 30, 31, 131, 150	Trunk	-	-	-	-	127					
Firewall		RCU	2	N/A	172	17	126	126	126			IP festgehalten fuer die RCU.	
			3	N/A	172	17	254	126	126			Diese ist mit der Firewall verbunden.	
			9	N/A	172	20	254	126	126			Anforderung von STADIER	