init HELLO

Скомпилировали статически под ARM init.c, который выводит строку Hello echo init | cpio -o -H newc | gzip > <u>initramfs.cpio.gz</u> запустили в qemu

qemu-system-arm -M vexpress-a9 -kernel ../zlmage -dtb ../vexpress-v2p-ca9.dtb -initrd initramfs.cpio.gz -append "console=ttyAMA0" -nographic

```
1.738222] CLK: Disabling unused Clocks
1.778784] Freeing unused kernel image (initmem) memory: 2048K
     1.783402] Run /init as init process
Hello
     1.949882] input: ImExPS/2 Generic Explorer Mouse as /devices/platform/b
00000/bus@40000000:motherboard-bus@40000000:iofpga@7,00000000/10007000.kmi/
    11.986661] amba 1000f000.wdt: deferred probe pending: (reason unknown)
    11.986720] amba 100e0000.memory-controller: deferred probe pending: (rea
    11.986730] amba 100e1000.memory-controller: deferred probe pending: (rea
    11.986735] amba 100e5000.watchdog: deferred probe pending: (reason unkno
    16.856779] Kernel panic - not syncing: Attempted to kill init! exitcode
    16.858452] CPU: 0 UID: 0 PID: 1 Comm: init Not tainted 6.17.0-rc5 #1 NON
    16.859216] Hardware name: ARM-Versatile Express
    16.859859] Call trace:
    16.860365] unwind_backtrace from show_stack+0x10/0x14
    16.861700] show_stack from dump_stack_lvl+0x54/0x68
    16.862062] dump_stack_lvl from vpanic+0xf4/0x304
               vpanic from panic+0x2c/0x30
    16.862469]
    16.862849]
                panic from do_exit+0x960/0x964
    16.863171]
               do_exit from do_group_exit+0x34/0x84
    16.863465]
                do_group_exit from pid_child_should_wake+0x0/0x60
    16.864481] ---[end Kernel panic - not syncing: Attempted to kill init!
```

Busybox

скачали busybox, собираем ARCH=arm make defconfig ARCH=arm make menuconfig

включили статическую сборку и указали префикс кросс-компилятора, также исключили утилиту tc и SHA1 hwaccel флаг, потому что были ошибки

ARCH=arm make -j12 ARCH=arm make install -j12 создали initramfs

find . | cpio -o -H newc | gzip > <u>initramfs.cpio.gz</u> запустили в qemu

QEMU_AUDIO_DRV=none qemu-system-arm -M vexpress-a9 -kernel zlmage -dtb vexpress-v2p-ca9.dtb -initrd initramfs.cpio.gz -append "console=ttyAMA0 rdinit=/bin/ash" -nographic

скопировали libc и линкер в директорию /lib прошивки для проверки скомпилировал hello world и скопировал в /bin пересобрали initramfs.cpio.gz

```
[ 1.965492] Freeing unused kernel image (initmem) memory: 2048K
[ 1.968786] Run /bin/ash as init process
/bin/ash: can't access tty; job control turned off
~ # [ 2.327170] input: ImExPS/2 Generic Explorer Mouse as /devices/platf
@40000000/bus@40000000:motherboard-bus@40000000:iofpga@7,00000000/10007000.
??
/bin/ash: ды: not found
~ # ls
bin initramfs.cpio.gz root usr
dev lib sbin
~ # ./bin/test
Hello World
```

интересно было собрать busybox без статической линковки, поэтому сделал это

```
akenoxd@DESKTOP:~/eltex/busybox-1.37.0/_install$ cd bin/
akenoxd@DESKTOP:~/eltex/busybox-1.37.0/_install/bin$ file busybox
busybox: ELF 32-bit LSB pie executable, ARM, EABI5 version 1 (SYSV), dynamically linked, interpreter /lib/ld-linux-armhf
.so.3, BuildID[shal]=8c3adb40623aac5ea2db4276afbe8d0d54c195dd, for GNU/Linux 3.2.0, stripped
akenoxd@DESKTOP:~/eltex/busybox-1.37.0/_install/bin$ |
```

чтобы узнать какие библиотеки нужны busybox для работы, используем readelf -d

```
akenoxd@DESKTOP:~/eltex/busybox-1.37.0/_install$ readelf -d bin/busybox
Dynamic section at offset 0xd4814 contains 30 entries:
                                                  Name/Value
  Tag
               Type
 0x00000001 (NEEDED)
                                                 Shared library: [libm.so.6]
                                                Shared library: [libresolv.so.2]
Shared library: [libc.so.6]
Shared library: [ld-linux-armhf.so.3]
 0x00000001 (NEEDED)
 0x00000001 (NEEDED)
 0x00000001 (NEEDED)
 0x0000000c (INIT)
                                                0x6668
 0x00000000d (FINI)
                                                0xac40c
 0x00000019 (INIT_ARRAY)
                                                0xd3f30
```

и копируем эти библиотеки в прошивку работает!

```
[ 2.049766] Freeing unused kernel image (initmem) memory: 2048K
[ 2.085923] Run /bin/ash as init process
/bin/ash: can't access tty; job control turned off
~ # [ 2.383990] input: ImExPS/2 Generic Explorer Mouse as /devices/platform/bus@40
@40000000/bus@400000000:motherboard-bus@40000000:iofpga@7,000000000/10007000.kmi/serio1
ls
bin initramfs.cpio.gz root usr
dev lib sbin
~ # ls lib/
ld-linux-armhf.so.3 libc.so.6 libresolv.so.2
libc.so libm.so.6
~ #
```