

# Stability of Oscillatory Rotating Disk Boundary Layers

---

**Scott Morgan**

*Supervisor: Dr. Christopher Davies*

*SIAM National Student Chapter Conference 2017*  
*23rd May 2017*



# Structure


- **Part 1:** What?
- **Part 2:** Why?
- **Part 3:** How?

**What?**

---

# What?

## Stability of Oscillatory Rotating Disk Boundary Layers



Simulations from E. Appelquist (KTH, Stockholm)

# What?


## Stability of Oscillatory Rotating Disk Boundary Layers

*Simulations from E. Appelquist (KTH, Stockholm)*

# What?

## Stability of Oscillatory Rotating Disk Boundary Layers

Adding oscillation to *channel* flow can be stabilising



Thomas et. al. (2011)

# What?

**Stability of Oscillatory Rotating Disk Boundary Layers**

# Why?

---


# Why Rotating Disks?

Rotating disks  $\approx$  Swept wings

# Why Swept Wings?

Co2 Emissions by Sector

The Economist



Electricity Generation   Transport   Aviation   Agriculture   Industry  
Residential   Commercial

meta-chart.com

# Why Not Just Study Swept Wings?

## Reason 1



vs.



# Why Not Just Study Swept Wings?

## Reason 2

$$F^2 - G^2 + F'H - F'' = 0$$

$$2FG + G'H - G'' = 0$$

$$2F + H' = 0$$

vs.

$$\frac{\partial \mathbf{u}}{\partial t} + (\mathbf{u} \cdot \nabla^*)\mathbf{u} = -\nabla p + \nu \nabla^2 \mathbf{u}$$
$$\nabla \cdot \mathbf{u} = 0$$

# How?


---

## How?

- Measure the response of the flow to some *disturbance*.


# How?

- Measure the response of the flow to some *disturbance*.
- Force disturbance at some point:



# How?


- Measure the response of the flow to some *disturbance*.
- Compute evolution:



Radial evolution of  $u(r, z = 0)$

# How?

- Measure the response of the flow to some *disturbance*.
- Compute evolution:



*Radial evolution of  $u(r, z = 0)$*

## **Something a Little More Technical**

---

## Something a Little More Technical

- Flow can be expressed as vector in three dimensions:

$$\mathbf{U}(r, \theta, z) = (F, G, H)$$

## Something a Little More Technical

- Flow can be expressed as vector in three dimensions:

$$\mathbf{U}(r, \theta, z) = (F, G, H)$$

- Boundary conditions:

$$\begin{aligned} G \text{ at disk surface} &= r\Omega(t) \\ &= r(\Omega_0 + \epsilon \cos(\phi t)) \end{aligned}$$

– Because of no-slip condition - velocity at disk surface must equal the velocity of the disk

## Something a Little More Technical

- Flow can be expressed as vector in three dimensions:

$$\mathbf{U}(r, \theta, z) = (F, G, H)$$

- Boundary conditions:

$$\begin{aligned} G \text{ at disk surface} &= r\Omega(t) \\ &= r(\Omega_0 + \epsilon \cos(\phi t)) \end{aligned}$$

- Because of no-slip condition - velocity at disk surface must equal the velocity of the disk
- Solve the Navier-Stokes equations.

## Something a Little More Technical

- Which parameters can we vary?

## Something a Little More Technical

- Which parameters can we vary?
  - Reynolds number (*actually radial position*)

## Something a Little More Technical

- Which parameters can we vary?
  - Reynolds number (*actually radial position*)
  - Oscillation amplitude

## Something a Little More Technical


- Which parameters can we vary?
  - Reynolds number (*actually radial position*)
  - Oscillation amplitude
  - Oscillation frequency

## Something a Little More Technical

- Can we quantify the stabilisation?


# Something a Little More Technical

- Can we quantify the stabilisation?
- Exponential growth?



# Something a Little More Technical

- Can we quantify the stabilisation?
- Exponential growth?



- YES!


$$\mathbf{u}(r, z, t) \sim u(z, t) e^{i\alpha r}$$

## Something a Little More Technical

- $-\alpha_i$  gives us the growth rate.
- Give some flow variable  $A$ , (we use  $A = u(r, z = 0, t)$ ), we can calculate:

$$\alpha_i \simeq \frac{-i}{A} \frac{\partial A}{\partial r}$$

# Something a Little More Technical



Fixed Reynolds number & frequency, varying wall amplitude

## Current & Future Work

- Use local techniques to confirm simulation results.
- Look at parallels between oscillation and surface roughness.
- Experimental confirmation.

**Thank You**

---

## Periodic Modulation - Setup

- Boundary conditions (non-rotating frame):

$$V(0, t) = \textcolor{red}{r}\Omega^*(t)$$

## Periodic Modulation - Setup

- Boundary conditions (non-rotating frame):

$$V(0, t) = \textcolor{red}{r}\Omega^*(t)$$

- Rotation rate:

$$\Omega^*(t) = \Omega_0^* + \epsilon\phi^* \cos(\phi^* t)$$

# Periodic Modulation - Setup

- Boundary conditions (non-rotating frame):

$$V(0, t) = \textcolor{red}{r}\Omega^*(t)$$

- Rotation rate:

$$\Omega^*(t) = \Omega_0^* + \epsilon\phi^* \cos(\phi^* t)$$

$\Omega_0^*$  - constant rotation rate

$\epsilon$  - angular displacement

$\phi^*$  - oscillation frequency

# Scalings

- Two length scales:

$$\delta_k^* = \sqrt{\frac{\nu^*}{\Omega_0^*}}, \quad \delta_s^* = \sqrt{\frac{\nu^*}{\phi^*}} \quad (1)$$

# Scalings

- Two length scales:

$$\delta_k^* = \sqrt{\frac{\nu^*}{\Omega_0^*}}, \quad \delta_s^* = \sqrt{\frac{\nu^*}{\phi^*}} \quad (1)$$

- Three temporal scales:

$$\tau_k^L = r_L^* \Omega_0^* t, \quad \tau_k^g = \Omega_0^* t, \quad \tau_s = \phi^* t \quad (2)$$

# Scalings

- Two length scales:

$$\delta_k^* = \sqrt{\frac{\nu^*}{\Omega_0^*}}, \quad \delta_s^* = \sqrt{\frac{\nu^*}{\phi^*}} \quad (1)$$

- Three temporal scales:

$$\tau_k^L = r_L^* \Omega_0^* t, \quad \tau_k^g = \Omega_0^* t, \quad \tau_s = \phi^* t \quad (2)$$

- Choose:

$$\delta_k^* = \sqrt{\frac{\nu^*}{\Omega_0^*}}, \quad \tau_k^L = r_L^* \Omega_0^* t \quad (3)$$

# Scalings

- Choose:

$$\delta_k^* = \sqrt{\frac{\nu^*}{\Omega_0^*}}, \quad \tau_k^L = r_L^* \Omega_0^* t \quad (4)$$

# Scalings

- Choose:

$$\delta_k^* = \sqrt{\frac{\nu^*}{\Omega_0^*}}, \quad \tau_k^L = r_L^* \Omega_0^* t \quad (4)$$

- Reynolds numbers:

$$R_k = r_L$$

$$R_s = \epsilon \sqrt{\varphi} R_k$$

# Scalings

- Choose:

$$\delta_k^* = \sqrt{\frac{\nu^*}{\Omega_0^*}}, \quad \tau_k^L = r_L^* \Omega_0^* t \quad (4)$$

- Reynolds numbers:

$$R_k = r_L$$

$$R_s = \epsilon \sqrt{\varphi} R_k$$

- Boundary conditions:

$$G(0, \tau) = 1 + \frac{R_s \sqrt{\varphi}}{R_k} \cos \left( \frac{\varphi}{R_k} \tau \right) \quad (5)$$

$\varphi = \frac{\phi^*}{\Omega_0^*}$  - number of oscillations per disk rotation period

# Scalings

- Choose:

$$\delta_k^* = \sqrt{\frac{\nu^*}{\Omega_0^*}}, \quad \tau_k^L = r_L^* \Omega_0^* t \quad (4)$$

- Reynolds numbers:

$$R_k = r_L$$

$$R_s = \epsilon \sqrt{\varphi} R_k$$

- Boundary conditions:

$$G(0, \tau) = 1 + \frac{R_s \sqrt{\varphi}}{R_k} \cos \left( \frac{\varphi}{R_k} \tau \right) \quad (5)$$


$\varphi = \frac{\phi^*}{\Omega_0^*}$  - number of oscillations per disk rotation period

- Three parameters:

$$(R_k, R_s, \varphi) \quad (6)$$

$(R_s \rightarrow 0$  recovers steady case)


# Typical Mean Flow Variation



Base flow variation for  $Rs = 10$ ,  $\phi = 50$

- Zero average deviation from steady state across a period.  $\int_0^T \mathbf{U} = 0$

# Typical Mean Flow Variation



Azimuthal variation near wall for  $Rs = 10$ ,  $\phi = 50$

- Zero average deviation from steady state across a period.  $\int_0^T \mathbf{U} = 0$

# Three Approaches to Stability Analysis

- Floquet theory
- DNS
- Instantaneous (frozen-flow) approximation

# Three Approaches to Stability Analysis

- Floquet theory
- DNS
- Instantaneous (frozen-flow) approximation
- Focus on *stationary* disturbances

# Floquet Theory

- Perturbation

$$\mathbf{U} = \mathbf{U}_B + \mathbf{u}$$

# Floquet Theory

- Perturbation

$$\mathbf{U} = \mathbf{U}_B + \mathbf{u}$$

- Normal mode approximation:

$$\phi(r, \theta, z, \tau) = \hat{\phi}(z, \tau) e^{\mu\tau} e^{i(\alpha r + \beta R\theta)}$$

where  $\hat{\phi}$  is periodic.

# Floquet Theory

- Perturbation

$$\mathbf{U} = \mathbf{U}_B + \mathbf{u}$$

- Normal mode approximation:

$$\phi(r, \theta, z, \tau) = \hat{\phi}(z, \tau) e^{\mu\tau} e^{i(\alpha r + \beta R\theta)}$$

where  $\hat{\phi}$  is periodic.

- Gives eigenvalue problem:

$$\sum_{n=-K}^K \mathcal{L}\{u_n^r, u_n^\theta, w_n; \mu\} e^{in\tau} = 0$$

to be solved for  $(\psi, \mu)$  where  $(\alpha, \beta)$  are prescribed.

## DNS - Wall Motion

- Wall displacement for stationary forcing (steady, rotating frame):

$$\zeta(r, \theta, \tau) = e^{\lambda r^2} e^{in\theta}$$

## DNS - Wall Motion

- Wall displacement for stationary forcing (steady, rotating frame):

$$\zeta(r, \theta, \tau) = e^{\lambda r^2} e^{in\theta}$$

- $\theta$  coordinate changes:

$$\theta \rightarrow \theta_0 + \int^{\tau} \Omega(\tilde{\tau})$$

## DNS - Wall Motion

- Wall displacement for stationary forcing (steady, rotating frame):

$$\zeta(r, \theta, \tau) = e^{\lambda r^2} e^{in\theta}$$

- $\theta$  coordinate changes:

$$\theta \rightarrow \theta_0 + \int^\tau \Omega(\tilde{\tau})$$

- Forcing stationary with respect to modulated disk:


$$\zeta(r, \theta_0, \tau) = e^{\lambda r^2} e^{in \int^\tau \Omega(\tilde{\tau})} e^{in\theta_0}$$

## DNS - Stationary Forcing

- Prescribe wall motion  $\zeta(r, \theta_0, \tau) = e^{\lambda r^2} e^{in \int^\tau \Omega(\tilde{\tau})} e^{in\theta_0}$

# DNS - Stationary Forcing

- Prescribe wall motion  $\zeta(r, \theta_0, \tau) = e^{\lambda r^2} e^{in \int^\tau \Omega(\tilde{\tau})} e^{in\theta_0}$




Radial evolution:  $R = 500, n = 32, R_s = 20, \varphi = 25$

- Receptivity issues.

# DNS - Stationary Forcing


- Calculate  $\alpha = -\frac{i}{A} \frac{\partial A}{\partial t}$  at fixed  $r$ .



$$R = 500, n = 32, Rs = 20, \varphi = 25$$

# DNS - Stationary Forcing


- Calculate  $\alpha = -\frac{i}{A} \frac{\partial A}{\partial t}$  at fixed  $r$ .



$$R = 500, n = 32, Rs = 20, \varphi = 25$$

# DNS - Stationary Forcing

- Exponential growth reconstructed from  $e^{i\alpha r}$



$$R = 500, n = 32, Rs = 20, \varphi = 25$$

## DNS - Results


- Exactly prescribe  $(\alpha, \mu, \psi)$  from Floquet theory at inflow.

$$\psi(r, \theta, z, \tau) = \hat{\psi}(z, \tau) e^{\mu \tau} e^{i \alpha r} e^{i n \theta}$$

# DNS - Results

- Exactly prescribe  $(\alpha, \mu, \psi)$  from Floquet theory at inflow.

$$\psi(r, \theta, z, \tau) = \hat{\psi}(z, \tau) e^{\mu \tau} e^{i \alpha r} e^{i n \theta}$$



Radial evolution:  $R = 500$ ,  $n = 32$ ,  $Rs = 20$ ,  $\varphi = 25$


# DNS - Results

- Calculate  $\alpha = -\frac{i}{A} \frac{\partial A}{\partial t}$  for fixed  $r$ .

Stationary Forcing		
$R_s$	$\varphi$	$\alpha$
0	N/A	0.2821 - 0.0712i
10	$\varphi = 25$	0.2820 - 0.0701i
	$\varphi = 50$	0.2820 - 0.0709i
20	$\varphi = 25$	0.2821 - 0.0686i
	$\varphi = 50$	0.2817 - 0.0702i

Inflow Prescribed Forcing		
$R_s$	$\varphi$	$\alpha$
0	N/A	0.2821 - 0.0712i
10	$\varphi = 25$	0.2820 - 0.0701i
	$\varphi = 50$	0.2820 - 0.0709i
20	$\varphi = 25$	0.2821 - 0.0685i
	$\varphi = 50$	0.2818 - 0.0702i

## DNS - Results




Variation of  $\alpha_i$  with increasing  $R_s$

## DNS - Impulsive Forcing

- Prescribe impulsive wall motion  $\zeta(r, \theta_0, \tau) = e^{\lambda r^2} e^{-\sigma t^2}$

# DNS - Impulsive Forcing

- Prescribe impulsive wall motion  $\zeta(r, \theta_0, \tau) = e^{\lambda r^2} e^{-\sigma t^2}$



Temporal evolution:  $R = 350$ ,  $n = 32$ ,  $Rs = 20$ ,  $\varphi = 25$

## Frozen flow approximation

- Freeze flow, treat  $\tau$  as parameter:

$$\phi(r, \theta, z, \tau) = \hat{\phi}(z; \tau) e^{i(\alpha r + \beta R\theta - \int^{\tau} \omega(\tilde{\tau}))} \quad (7)$$

where  $\hat{\phi}$  is slowly varying.

## Frozen flow approximation

- Freeze flow, treat  $\tau$  as parameter:

$$\phi(r, \theta, z, \tau) = \hat{\phi}(z; \tau) e^{i(\alpha r + \beta R\theta - \int^{\tau} \omega(\tilde{\tau}))} \quad (7)$$

where  $\hat{\phi}$  is slowly varying.

- Specify  $\alpha$  and solve OS equation for  $\omega(\tau)$  at each time-step.

## Frozen flow approximation

- Freeze flow, treat  $\tau$  as parameter:

$$\phi(r, \theta, z, \tau) = \hat{\phi}(z; \tau) e^{i(\alpha r + \beta R\theta - \int^{\tau} \omega(\tilde{\tau}))} \quad (7)$$

where  $\hat{\phi}$  is slowly varying.

- Specify  $\alpha$  and solve OS equation for  $\omega(\tau)$  at each time-step.
- Specify  $\omega$  and solve OS equation for  $\alpha(\tau)$  at each time-step.

## Connections with the Stokes Layer

- Write

$$\begin{aligned}\mathbf{U}^T &= \mathbf{U}^S + \mathbf{U}^M \\ &= \mathbf{U}^S + \epsilon \mathbf{U}_1 + \mathcal{O}(\epsilon^2)\end{aligned}$$

## Connections with the Stokes Layer

- Write

$$\begin{aligned}\mathbf{U}^T &= \mathbf{U}^S + \mathbf{U}^M \\ &= \mathbf{U}^S + \epsilon \mathbf{U}_1 + \mathcal{O}(\epsilon^2)\end{aligned}$$

- High frequency modulation suggests primary lengthscale:

$$\delta_s = \sqrt{\frac{1}{\varphi}}$$

# Connections with the Stokes Layer

- Write

$$\begin{aligned}\mathbf{U}^T &= \mathbf{U}^S + \mathbf{U}^M \\ &= \mathbf{U}^S + \epsilon \mathbf{U}_1 + \mathcal{O}(\epsilon^2)\end{aligned}$$

- High frequency modulation suggests primary lengthscale:

$$\delta_s = \sqrt{\frac{1}{\varphi}}$$

- Rescale

$$\tilde{z} = \frac{z}{\delta_s}, \quad \tilde{\tau} = \frac{\varphi}{R} \tau$$

# Connections with the Stokes Layer

- Near the wall we have

$$\begin{aligned}\left(\frac{1}{\delta^2}\right) \frac{\partial F}{\partial \tilde{z}} &= \left(\frac{1}{\delta^2}\right) F'' + \mathcal{O}(\delta^{-1}) \\ \left(\frac{1}{R\delta^2}\right) \frac{\partial G}{\partial \tilde{z}} &= \left(\frac{1}{\delta^2}\right) G'' + \mathcal{O}(\delta^{-1})\end{aligned}$$

$$H \sim \delta F$$

with

$$F(0, \tilde{r}) = H(0, \tilde{r}) = 0, \quad G(0, \tilde{r}) = \cos(\tilde{r})$$

$$F \rightarrow 0 \quad G \rightarrow 0 \quad \text{as} \quad \tilde{z} \rightarrow \infty$$

# Connections with the Stokes Layer

- To dominant balance:

$$\frac{\partial F}{\partial \tilde{\tau}} = F'', \quad \text{with} \quad F(0) = F(\tilde{z} \rightarrow \infty) = 0$$

$$\frac{1}{R} \frac{\partial G}{\partial \tilde{\tau}} = G'', \quad \text{with} \quad G(0) = \cos(\tilde{\tau}), \quad G(\tilde{z} \rightarrow \infty) = 0$$

# Connections with the Stokes Layer

- To dominant balance:

$$\frac{\partial F}{\partial \tilde{\tau}} = F'', \quad \text{with} \quad F(0) = F(\tilde{z} \rightarrow \infty) = 0$$


$$\frac{1}{R} \frac{\partial G}{\partial \tilde{\tau}} = G'', \quad \text{with} \quad G(0) = \cos(\tilde{\tau}), \quad G(\tilde{z} \rightarrow \infty) = 0$$

- Which gives Stokes layer:

$$F = 0$$

$$G = \frac{1}{R} \exp(-\tilde{z}) \cos(\tilde{\tau} - \tilde{z})$$

# Connections with the Stokes Layer



Comparison between Stokes layer profile and base flow variation