# Projecto FST Novabase – Electrónica

# Relatório Semanal - 14/11/2014

#### Por Laura Gouveia

# Programação para dsPIC

### Colocar pin a HIGH

- Declarar pin como output (TRISx: 0 output; 1-input)
- Declarar valor do pin (LATx)

```
//coloca pin a HIGH
void bitB0_high() {
    TRISBbits.TRISB0 = 0; //set pin 0 port B as output
    LATBbits.LATB0 = 1; // set pin 0 port B a high
}
```

#### Inicializar Timer1

- Declarar funcionamento em idle, uso de gaterd time, relógio a usar para sincronizar (interior ou externo) e prescale de frequência a usar na frequência de relógio.
- Declarar parâmetros de interrupção.
- Declarar valor final do timer (PRx) e valor inicial (TMRx).
- Iniciar timer.

```
//inicializar timer 1
void timer1_init() {
    T1CONbits.TSIDL = 0; //continue in idle mode
    T1CONbits.TGATE = 0; //disable gated time accumulation
    T1CONbits.TCS = 0; //use internal clock (TSYNC is ignored)
    T1CONbits.TCKPS = 3; //prescale 1:256

IECObits.T1IE = 1; //interrupt enable timer1
    IFSObits.T1IF = 0; //clear interrupt flag
    IPCObits.T1IP = 4; // prioridade 4

PR1 = 29297; //valor final do timer 1 (FCY/PRESCALE) Freq = 1 Hz
    TMR1 = 0; //valor inicial do timer1
```

```
T1CONbits.TON = 1; //starts timer1
}
```

## Tratamento de interrupção do Timer1 - Inverter valor do pin

- Tratamento de interrupção.
- Limpar flag de interrupção.

#### **Pulse Width Modulation**

- Inicializar Output Compare pin como output.
- Declarar modo em idle, timer a ser utilizado e modo de Output Compare
- Declarar valor inicial, em registo (OCxR) e registo auxiliar(OCxRS).
- Inicializar timer.

```
IECObits.T2IE = 0; //interrupt disable timer2
IFSObits.T2IF = 0; //clear interrupt flag
IPC1bits.T2IP = 4; // prioridade 4

PR2 = 7500; //valor final do timer2 FCY/PRESCALE fpwm=1kHz
TMR2 = 0; //valor inicial do timer2

T2CONbits.TON = 1; //starts timer2
}
```

# Aumentar duty cycle de PWM

```
//tratamento interrupçao timer1
void __attribute__((interrupt, auto_psv, shadow)) _T1Interrupt(void) {
    OC1RS++; //incrementa duty cycle
    if(OC1RS==7500) //duty cycle 100%?
        OC1RS=0; //reset duty cycle

IFSObits.T1IF = 0; //clear interrupt flag
}
```

# Cálculo do período e resolução de PWM

# Equation 14-1: Calculating the PWM Period

```
PWM Period = [(PRy) + 1] • TCY • (TMRy Prescale Value)

PWM Frequency = 1/[PWM Period]
```

## Equation 14-2: Calculation for Maximum PWM Resolution

```
Maximum PWM Resolution (bits) = \frac{\log_{10} \left(\frac{\text{FOSC}}{\text{FPWM}}\right)}{\log_{10}(2)} \text{ bits}
```