

Burning fuel for cheap! Transport independent depletion in OpenMC

Oleksandr Yardas ¹
Paul Romano ² Madicken Munk ³ Kathryn Huff ¹

¹University of Illinois Urbana-Champaign

²Argonne National Laboratory

³Oregon State University

July 9, 2025



ILLINOIS

Outline



① Motivation

The Computer Problem
Nuclear Basics

② Methods

Modeling Depletion
Code Additions
Model Problem

③ Results

④ Conclusion

Simulating a nuclear reactor is expensive!

- Seven dimensions: space (3), energy (1) angle (2), time (1)
- Low-error → computationally-intensive methods




Figure 1: OpenMC model of the ATR Reactor, from [4]. The blue cross shape contains the fuel. The Pink circles on the outside are control drums.



Fission Chain Reaction




Figure 2: Diagram of a fission chain reaction, from [1].



Depletion

Concentration of nuclides in a reactor are constantly changing due to fission, neutron capture, and decay.

Why do we care?

- Strong coupling between depletion and transport
 - Neutron poisons → affects neutron economy
 - ↓ U, ↑ Pu → Change in fission neutron energy distribution
- Fission product decay heat → affects fuel reprocessing/disposal




Figure 3: Buildup of plutonium isotopes with a burnup for a typical LWR fuel composition. Reproduced from Figure 6-2 in [6].



Depletion makes everything *more* expensive

- Depletion calculation track thousands of nuclides
- Nonuniform neutron density in reactor → each fuel element is a unique material (recall the ATR, Fig 1)
- Axial discretization can add additional orders of magnitude of complexity





Figure 5: Example of the complicated web of production and transmutation reactions. From [3]

Outline



① Motivation

The Computer Problem
Nuclear Basics

② Methods

Modeling Depletion
Code Additions
Model Problem

③ Results

④ Conclusion



Modeling Depletion

Governing Equation:

$$\frac{dN_i}{dt} = \sum_{j=1}^n \underbrace{N_j(t) \int_0^\infty f_{j \rightarrow i}(E) \sigma_j(E) \phi(E, t) dE}_{\text{Production of } i \text{ from } j} + \sum_{j=1}^n \underbrace{N_j(t) \lambda_{j \rightarrow i}}_{\text{Decay of } j \text{ into } i} - N_i(t) \underbrace{\int_0^\infty \sigma_i(E) \phi(E, t) dE}_{\text{Consumption of } i} - N_i(t) \underbrace{\sum_{j=1}^n \lambda_{i \rightarrow j}}_{\text{Decay of } i}, \quad (1)$$

where

$N_i(t)$ \equiv density of nuclide i at time t [cm^{-3}]

$\sigma_i(E)$ \equiv transmutation cross section for nuclide i at energy E and time t [cm^2]

$\phi(E, t)$ \equiv neutron flux at energy E and time t [$\text{n cm}^{-2} \text{s}^{-1}$]

$f_{j \rightarrow i}(E)$ \equiv fraction of transmutation reactions in nuclide j that produce nuclide i

$\lambda_{j \rightarrow i}$ \equiv decay constant for decay modes in nuclide j that produce nuclide i [s^{-1}]

n \equiv total number of nuclides.

Neutron transport software of choice: OpenMC



- Monte carlo neutron particle transport code [9]
- Open source, community developed!!
- C++ core: neutron transport
- Python API: creating input, processing output, **depletion module**
- Depletion dependencies: NumPy (arrays), H5Py (output file processing), Matplotlib (plotting), SciPy (sparse matrices), uncertainties (uncertainty propagation)

Depletion algorithm

What do we need to solve Equation 1?

- $N_i(0)$, $n \rightarrow$ Given by the problem's initial conditions (e.g. Westinghouse PWR using 5% enriched fuel at BOL)
- $\sigma_i(E)$, $f_{j \rightarrow i}$, $\lambda_{j \rightarrow i} \rightarrow$ Material properties (data stored in memory for speed)
- $\phi(E, t) \rightarrow$ Concentration of neutrons in the reactor; requires a neutron transport simulation
- $t \rightarrow$ time steppers (called *integrators* in the depletion module)

Simplified Algorithm

- ① Run an OpenMC simulation to obtain $\phi(E, t_h)$
- ② Plug in $\phi(E, t_h)$, $N_i(t_h)$, $\sigma_i(E)$, $f_{j \rightarrow i}$, $\lambda_{j \rightarrow i}$ to obtain production and consumption terms in Equation 1
- ③ Solve Equation 1 for $N_i(t_{h+1})$ (Chebyshev rational approximation method [8])
- ④ Update material compositions using $N_i(t_{h+1})$
- ⑤ Repeat for all time steps t_h for $h \in [0, H]$

Can we make this cheaper?

- ① Assume *static* fluxes → decouple transport from depletion.
- ② Use a discrete energy grid → Integrals in Equation 1 become sums over energy groups g (simple + fast to evaluate)

MicroXS

- Stores $\sigma_{i,g}$
- Indexed by nuclide, reaction, energy group

get_microxs_and_flux()

- Run an OpenMC simulation to obtain $\sigma_{i,g}$ and ϕ_g for all nuclides
- Can get $\sigma_{i,g}, \phi_g$ for as many materials/domains as desired

IndependentOperator

- Drop in replacement for Operator class
- Performs step 2 in the Simplified algorithm for energy-discretized value ϕ_g and $\sigma_{i,g}$

Model Problem

- Single Pressurized Water Reactor (PWR) pincell
- 4.25% enriched fuel
- Reflective boundary conditions

Three cases:

- ① Transport-coupled depletion
(base truth)
- ② Transport-independent depletion
- ③ Transport-independent depletion
w/ recalculated cross sections
(sanity check)

Ten time steps, two different Δt :

- ① 3-day (Xe 135 poisoning limit)
- ② 30-day (long timestep approximation)




Figure 6: Slice plot of the pincell model in the xy -plane. Blue = water, black = cladding, pink = fuel

Three energy group structures: One group (single energy), 8 group, 40 group

Outline

① Motivation

The Computer Problem
Nuclear Basics

② Methods

Modeling Depletion
Code Additions
Model Problem

③ Results

④ Conclusion

Run time


Explicit run time data was not collected, but based on the file timestamps, we can estimate how long each case took to complete on a cluster

Table 1: Comparison of average total runtimes


Case	Runtime scale	Notes
1	hours	
2	minutes	Does not include the initial simulation to obtain ϕ_g and $\sigma_{i,g}$
3	hours	Cross section data had to be loaded in at each timestep, so this case took the longest amount of time

Case 2 is very fast!

One-group actinides (3-day time steps)




(a)




(b)

Figure 7: Actinide concentration error relative to Case 1 using 3-day time steps at 3, 12, 21, and 30 days of depletion for (a) constant cross sections (Case 2); (b) updating cross sections (Case 3).

One-group actinides (30-day time steps)



(a)



(b)

Figure 8: Actinide concentration error relative to Case 1 using 30-day time steps at 30, 120, 210, and 300 months of depletion for (a) constant cross sections (Case 2); (b) updating cross sections (Case 3).

Overprediction of (n, γ) reaction rates on ^{240}Pu




Figure 9: Relative ^{240}Pu (n, γ) reaction rate error using constant cross sections and 30-day time steps.

Fission products (3-day time steps)




Figure 10: (a) constant cross sections (Case 2); (b) updating cross sections (Case 3).

Fission products (30-day time steps)






Figure 11: (a) constant cross sections (Case 2); (b) updating cross sections (Case 3).

8-group actinides




(a)




(b)

Figure 12: (a) 3-day time steps; (b) 30-day time steps

40-group actinides



(a)



(b)

Figure 13: (a) 3-day time steps; (b) 30-day time steps

Outline



① Motivation

The Computer Problem
Nuclear Basics

② Methods

Modeling Depletion
Code Additions
Model Problem

③ Results

④ Conclusion

Conclusion

I

- Depletion calculations are expensive!

Conclusion



- Depletion calculations are expensive!
- Static, energy-discretized fluxes and cross sections yield low errors for abundant nuclides, moderate errors for trace nuclides

Conclusion



- Depletion calculations are expensive!
- Static, energy-discretized fluxes and cross sections yield low errors for abundant nuclides, moderate errors for trace nuclides
- Transport-independent depletion provide orders of magnitude of speedup for low to moderate errors in nuclide concentration.

Conclusion



- Depletion calculations are expensive!
- Static, energy-discretized fluxes and cross sections yield low errors for abundant nuclides, moderate errors for trace nuclides
- Transport-independent depletion provide orders of magnitude of speedup for low to moderate errors in nuclide concentration.
- Energy group structure does not matter for simple models

Technical Gaps and future work



- Full core model
- Multiple materials/depletion zones

Acknowledgement

People:

- Paul Romano - Conceptualization, Methodology, Software, Funding acquisition, Writing - review and editing
- Madicken Munk and Kathryn Huff - Funding acquisition, Writing - review and editing

Funding streams:

- Exascale Computing Project (17-SC-20-SC) (initial implementation)
- NRC Integrated University Grant Program Fellowship.
- U.S. Department of Energy Office of Fusion Energy Sciences Award Number DE-SC0022033.

Computing resources:

- Bebop (Argonne National Laboratory)
- Sawtooth (Idaho National Lab, Office of Nuclear Energy of the U.S. Department of Energy and the Nuclear Science User Facilities Contract No. DE-AC07-05ID14517)

References I



- [1] Illustration of a nuclear fission chain reaction., June 2017.
- [2] Amanda M. Bachmann, Oleksandr Yardas, and Madicken Munk.
An Open-Source Coupling for Depletion During Fuel Cycle Modeling.
Nuclear Science and Engineering, 0(0):1–14, September 2024.
Publisher: Taylor & Francis eprint: <https://doi.org/10.1080/00295639.2024.2393940>.
- [3] JWB at en.wikipedia.
Magyar: A 238Pu és 244Cm közötti elemátalakulás folyamata LWR-ben (könnyűvizes reaktorban).[9] A hasadás száazlékos aránya 100 mínusz a feltüntetett százalékok. Az elemátalakulás teljes sebessége nuklidtól függően nagymértékben változik. A 245Cm–248Cm felezési ideje hosszú, bomlásuk elhanyagolható., September 2007.
- [4] OpenMC User's Guide.
Chapter 9. Geometry Visualization.
- [5] Kathryn D. Huff, Matthew J. Gidden, Robert W. Carlsen, Robert R. Flanagan, Meghan B. McGarry, Arrielle C. Opotowsky, Erich A. Schneider, Anthony M. Scopatz, and Paul P. H. Wilson.
Fundamental concepts in the Cyclus nuclear fuel cycle simulation framework.
Advances in Engineering Software, 94:46–59, April 2016.
arXiv: 1509.03604.

References II

- [6] Ronald Allen Knief.
Nuclear Energy Technology.
Hemisphere Publishing Corporation, 1981.
- [7] Ethan E. Peterson, Paul K. Romano, Patrick C. Shriwise, and Patrick A. Myers.
Development and validation of fully open-source R2S shutdown dose rate capabilities in OpenMC*.
Nuclear Fusion, 64(5):056011, March 2024.
Publisher: IOP Publishing.
- [8] Paul K Romano.
Depletion capabilities in the OpenMC Monte Carlo particle transport code.
Annals of Nuclear Energy, page 15, 2021.
- [9] Paul K. Romano, Nicholas E. Horelik, Bryan R. Herman, Adam G. Nelson, Benoit Forget, and Kord Smith.
OpenMC: A state-of-the-art Monte Carlo code for research and development.
Annals of Nuclear Energy, 82:90–97, August 2015.
- [10] James Tracy Jr.
A Binding Energy Study of the Atomic Mass Evaluation 2012.
March 2017.

Application to fusion systems



- Proposed fusion energy facilities have a source rate high enough to activate materials, low enough to avoid significant composition change via depletion
- Activated nuclides decay and release high energy photons after long after reactor shutdown
- Computing this dose is an important quantity for safety and licensing

Transport-independent depletion was used in the workflow to calculate the shutdown dose rate in [7]

Application to fuel cycles



- Depletion determines how loaded fuel composition affect spent fuel compositions and related fuel cycle metrics.
- Global fuel cycle accounts for hundreds of reactors at once → impractical to run transport-coupled depletion to get spent fuel compositions
- A common approach is to use “recipes” that are based on depletion calculations for a specific reactor.

Transport-independent depletion was used in Cyclus [5], an open source fuel cycle simulator, to provide real-time fuel depletion capabilities that is reactor-agnostic [2].