

GEBZE TECHNICAL UNIVERSITY ELECTRONIC ENGINEERING

ELEC335 – MICROPROCESSORS LABAORATORY


LAB 1

| HAZIRLAYANLAR |
|-----------------------------------|
| 1801022035 – Ruveyda Dilara Günal |
| 1801022071 – Alperen Arslan |
| 1901022255 – Emirhan Köse |

PROBLEMS

Problem 1

• Identify all the components and explain their usage






Figure 1: NucleoG031K8 Layout

- **3.3V Power Supply for ST-LINK** → USB üzerinden verilen besleme kart üzerindeki sabit regülatör tarafından 5V'a düşürülmektedir. ST-LINK için güç kaynağı görevi gören bu regülatör ise 5V'u 3V'a düşürerek ST-LINK'e güç vermektedir.
- ST-LINK MCU → ST-LINK MCU allows the desired code to be uploaded to the target MCU via UART. When it is desired to load code via CubeIDE, it is first connected to the ST-LINK MCU. ST-LINK MCU deletes the code in the memory of the target MCU and loads the desired code.
- VDD Power → It is the main regulator that reduces the voltage supplied via USB to 5V. It is the supply of most components on the board.
- Reset Button → It is the button that restarts the code running on the target MCU from the beginning. It makes the RST pin 1 on the target MCU when pressed.
- **USB 5V Power Switch** → It is the regulator that goes by the name of Step-Down or Buck Switching regulator. In case of large voltage values, it offers a more reasonable voltage range as an output.
- ST-LINK USB CONNECTOR → It is the micro USB input used to load the code to the target MCU or to feed the card.
- Target MCU → It is the MCU that does what is requested in the loaded code. It controls the
 pin outputs as desired in the code, and saves the loaded code to the ROM inside. In this way,
 every time the card is powered, it constantly fulfills what is required in the code.
- Explain all the connected peripherals and their pin connections with the microcontroller.




Figure 2: NucleoG031K8 Pinout

 In this problem you are asked to write code that will light up the on-board LED connected to pin PC6.




Figure 3: Problem 2 Flowchart




Figure 4: Problem 2 Block Diagram

```
/*
 * asm.s
 * author: Emirhan Köse, Ruveyda Dilara Günal, Alperen Arslan
 */
.syntax unified
.cpu cortex-m0plus
.fpu softvfp
.thumb
/* make linker see this */
.global Reset_Handler
/* get these from linker script */
.word _sdata
.word edata
.word sbss
.word ebss
/* define peripheral addresses from RM0444 page 57, Tables 3-4 */
.equ RCC_BASE,
                 (0x40021000)
                                    // RCC base address
.equ RCC_IOPENR,
                   (RCC_BASE + (0x34)) // RCC IOPENR register
offset
.equ GPIOC_BASE, (0x50000800)
                                         // GPIOC base address
.equ GPIOC MODER, (GPIOC BASE + (0x00)) // GPIOC MODER
register offset
```

```
.equ GPIOC_ODR, (GPIOC_BASE + (0x14)) // GPIOC ODR register
offset
/* vector table, +1 thumb mode */
.section .vectors
vector table:
                      /* Stack pointer */
     .word _estack
     .word Reset_Handler +1 /* Reset handler */
     .word Default Handler +1 /* NMI handler */
     .word Default_Handler +1 /* HardFault handler */
     /* add rest of them here if needed */
/* reset handler */
.section .text
Reset_Handler:
     /* set stack pointer */
     ldr r0, = estack
     mov sp, r0
     /* initialize data and bss
      * not necessary for rom only code
      * */
     bl init_data
     /* call main */
     bl main
     /* trap if returned */
     b.
/* initialize data and bss sections */
.section .text
```

```
init_data:
     /* copy rom to ram */
     ldr r0, =_sdata
     ldr r1, =_edata
     ldr r2, =_sidata
     movs r3, #0
     b LoopCopyDataInit
     CopyDataInit:
          ldr r4, [r2, r3]
          str r4, [r0, r3]
          adds r3, r3, #4
     LoopCopyDataInit:
          adds r4, r0, r3
          cmp r4, r1
          bcc CopyDataInit
     /* zero bss */
     ldr r2, =_sbss
     ldr r4, =_ebss
     movs r3, #0
     b LoopFillZerobss
     FillZerobss:
          str r3, [r2]
          adds r2, r2, #4
     LoopFillZerobss:
           cmp r2, r4
           bcc FillZerobss
```

```
bx lr
/* default handler */
.section .text
Default_Handler:
     b Default_Handler
/* main function */
.section .text
main:
     /* enable GPIOC clock, bit2 on IOPENR */
     ldr r6, =RCC_IOPENR
     ldr r5, [r6]
     /* movs expects imm8, so this should be fine */
     movs r4, 0x4
     orrs r5, r5, r4
     str r5, [r6]
     /* setup PC6 for led 01 for bits 12-13 in MODER */
     ldr r6, =GPIOC MODER
     ldr r5, [r6]
     /* cannot do with movs, so use pc relative */
     1dr r4, =0x3000
     mvns r4, r4
     ands r5, r5, r4
     1dr r4, =0x1000
     orrs r5, r5, r4
     str r5, [r6]
     /* turn on led connected to C6 in ODR */
```

```
ldr r6, =GPIOC_ODR

ldr r5, [r6]

movs r4, 0x40

orrs r5, r5, r4

str r5, [r6]

/* for(;;); */

b .

/* this should never get executed */
nop
```

• Using a voltmeter, measure the voltage on the PC6 pin when the LED is on, and when the LED is off. Explain and justify the results.




Figure 5: Led is OFF




Figure 6: Led is ON

The Led3 is on with the help of the pc6 pin. In order to burn this led, the pc6 pin must be made high. When this pin is connected, the current goes to the base of the Q2 transistor and enables the transistor to be turned on. When this transistor is turned on, led3 becomes short with ground and the led turns on. The pc6 pin must be in the low state when the led is off, so the voltage isn't visible when measuring the voltage of the pc6 pin.

 Find out the nominal voltage and absolute maximum voltage values of your microcontroller pins.

| VDD | 3.31V |
|------|-------|
| VIN | 0.01V |
| VREF | 3.32V |

• In this problem you are asked to write code that will light up 4 external LEDs connected to the board.




Figure 7: Problem 3 Flowchart




Figure 8: Problem 3 Block Diagram

```
/*
 * asm.s
 * authors: Emirhan KÖSE, RUVEYDA DİLARA GUNAL, ALPEREN ARSLAN
 * description: Added the necessary stuff for turning on the green
LED on the
    G031K8 Nucleo board. Mostly for teaching.
 */
.syntax unified
.cpu cortex-m0plus
.fpu softvfp
.thumb
/* make linker see this */
.global Reset Handler
/* get these from linker script */
.word _sdata
.word _edata
.word _sbss
.word _ebss
/* define peripheral addresses from RM0444 page 57, Tables 3-4 */
.equ RCC_BASE, (0x40021000) // RCC base address
```

```
.equ RCC_IOPENR, (RCC_BASE + (0x34)) // RCC IOPENR register
offset
.equ GPIOB_BASE, (0x50000400) // GPIOC base address
.equ GPIOB_MODER, (GPIOB\_BASE + (0x00)) // GPIOC MODER
register offset
.equ GPIOB_ODR, (GPIOB\_BASE + (0x14)) // GPIOC ODR register
offset
/* vector table, +1 thumb mode */
.section .vectors
vector_table:
                  /* Stack pointer */
     .word _estack
     .word Reset Handler +1 /* Reset handler */
     .word Default_Handler +1 /*
                                     NMI handler */
     .word Default_Handler +1 /* HardFault handler */
     /* add rest of them here if needed */
/* reset handler */
.section .text
Reset Handler:
    /* set stack pointer */
     ldr r0, =_estack
     mov sp, r0
     /* initialize data and bss
```

```
* not necessary for rom only code
      * */
     bl init_data
     /* call main */
     bl main
     /* trap if returned */
     b.
/* initialize data and bss sections */
.section .text
init_data:
     /* copy rom to ram */
     ldr r0, =_sdata
     ldr r1, =_edata
     ldr r2, =_sidata
     movs r3, #0
     b LoopCopyDataInit
     CopyDataInit:
           ldr r4, [r2, r3]
           str r4, [r0, r3]
           adds r3, r3, #4
     LoopCopyDataInit:
           adds r4, r0, r3
           cmp r4, r1
```

```
bcc CopyDataInit
     /* zero bss */
     ldr r2, =_sbss
     ldr r4, =_ebss
     movs r3, #0
     b LoopFillZerobss
     FillZerobss:
           str r3, [r2]
           adds r2, r2, #4
     LoopFillZerobss:
           cmp r2, r4
           bcc FillZerobss
     bx lr
/* default handler */
.section .text
Default_Handler:
     b Default_Handler
/* main function */
.section .text
```

```
main:
     /* enable GPIOC clock, bit2 on IOPENR */
     ldr r6, =RCC_IOPENR
     ldr r5, [r6]
     /* r4 --> 0010 PORT B is enable*/
     movs r4, 0x2
     orrs r5, r5, r4
     str r5, [r6]
     /*mode 4 mode 5 mode 8 and mode 9 are adjusted as output 01
*/
     ldr r6, =GPIOB_MODER
     ldr r5, [r6]
     /* cannot do with movs, so use pc relative */
     ldr r4, =0xE0E00
     mvns r4, r4
     ands r5, r5, r4
     1dr r4, =0x50500
     orrs r5, r5, r4
     str r5, [r6]
     /pin 4 5 8 and 9 are output high/
     ldr r6, =GPIOB_ODR
     ldr r5, [r6]
     ldr r4,=0x330
     orrs r5, r5, r4
     str r5, [r6]
```

```
/* for(;;); */
b .
/* this should never get executed */
nop
```




Figure 9: Four leds toggle circuit

• Power off your board, then power back on. (Disconnect the cable) Are the LEDs light up again? Explain and justify the results.

The codes are written to the rom (read only memory) via st-link. We can think of Rom as a computer's memory. As the information on the disk is not lost when the computer is turned off, the information on the rom is not lost either. When the power is turned on again, the code is written in it and it continues to work in the same way.

• In this problem you are asked to write code that will light up 1 external LED connected to the board using an external push-button. Whenever the button is pressed, the LED should be on, and whenever the button is released, the LED should be off.




Figure 10: Problem 4 Flowchart




Figure 11: Problem 4 Block Diagram

```
// Q4.s
// Author: Emirhan Köse, Ruveyda Dilara Günal, Alperen Arslan
 //
.syntax unified
.cpu cortex-m0plus
.fpu softvfp
.thumb
// make linker see this
.global Reset_Handler
// get these from linker script
.word _sdata
.word _edata
.word _sbss
.word _ebss
```

```
// define clock base and enable addresses
.equ RCC BASE, (0x40021000) // RCC base address
.equ RCC_IOPENR, (RCC_BASE + (0x34)) // RCC IOPENR register
offset
// define GPIO Base, Moder and ODR pin addresses
.equ GPIOB BASE, (0x50000400)
                                     // GPIOB base address
.equ GPIOB_MODER, (GPIOB_BASE + (0x00)) // GPIOB MODER
register offset
.equ GPIOB_IDR, (GPIOB\_BASE + (0x10)) // GPIOB IDR register
offset
offset
// vector table, +1 thumb mode
.section .vectors
vector table:
                    // Stack pointer
    .word estack
    .word Reset_Handler +1 // Reset handler
    .word Default Handler +1 //
                                  NMI handler
    .word Default_Handler +1 // HardFault handler
    // add rest of them here if needed
// reset handler
.section .text
Reset Handler:
    // set stack pointer
    ldr r0, = estack
```

```
mov sp, r0
     // initialize data and bss
     // not necessary for rom only code
     bl init_data
     // call main
     bl main
     // trap if returned
     b.
// initialize data and bss sections
.section .text
init_data:
     // copy rom to ram
     ldr r0, =_sdata
     ldr r1, =_edata
     ldr r2, =_sidata
     movs r3, #0
     b LoopCopyDataInit
     CopyDataInit:
          ldr r4, [r2, r3]
          str r4, [r0, r3]
          adds r3, r3, #4
```

```
LoopCopyDataInit:
           adds r4, r0, r3
           cmp r4, r1
           bcc CopyDataInit
     // zero bss
     ldr r2, =_sbss
     ldr r4, =_ebss
     movs r3, #0
     b LoopFillZerobss
     FillZerobss:
           str r3, [r2]
           adds r2, r2, #4
     LoopFillZerobss:
           cmp r2, r4
           bcc FillZerobss
     bx lr
// default handler
.section .text
Default_Handler:
     b Default_Handler
// main function
```

```
.section .text
main:
     // enable GPIOB clock, bit1 on IOPENR
     ldr r6, =RCC_IOPENR
     ldr r5, [r6]
     // movs expects imm8, so this should be fine
     movs r4, 0x2
     orrs r5, r5, r4
     str r5, [r6]
     // setup PB4 and PB5 for button and led 01 and 00 in MODER
     ldr r6, =GPIOB_MODER
     ldr r5, [r6]
     // cannot do with movs, so use pc relative
     1dr r4, = [0x30300]
     bics r5, r5, r4
     ldr r4, =[0xCFDFF]
     orrs r5, r5, r4
     str r5, [r6]
     // turn on led connected PB5 if button is pressed
loop:
     ldr r6, = GPIOB_IDR
     ldr r5, [r6] //IDR Value
     lsrs r5, r5, #8 // Shifting to first bit
     movs r4, #0x1
```

```
ands r5, r5, r4 //Getting the value of button pressed or not
cmp r5, #0x1 //Compare IDR Value with 1 bit
bne BNE //If not equal
beq BEQ //If equal
//If is equal
BEQ:
ldr r6, = GPIOB\_ODR
ldr r5, [r6] //ODR Value
movs r4, 0x10
orrs r5, r5, r4 //Setting led on
str r5, [r6]
b loop
//If is not equal
BNE:
ldr r6, = GPIOB\_ODR
ldr r5, [r6] //ODR Value
movs r4, 0x10
bics r5, r5, r4 //Setting led off
str r5, [r6]
b loop
/* this should never get executed */
nop
```




Figure 12: When push button




Figure 13: When not push button

 Using an oscilloscope, capture your button press, and see if you can spot any bouncing happening. Include a picture of this setup and capture in your report and comment on the result. Try with different buttons if you have more than one and compare the results.



Figure 14: Voltage signal on the led button 1 circuit




Figure 15: Voltage signal on the led button 2 circuit

When the button is not pressed, the value dec the anode and cathode of the led is 0 volts. When the button is pressed, this value will change from 0 volts to 3.3 volts. But since the state of the button is not stable during this transition, it dec to a random volt value for a short time between 0 and 3.3 volts

In this problem you are asked to write code that will blink 1 external LED at roughly 1 second intervals.




Figure 16: Problem 5 Flowchart




Figure 17: Problem 5 Block Diagram

```
/*
* asm.s
* author: Furkan Cayci
* description: Added the necessary stuff for turning on the green LED on the
* G031K8 Nucleo board. Mostly for teaching.
*/
.syntax unified
.cpu cortex-m0plus
.fpu softvfp
.thumb
/* make linker see this */
.global Reset_Handler
```

```
/* get these from linker script */
.word sdata
.word _edata
.word sbss
.word _ebss
/* define peripheral addresses from RM0444 page 57, Tables 3-4 */
.equ RCC_BASE, (0x40021000) // RCC base address
.equ RCC IOPENR, (RCC BASE + (0x34)) // RCC IOPENR register offset
.equ GPIOB_BASE, (0x50000400) // GPIOC base address
.equ GPIOB_MODER, (GPIOB_BASE + (0x00)) // GPIOC MODER register offset
.equ GPIOB ODR, (GPIOB BASE + (0x14)) // GPIOC ODR register offset
/* vector table, +1 thumb mode */
.section .vectors
vector_table:
      .word _estack /* Stack pointer */
      .word Reset_Handler +1 /* Reset handler */
      .word Default Handler +1 /* NMI handler */
      .word Default_Handler +1 /* HardFault handler */
      /* add rest of them here if needed */
/* reset handler */
.section .text
Reset_Handler:
```

```
/* set stack pointer */
       Idr r0, =_estack
       mov sp, r0
       /* initialize data and bss
        * not necessary for rom only code
        * */
       bl init_data
       /* call main */
       bl main
       /* trap if returned */
       b.
/* initialize data and bss sections */
.section .text
init_data:
       /* copy rom to ram */
       ldr r0, =_sdata
       ldr r1, =_edata
       ldr r2, =_sidata
       movs r3, #0
       b LoopCopyDataInit
       CopyDataInit:
               ldr r4, [r2, r3]
               str r4, [r0, r3]
```

```
adds r3, r3, #4
       LoopCopyDataInit:
              adds r4, r0, r3
              cmp r4, r1
              bcc CopyDataInit
       /* zero bss */
       ldr r2, =_sbss
       Idr r4, =_ebss
       movs r3, #0
       b LoopFillZerobss
       FillZerobss:
              str r3, [r2]
              adds r2, r2, #4
       LoopFillZerobss:
              cmp r2, r4
              bcc FillZerobss
       bx Ir
/* default handler */
.section .text
Default_Handler:
       b Default_Handler
```

```
/* main function */
.section .text
main:
       /* enable GPIOB clock, bit2 on IOPENR */
       ldr r6, =RCC_IOPENR
       Idr r5, [r6]
       /* movs expects imm8, so this should be fine */
       movs r4, 0x2
       orrs r5, r5, r4
       str r5, [r6]
       /* setup PC6 for led 01 for bits 12-13 in MODER */
       ldr r6, =GPIOB_MODER
       ldr r5, [r6]
       /* cannot do with movs, so use pc relative */
       movs r4, 0x3
       Isls r4, r4, #8
       bics r5, r5, r4
       movs r4, 0x1
       Isls r4, r4, #8
       orrs r5, r5, r4
       str r5, [r6]
       /* turn on led connected to C6 in ODR */
       ldr r6, =GPIOB_ODR
       Idr r5, [r6]
```

```
movs r4, 0x1
       Isls r4, r4, #4
       orrs r5, r5, r4
       str r5, [r6]
loop:
       //turn on led connected to PB4 in ODR
       ldr r6, =GPIOB_ODR
       ldr r5, [r6]
       movs r4, 0x1
       Isls r4, r4, #4
       orrs r5, r5, r4
       str r5, [r6]
       ldr r1, =#1000000
       bl delay
       //turn off led connected to PB4 in ODR
       ldr r6, =GPIOB_ODR
       Idr r5, [r6]
       movs r4, 0x1
       Isls r4, r4, #4
       bics r5, r5, r4
       str r5, [r6]
       ldr r1, =#10000000
       bl delay
```

b loop

delay:

subs r1, r1, #1

bne delay

bx lr

//this should never get executed

nop

 Using an oscilloscope, capture and measure the blink interval. This should be around 1 sec.



Figure 18: Voltage signal on the led

It has been observed that the image appears when measuring the voltage signal on the external led leg in the blink circuit is about 2 volts when the led is on and 0 volts when it goes out. The time/div ratio was set to 200ms, and it was observed that the led burned out 980ms and went out 980ms. Then the code was changed and the led was set to light 1 time per second.

Try to estimate the CPI (Cycles per Instruction) and comment/justify the results.

$$CPI = \frac{5 * 43 + 4 * 12 + 4 * 31 + 3 * 12}{100}$$
$$= 4.23$$

Conclusion

In this project, the functions of the components on the stm32g031k card were written first. Then, the Id3 led on the board was burned by giving high to the PC6 pin. The high and low states of the PC6 pin were measured with a multimeter. Then, 4 external LEDs were connected to different pins and lit. It has been observed here that the codes are not cleared when the power is turned on again after the power is turned off. Then an external LED was lit thanks to a button. It has been observed that when the button is pressed, the led lights up, and when it is not pressed, the led does not light up. Here, the voltage signal between the anode and the cathode of the led was observed by pressing and pulling the button with the help of an oscilloscope. When the voltage signal is examined, since the button changes from 0 to 1, the signal deviates to random voltages at intermediate values. Finally, the voltage signal between the anode and cathode of the led was measured by flashing an external led once per second. Here the voltage is 0 volts when the led is off. When the LED is lit, the voltage value of the LED is seen as 2 volts. The duration of these values is 980 ms. ie 980ms in high mode and 980ms in low mode. Then, by playing on the code, these times decreased and the led started to blink once a second.

Reference

https://github.com/fcayci/stm32g0

https://www.st.com/content/ccc/resource/technical/layouts and diagrams/schematic pac k/group1/05/c3/27/2a/6b/db/41/f1/MB1455-G031K8-C01 Schematic/files/MB1455-G031K8-C01 Schematic.pdf/jcr:content/translations/en.MB1455-G031K8-C01 Schematic.pdf

https://www.st.com/resource/en/reference manual/rm0444-stm32g0x1-advanced-armbased-32bit-mcus-stmicroelectronics.pdf