
Name – Aryan Gupta

Roll No -MT22154

Lab no -11

## Advanced Embedded Logic Design

## Block Diagram: -



## Code:-

```
Use of the Software is limited solely to applications:
  (a) running on a Xilinx device, or
 ' (b) that interact with a Xilinx device through a bus or interconnect.
* THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
 IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
* FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL
 XILINX BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY,
 WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF
 OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE
 SOFTWARE.
* Except as contained in this notice, the name of the Xilinx shall not be used
' in advertising or otherwise to promote the sale, use or other dealings in
 this Software without prior written authorization from Xilinx.
 * helloworld.c: simple test application
 * This application configures UART 16550 to baud rate 9600.
 * PS7 UART (Zynq) is not initialized by this application, since
 * bootrom/bsp configures it to baud rate 115200
 * | UART TYPE BAUD RATE
 * uartns550 9600
 * uartlite Configurable only in HW design

* ps7_uart 115200 (configured by bootrom/bsp)
#include <stdio.h>
#include <stdlib.h>
#include "xaxidma.h"
#include "xparameters.h"
#include "platform.h"
#include<xtime 1.h>
#include "xmatmul_mm_sp.h"
#define INP SIZE 8
#define MATSIZE 8
#define MEM BASE ADDR
                          0x01000000
#define TX_BD_SPACE_BASE
                           (MEM_BASE_ADDR)
#define RX_BD_SPACE_BASE
                           (MEM_BASE_ADDR + 0x00001000)
#define RX_BUFFER_BASE
                            (MEM_BASE_ADDR + 0x00300000)
int SGDMA RxSetup(XAxiDma * AxiDmaInstPtr, u32 No of BDs);
```

```
int SGDMA_TxSetup(XAxiDma * AxiDmaInstPtr, u32 No_of_BDs);
float Find input A[8][8];
float Find input B[8][8];
float Find_outputps[8][8];
float Find output1[8][8];
float Find output2[8][8];
float Find_output3[8][8];
float DMA_input1[INP_SIZE*INP_SIZE*2];
void input()
{
    printf("What is going on\n");
    for (int i=0;i<INP SIZE;i++)</pre>
                            for(int j=0; j<INP_SIZE; j++)</pre>
                                Find_input_A[i][j]= (rand()%20);
                                Find_input_B[i][j]= (rand()%20);
                        }
void PS()
    float Find_outputps[INP_SIZE][INP_SIZE];
    XTime time_PS_start , time_PS_end;
    XTime SetTime(0);
    XTime_GetTime(&time_PS_start);
    for(int i=0; i<MATSIZE; i++)</pre>
        for(int j=0; j<MATSIZE; j++)</pre>
            float res=0;
            for(int index=0; index<MATSIZE; index++)</pre>
                res+=Find_input_A[i][index]*Find_input_B[index][j];
            Find_outputps[i][j]=res;
    XTime_GetTime(&time_PS_end);
    printf("\n-----\n");
                                                  float time_PS = 0;
                                                  time PS = (float)1.0 *
(time_PS_end - time_PS_start) / (COUNTS_PER_SECOND/1000000);
                                                  printf("Execution Time for
PS in Micro-Seconds : %f\n" , time_PS);
    for(int row=0; row<MATSIZE; row++)</pre>
            for( int col=0; col<MATSIZE; col++)</pre>
```

```
printf("Input A %f, Input B
%f\n",Find_input_A[row][col],Find_input_B[row][col]);
    for(int row=0; row<MATSIZE; row++)</pre>
                 for(int col=0; col<MATSIZE; col++)</pre>
                     printf("Output %f\n",Find_outputps[row][col]);
            }
int Find_ACP1()
    float Find output DMA[INP SIZE*INP SIZE];
    int status;
     XAxiDma_Config *DMA_confptracp; //DMA configuration pointer
     XAxiDma AxiDMAacp; // DMA instance pointer
     DMA_confptracp = XAxiDma_LookupConfig(XPAR_AXI_DMA_0_DEVICE_ID);
     status = XAxiDma_CfgInitialize(&AxiDMAacp, DMA_confptracp);
     if(status != XST_SUCCESS)
        printf("ACP DMA Init Failed\t\n");
        return XST_FAILURE;
     XTime time_ACP_start , time_ACP_end;
                  XTime_SetTime(0);
                  XTime_GetTime(&time_ACP_start);
            int index=0;
            for(int row=0; row<MATSIZE; row++)</pre>
                 for(int col=0; col<MATSIZE; col++)</pre>
                     DMA_input1[index]=Find_input_A[row][col];
                     index++;
            for(int row=0; row<MATSIZE; row++)</pre>
                 for(int col=0; col<MATSIZE; col++)</pre>
                     DMA_input1[index]=Find_input_B[row][col];
                     index++;
            for(int i=0; i<INP_SIZE*INP_SIZE*2; i++)</pre>
```

```
printf("Input %f \n ",DMA_input[i]);
               status = XAxiDma SimpleTransfer(&AxiDMAacp,
(UINTPTR)Find_output_DMA,(sizeof(float)*INP_SIZE*INP_SIZE),XAXIDMA_DEVICE_TO_D
MA);
               status = XAxiDma SimpleTransfer(&AxiDMAacp,
(UINTPTR)DMA_input1,
(sizeof(float)*INP_SIZE*INP_SIZE*2),XAXIDMA_DMA_TO_DEVICE);
               status = XAxiDma_ReadReg(XPAR_AXI_DMA_0_BASEADDR,0x04) &
0x00000002;
               while(status!=0x00000002)
                 status = XAxiDma_ReadReg(XPAR_AXI_DMA_0_BASEADDR,0x04) &
0x00000002;
               status = XAxiDma ReadReg(XPAR AXI DMA 0 BASEADDR,0x34) &
0x00000002;
              while(status!=0x00000002)
                status = XAxiDma_ReadReg(XPAR_AXI_DMA_0_BASEADDR,0x34) &
0x00000002;
              XTime_GetTime(&time_ACP_end);
                              printf("\n-----ACP FPGA EXECUTION TIME----
       ----\n");
                                  float time_ACPFPGA = 0;
                                  time_ACPFPGA = (float)1.0 * (time_ACP_end -
time_ACP_start) / (COUNTS_PER_SECOND/1000000);
                                  printf("Execution Time for ACP FPGA in
Micro-Seconds : %f\n" , time_ACPFPGA);
                                  for(int i = 0; i<INP_SIZE*INP_SIZE; i++)</pre>
                                      printf("Output :
%f\n",Find_output_DMA[i]);
                                  index=0;
                            for(int row=0; row<MATSIZE; row++)</pre>
                                             for(int col=0; col<MATSIZE; col++)</pre>
                                                 Find_output1[row][col]=Find_ou
tput_DMA[index];
                                                 index++;
                                         }
     return 0;
```

```
int Find_ACP2()
    int status;
    float DMA_input[MATSIZE*MATSIZE*2];
    u32 No of BDs=1;
    XAxiDma AxiDMAsg;
    XAxiDma_Config *DMA_confptrsg;
    DMA_confptrsg = XAxiDma_LookupConfig(XPAR_AXI_DMA_1_DEVICE_ID);
    status = XAxiDma_CfgInitialize(&AxiDMAsg, DMA_confptrsg);
    if(status != XST_SUCCESS)
        printf("DMA SG Init Failed\t\n");
        return XST_FAILURE;
    if(!XAxiDma HasSg(&AxiDMAsg))
        xil_printf("Device configured as Simple mode \r\n");
        return XST_FAILURE;
    status = SGDMA_TxSetup(&AxiDMAsg, No_of_BDs);
    if (status != XST_SUCCESS)
        return XST_FAILURE;
    status = SGDMA_RxSetup(&AxiDMAsg, No_of_BDs);
    if (status != XST_SUCCESS)
        return XST_FAILURE;
        int index=0;
        for(int row=0;row<MATSIZE;row++)</pre>
            for(int col=0;col<MATSIZE;col++)</pre>
                DMA_input[index]=Find_input_A[row][col];
                index=index+1;
        for(int row=0;row<MATSIZE;row++)</pre>
            for(int col=0;col<MATSIZE;col++)</pre>
                DMA_input[index]=Find_input_B[row][col];
                index=index+1;
        XAxiDma_BdRing *TxRingPtr;
        XAxiDma BdRing *RxRingPtr;
```

```
XAxiDma Bd *TxBdPtr, *RxBdPtr;
        RxRingPtr = XAxiDma GetRxRing(&AxiDMAsg);
        status = XAxiDma BdRingAlloc(RxRingPtr, 1, &RxBdPtr);
        if (status != XST_SUCCESS) {
            xil printf("RX alloc BD failed %d\r\n", status);
            return XST FAILURE;
        UINTPTR RxBufferPtr;
        RxBufferPtr = RX BUFFER BASE;
        status = XAxiDma_BdSetBufAddr(RxBdPtr, RxBufferPtr);
        if (status != XST_SUCCESS)
            xil printf("Set buffer addr %x on BD %x failed %d\r\n",
                (unsigned int)RxBufferPtr, (UINTPTR)RxBdPtr, status);
            return XST FAILURE;
        }
        status = XAxiDma BdSetLength(RxBdPtr, (sizeof(float)*MATSIZE*MATSIZE),
                RxRingPtr->MaxTransferLen);
        if (status != XST SUCCESS)
            xil_printf("Rx set length %d on BD %x failed %d\r\n",
                    (sizeof(float)*MATSIZE*MATSIZE), (UINTPTR)RxBdPtr,
status);
            return XST_FAILURE;
        XAxiDma BdSetCtrl(RxBdPtr, 0);
        XAxiDma_BdSetId(RxBdPtr, RxBufferPtr);
        memset((void *)RX_BUFFER_BASE, 0, (sizeof(float)*MATSIZE*MATSIZE));
        TxRingPtr = XAxiDma GetTxRing(&AxiDMAsg);
        status = XAxiDma_BdRingAlloc(TxRingPtr, 1, &TxBdPtr);
        if (status != XST_SUCCESS)
            return XST_FAILURE;
        status = XAxiDma_BdSetBufAddr(TxBdPtr, (UINTPTR) DMA_input);
        if (status != XST_SUCCESS)
            xil printf("Tx set buffer addr %x on BD %x failed
%d\r\n",(UINTPTR)DMA_input, (UINTPTR)TxBdPtr, status);
            return XST_FAILURE;
        status = XAxiDma BdSetLength(TxBdPtr,
(sizeof(float)*MATSIZE*MATSIZE*2),TxRingPtr->MaxTransferLen);
        if (status != XST_SUCCESS)
            xil_printf("Tx set length %d on BD %x failed
%d\r\n",(sizeof(float)*MATSIZE*MATSIZE*2), (UINTPTR)TxBdPtr, status);
            return XST FAILURE;
```

```
XAxiDma BdSetCtrl(TxBdPtr, XAXIDMA BD CTRL TXEOF MASK |
XAXIDMA BD CTRL TXSOF MASK);
        XAxiDma BdSetId(TxBdPtr, (UINTPTR)DMA input);
        int Txcount, Rxcount;
        XTime time_PL_start , time_PL_end;
        XTime_SetTime(0);
        XTime_GetTime(&time_PL_start);
        status = XAxiDma BdRingToHw(RxRingPtr, 1, RxBdPtr);
        if (status != XST_SUCCESS)
            xil printf("RX submit hw failed %d\r\n", status);
            return XST_FAILURE;
        status = XAxiDma BdRingToHw(TxRingPtr, 1, TxBdPtr);
        if (status != XST SUCCESS) {
            xil_printf("to hw failed %d\r\n", status);
            return XST_FAILURE;
        while(!(XAxiDma BdRead(TxBdPtr,
XAXIDMA_BD_STS_OFFSET)&XAXIDMA_BD_STS_COMPLETE_MASK));
        while(!(XAxiDma_BdRead(RxBdPtr,
XAXIDMA_BD_STS_OFFSET)&XAXIDMA_BD_STS_COMPLETE_MASK));
        XTime_GetTime(&time_PL_end);
        Txcount = XAxiDma_BdRingFromHw(TxRingPtr,1, &TxBdPtr);
        Rxcount = XAxiDma_BdRingFromHw(RxRingPtr,1, &RxBdPtr);
        status = XAxiDma_BdRingFree(TxRingPtr, Txcount, TxBdPtr);
        if (status != XST_SUCCESS) {
            xil_printf("Failed to free %d tx BDs %d\r\n",Txcount, status);
            return XST_FAILURE;
        status = XAxiDma BdRingFree(RxRingPtr, Rxcount, RxBdPtr);
        if (status != XST_SUCCESS) {
            xil_printf("Failed to free %d rx BDs %d\r\n",Rxcount, status);
            return XST_FAILURE;
        float time_w = ((float)1.0 * (time_PL_end - time_PL_start) /
(COUNTS PER SECOND/1000000));
        printf("Execution Time for for SG DMA based PL: %f\n",time w);
        index =0;
        float *DMA_output2 = (float *) RX_BUFFER_BASE;
        for(int row=0;row<MATSIZE;row++)</pre>
            for(int col=0;col<MATSIZE;col++)</pre>
                Find_output2[row][col] = DMA_output2[index];
                index = index+1;
```

```
}
      return 0;
int Find ACP3()
    float Find_output_DMA[INP_SIZE*INP_SIZE];
    XMatmul_mm_sp AxiMM1;
    XMatmul_mm_sp_Config *MM_confptr1;
    MM_confptr1 = XMatmul_mm_sp_LookupConfig(XPAR_MATMUL_MM_SP_0_DEVICE_ID);
    int status = XMatmul_mm_sp_CfgInitialize(&AxiMM1,MM_confptr1);
    XTime time_PL_start , time_PL_end;
    XTime SetTime(0);
    XTime_GetTime(&time_PL_start);
    XMatmul_mm_sp_Set_Matrix_In(&AxiMM1,(u32)DMA_input1);
    XMatmul mm sp Set Matrix C HW(&AxiMM1,(u32)Find output DMA);
    XMatmul mm sp Start(&AxiMM1);
    while(XMatmul_mm_sp_IsDone(&AxiMM1)==0)
    XTime_GetTime(&time_PL_end);
    float time MM = 0;
    time_MM = (float)1.0 * (time_PL_end - time_PL_start) /
(COUNTS_PER_SECOND/1000000);
    printf("Execution Time for AXI MM Matrix mul FPGA in Micro-Seconds : %f\n"
, time_MM);
    for(int i = 0; i<INP_SIZE*INP_SIZE; i++)</pre>
            printf("Output : %f\n",Find_output_DMA[i]);
    int index=0;
    for(int row=0;row<MATSIZE;row++)</pre>
        for(int col=0;col<MATSIZE;col++)</pre>
            Find_output3[row][col] = Find_output_DMA[index];
            index = index+1;
     return 0;
int compare1()
    for(int i=0; i<MATSIZE; i++)</pre>
        for(int j=0; j<MATSIZE; j++)</pre>
            if(Find_output1[i][j]-Find_outputps[i][j]>0.001)
                return 0;
```

```
return 1;
int compare2()
    for(int i=0; i<MATSIZE; i++)</pre>
        for(int j=0; j<MATSIZE; j++)</pre>
             if(Find_output2[i][j]-Find_outputps[i][j]>0.001)
                 return 0;
    return 1;
int compare3()
    for(int i=0; i<MATSIZE; i++)</pre>
        for(int j=0; j<MATSIZE; j++)</pre>
            if(Find_output3[i][j]-Find_outputps[i][j]>0.001)
                 return 0;
    return 1;
int main()
    init_platform();
    input();
    PS();
    Find_ACP1();
    Find_ACP2();
    Find_ACP3();
    int ans=compare1();
    int ans1=compare2();
    int ans2=compare3();
    if(ans==1)
        printf("You are great\n");
    else
```

```
printf("No good at all\n");
    if(ans1==1)
        printf("You are great\n");
    else
        printf("No good at all\n");
    if(ans2==1)
        printf("You are great\n");
    else
        printf("No good at all\n");
    return 0;
int SGDMA_RxSetup(XAxiDma * AxiDmaInstPtr, u32 No_of_BDs)
   XAxiDma_BdRing *RxRingPtr;
   int status;
    XAxiDma_Bd BdTemplate;
    RxRingPtr = XAxiDma_GetRxRing(AxiDmaInstPtr);
    XAxiDma_BdRingIntDisable(RxRingPtr, XAXIDMA_IRQ_ALL_MASK);
    status = XAxiDma_BdRingCreate(RxRingPtr,
RX_BD_SPACE_BASE,RX_BD_SPACE_BASE, XAXIDMA_BD_MINIMUM_ALIGNMENT, No_of_BDs);
    if (status != XST_SUCCESS) {
        xil_printf("RX create BD ring failed %d\r\n", status);
        return XST_FAILURE;
    XAxiDma_BdClear(&BdTemplate);
    status = XAxiDma_BdRingClone(RxRingPtr, &BdTemplate);
    if (status != XST_SUCCESS)
        xil_printf("RX clone BD failed %d\r\n", status);
       return XST_FAILURE;
    status = XAxiDma_BdRingStart(RxRingPtr);
    if (status != XST_SUCCESS)
        xil_printf("RX start hw failed %d\r\n", status);
        return XST_FAILURE;
    return XST SUCCESS;
```

```
int SGDMA_TxSetup(XAxiDma * AxiDmaInstPtr, u32 No_of_BDs)
   XAxiDma_BdRing *TxRingPtr;
   XAxiDma Bd BdTemplate;
    int status;
    TxRingPtr = XAxiDma_GetTxRing(AxiDmaInstPtr);
   XAxiDma_BdRingIntDisable(TxRingPtr, XAXIDMA_IRQ_ALL_MASK);
    status = XAxiDma_BdRingCreate(TxRingPtr, TX_BD_SPACE_BASE,
TX_BD_SPACE_BASE, XAXIDMA_BD_MINIMUM_ALIGNMENT, No_of_BDs);
    if (status != XST_SUCCESS)
        xil_printf("failed create BD ring in txsetup\r\n");
       return XST FAILURE;
   XAxiDma_BdClear(&BdTemplate);
    status = XAxiDma_BdRingClone(TxRingPtr, &BdTemplate);
    if (status != XST_SUCCESS)
       xil_printf("failed bdring clone in txsetup %d\r\n", status);
       return XST_FAILURE;
    status = XAxiDma_BdRingStart(TxRingPtr);
    if (status != XST_SUCCESS)
        xil_printf("failed start bdring txsetup %d\r\n", status);
        return XST_FAILURE;
    return XST_SUCCESS;
```

