#### PROPOSAL FOR THE IMLAC PDS1 SOFTWARE SYSTEM

H. van der Beken, B. Carpenter, S. Jupp, W. Remmer

#### Introduction

Outline proposals for the PDS1 software were given in a previous note (MPS/CO Computer 71-1). This note gives more details of the general software to be implemented for communication between the IBM 1800 and the mini-computers, and for display generation in the mini-computers. The programs are now being written on the basis of these proposals and it is hoped that they will be operational in late summer.

The general software will consist of four main parts:

- 1) assembler program for PDS1 assembly language
- 2) programs and routines to use the disc file on which PDS1 coreloads will be stored
- 3) communications routines in the IBM
- 4) the 1 K EXECutive in the PDS1's.

Documentation will be organized by E. Ratcliff and will consist of three main parts:

- a) assembler manual
- b) programmer's guide to EXEC and communications procedures
- c) subroutine descriptions.

A few copies of the manufacturer's manuals will be available for borrowing. In general only the hardware aspects of these are relevant.

#### Assembler program

The assembler will run in the V-core of the IBM as a background-processing job. It will read in a program punched on cards in a language based on the manufacturer's assembly language. PDS1 object code will be created and the program can be listed on the line printer. If no errors occur during assembly, it will be possible to build the object code into a PDS1 coreload (PCL) and store it on the PCL disc file for subsequent execution.

Programs will be assembled absolutely and will not be relocatable. There will be no CALL facility for subroutines, which must be included as cards unless they are in the EXEC. There will be no LOCAL facility but the user may organize his own overlay if required.

It will not be possible to test a program unless it has first been stored on the PCL file.

## Disc file

The PDS1's have been provisionally assigned 80 sectors of disc space, most of which will be available for PCL storage. Programs will be written to create the PCL file and to list its contents. Routines will be written to delete a particular PCL, to write a new PCL into the file and to read a PCL from the file into core.

Space in the file is restricted; there is room, for example, for approximately 23 PCL of 1 K each.

## IBM communications routines

Each PDS1 will be able to send an interrupt bit to the IBM. When this occurs, an ISSR will read a 16 bit status word in the PDS1 interface. Fig. 1 shows the bits so far assigned in this status word.

provident special contraction of the special con			PIV	PDS1 Interface Violation. This				
15	PIV			bit indicates that the software has attempted to transmit data in				
14	PRQ	Cause interrupt		the wrong direction				
13	RCS		PRQ	PDS1 Requests. The PDS1 wishes to transmit to the IBM				
12	TCP		RCS	Requests Cold Start. The PDS1 requests the IBM to transmit its				
11	READY			cold start program				
10	ON-LINE		TCP	Transmission Complete				

Fig. 1

When the PIV bit is detected, the ISSR in the IBM should attempt a PDS1 restart. If this fails it should try a reload, and if this fails it should switch to the back-up PDS1. The next call to the transmission subroutines (see below) would return an error code.

When the PRQ bit is detected, the ISSR will read in one word of data from the PDS1. The top 8 bits of this will be a control function and the bottom 8 bits will normally be a word count. If the control function specifies "queue coreload" the IBM coreload specified in the queue indicator (see below) will be queued. If it specifies "abort" appropriate action will be taken. Otherwise the control function and word count will be passed over to the coreload using the PDS1 via the interrupt indicator (see below). In this case the control function will specify what type of file is waiting in the PDS1 for transmission to the partition (see Appendix).

Two skeleton flags are needed:

SKF1: Interrupt indicator
Zero when no PRQ received
Non-zero when PRQ received and action is required by
partition. Actually contains a control function and
word count

SKF2: Queue indicator.

Routines will be provided for transmitting files between a partition and a PDS1. The probable set of routines is:

- 1) read a specified PCL from disc, transmit to a PDS1
- 2) transmit a user-provided file to a PDS1. Useful file length up to approximately 240 words. The user must supply a control function and word count. See Appendix for control functions.
  - (N.B. This routine will replace or duplicate CODDW, CPLOC, CPLOP, etc. Multiple entries may be provided if this seems more convenient.)
- 3) receive a file from a PDS1. Useful length up to approximately 240 words. Control function and word count were provided in SKF2; user must decode control function.

These routines and the ISSR will all be in the 1800 Executive and will share a word indicating the busy/free and OK/broken status of each PDS1, so that back-up operations will be carried out automatically.

#### PDS1 EXECutive

The resident software in the PDS1 will consist of approximately 1 K of code and tables, leaving another 1 K for the USER program. The EXEC will be capable of generating a display and of transmitting operator responses to the IBM, but more complex operations, e.g. checking the syntax of an operator response, would require a USER program. EXEC will consist of three main parts: a monitor, an interrupt servicing routine, and a set of routines.

## 1. Monitor

The monitor will be a short program which will check certain software flags and will carry out actions requested by the IBM or the keyboard. The monitor will be in subroutine form so that the USER

program can employ it if required, and when no USER program is running, the monitor will loop continuously. This arrangement ensures that although the IBM and the keyboard are serviced at interrupt level, the display update routines are called only from mainline level.

# 2. <u>Interrupt servicing routine</u>

There is only one interrupt level and therefore only one interrupt servicing routine, which handles the following devices:

- a) AIP (IBM Accept Input interrupt)
  Reads in a file from the IBM and acts according to the control function bits at the head of the file (see Appendix)
- b) 33 <sup>1</sup>/3 Hz synchronization
  Starts next frame of display.
  Checks keyboard. If set, reads character. If recognized control character, acts accordingly (see Appendix). If unrecognized control character, escapes to USER. If not control character, converts to EBCDIC, sets flag and returns to mainline.

Moves cursor, if required by relevant SKF.

c) Any other interrupt - escape to USER.

## 3. Subroutines

Subroutines do not preserve the accumulator, which is often used to pass parameters across. Subroutines are non-reentrant and must be called from mainline level only.

A provisional list of subroutines is:

ERMON	Error subroutine
INSCH } DELCH	Single character insert and delete
INSST }	Multiple character insert and delete (uses packed EBCDIC)

DRXYL DELXY Draw and delete horizontal or vertical line
DRGRA Draw graph (see below)
DELGR Delete graph
CLSCR Clear screen (except system area)
TRFIL Transmit a file to IBM

DRGRA is rather complex. For book-keeping purposes, each set of axes and each graph on that set of axes will be numbered. The following parameters are required for each set of axes:

(USER supplies control function, word count).

- a) book-keeping number
- b) origin, given as a position on the character-matrix
- c) length of axes, given in character-matrix units
- d) range of x and y values, i.e. values to be assigned to extremities of axes
- e) number of subdivisions of each axis
- f) labels for each axis.

For each graph we require:

- a) book-keeping number
- b) histogram or point plot
- c) list of pairs of (x,y) values.

This standard version of DRGRA will be placed at the end of EXEC. If a user requires a version capable of drawing continuous curves (which would extend beyond the 1 K boundary of EXEC), he can overlay the end of EXEC with a program containing his own DRGRA. In this case the USER program must exit by forcing a cold start rather than by returning to the monitor loop.

# General procedures

Initially a program request will cause a program to be queued to the partition in the normal way. A standard program request unit will be mounted near each PDS1 display as they may act as back-up units for each other. Procedures after this will be chosen for each application, so as to compromise between (e.g.) operator waiting time and partition usage. Some examples are shown in Fig. 2 (PCL = PDS1 coreload, ICL = IBM partition coreload).

## Distribution

- CO Computer Section
- E. Asséo
- S. Battisti
- G. Baribaud
- G. Benincasa
- M. Bouthéon
- C. Bovet
- G. Brianti
- G. Daems
- A. Daneels
- D. Dekkers
- P. Heymans
- F. Hofmeister

Frank James

- H. Koziol
- P. Lefèvre
- J.H.B. Madsen
- A. Millich
- K.O.H. Pedersen
- K.H. Reich
- Ch. Serre
- G. Shering
- K. Schind1
- P.H. Standley
- U. Tallgren



# Control functions for files from IBM to PDS1 (8 bits)

00000000 Cold start program

Oxxxxxxx Undefined (escape to USER)

10 Binary file follows:

10xxxx Load into core, set SKF and return to mainline

llxxxx Load into core and enter

Oxxxxx Load into core and wait for chained file

EBCDIC or Graphical file follows:

Oxxxxx EBCDIC

1xxxxx Graphical

x0xxxx Load into buffer, set SKF and return to mainline

1x10xxx Display (via monitor) and return to mainline

|x11xxx Display (via monitor) and return to mainline. Set "return changes made". Monitor will store changes made from keyboard and transmit them to the IBM when

TRANSMIT key is pressed

# Control functions for files from PDS1 to IBM (8 bits)

00000000 Not allowed

Oxxxxxxx Undefined (passed to partition)

100xxxxx Abort

101xxxxx Queue as per queue indicator

11'

O0xxxx Changed characters file

01xxxx EBCDIC

110xxxx STARC format

Illxxxx Section of display list (for saving a reference curve)

## Control key allocations

↑↓→ Initiate cursor movement

CONT 5 Rapid cursor movement (normally single shot)

CONT 6 Stop cursor movement

HOME Cursor home

CR or LF New line (end of statement)

TAB Skip to 2nd column of display

DEL Delete, cancel, ignore. Converted to -1

TRANSMIT Send changes to IBM

## Two-key allocations

Abort program, transmit abort request to IBM, return to

EXEC monitor

↑B Change to back-up keyboard.

This leaves 8 control keys and about 30 two-key combinations free for user allocation.

P R O G R	ICL 1 queued to position	Wait	ICL 1 loads PCL 1 into PDS 1 exits	PCL 1 conducts discussion (partition free)	PCL 1 requests ICL n to be queued (n depends on discussion	Wait	ICL n communicates with PCL 1	PCL 1 exits ICL computes (PDS 1 free)		Data displayed (Partition & PDS 1 free)
A M R E			ICL 1 loads PCL 1, sets SKF 3 ICL 2, exits	PCL 1 conducts discussion (partition free)	PCL 1 sends PRQ	Wait	ICL 2 communicates with PCL 1			
Q U E S			ICL 1 loads PCL 1, starts computing	PCL 1 & ICL 1 compute, communicate, display, discuss	PCL 1 & ICL 1 exit (parti-tion & PDS 1 free, display not destroyed)					
T			ICL 1 computes	ICL 1 loads PCL 1 into PDS 1	ICL 1 & PCL 1 communicate	PCL 1 generates display (partition free)	PCL 1 exits (PDS free, display not destroyed)			
				display data to	Data displayed (partition and PDS 1 free)		Fig.2 Example	es of prog	ram sequences	· .
						R.				

(Machine cycle or operator request)

