Министерство науки и высшего образования Российской Федерации

ФЕДЕРАЛЬНОЕ ГОСУДАРСТВЕННОЕ АВТОНОМНОЕ ОБРАЗОВАТЕЛЬНОЕ УЧРЕЖДЕНИЕ ВЫСШЕГО ОБРАЗОВАНИЯ

«НАЦИОНАЛЬНЫЙ ИССЛЕДОВАТЕЛЬСКИЙ УНИВЕРСИТЕТ ИТМО»

Лабораторная работа №3 по дисциплине «Имитационное моделирование робототехнических систем»

Выполнил: студент гр. R41341с Борисов М. В.

Преподаватель: Бжихатлов И. А.

Санкт-Петербург 2021 г.

Цель работы

- Импортировать модель манипулятора в симулятор
- Собрать визуальную и физическую части манипулятора
- Написать скрипт для поиска зелёного куба в рабочем пространстве
- Реализовать касание манипулятором до куба при обнаружении

Ход работы

Воспользуемся моделью манипулятора доступной по ссылке https://grabcad.com/library/r arm-manipulator-fanuc-m-20ib-industrial-robot-1 и изображённом на рисунке 1.



Рис. 1: Рендер манипулятора


Для уменьшения потребления ресурсов на рендер уменьшим число полигонов модели с помощью опции $Edit \rightarrow Decimate selected shape. Покрасим отдельные детали в различные цвета для удобства, после чего сделаем ещё более простые модели деталей. Эти детали будут служить физической репрезентацией манипулятора и на их основе будут считаться коллизии и взаимодействия.$


Базу робота заменим обычным цилиндром, остальные детали заменим их выпуклой оболочкой. Используя редактор вершин и мешей разметим места для установки осей вращения с помощью компонента Dummy. По ним в дальнейшем будет проще ориентироваться.

Также с помощью этого компонента отметим конец последнего звена манипулятора, куда обычно крепятся инструменты. В это место мы прикрепим датчики.

Все детали манипулятора необходимо называть шаблонно (рисунок 3b), в коде это упростит работу.


В конечном итоге получим модель манипулятора и соответствующее ей дерево (рисунок 3).





(а) Настройки динамических компонентов


(b) Настройки объекта измерения (куба)



(с) Настройки сочленений

Рис. 2: Настройки тел и сочленений

На рисунке 2 показаны настройки для различных тел модели. При том для динамических тел, которые участвуют в расчётах важно чередование локальной



(а) Собранный манипулятор

(b) Дерево модели манипулятора

Рис. 3: Модель

маски соседних элементов для избежания ложных коллизий. Для элементов визуализации галочки динамики и взаимодействия сняты, поскольку в расчёте они не участвуют.

Скрипт напишем с использованием remote API на python. Код целиком приведён в приложении А. Алгоритм следующий:

- 1. Начать вращение вокруг своей оси (первое сочленение)
- 2. Совершать осциллирующее движение последним звеном (сканировать пространство)
- 3. Как только обнаружен зелёный куб остановиться
- 4. Медленно приблизиться и коснуться куба
- 5. Вернуться в исходное положение

У данного алгоритма есть множество недостатков, в частности для "честного" касания куба необходимо решать обратную задачу кинематики. Также для "честного" определения зелёного предмета желательно переводить получаемый цвет в HSV пространство, которое даёт более надёжные измерения цвета. Однако в рамкой лабораторной работы такого алгоритма достаточно.

Для каждого этапа алгоритма в скрипте прописана соответствующая функция, что позволяет при необходимости легко модифицировать и улучшить код (например, для последующих лабораторных работ).

Вывод

В работе изучен алгоритм импорта сторонних файлов и создания из них моделей для симуляции. Изучена работа с новым визуальным сенсором. Разработан простой алгоритм взаимодействия с окружением и рассмотрены его недостатки.

A. RemoteAPI скрипт

```
from typing import Any, List, NewType, Optional
 2
    from math import pi, isclose
 3
 4
    import vrepapi.sim as vrepapi
 5
 6
    from L2.src.main import VREPClient
 7
 8
    VREPHandle = NewType('VREPHandle', Any)
 9
10
11
    class L3Controller(VREPClient):
12
         __basename = 'manipulator'
13
         __sep = '_'
14
         __link_basename = 'link'
15
         __joint_basename = 'joint'
16
         __sensor_basename = 'sensor'
17
18
         _{n_{\text{links}}} = 4
19
20
         __base_handle: VREPHandle
21
         __links_handles: List[VREPHandle]
22
         __joint_handles: List[VREPHandle]
23
         __tip_handle: VREPHandle
24
25
         __prox_sensor_handle: VREPHandle
26
         __vis_sensor_handle: VREPHandle
27
28
         D EPS: float = 1e-2
29
         __ANGLE_EPS: float = 0.1
30
         \underline{\hspace{0.1cm}} G_THRESH: float = 0.9
31
32
         __joint_ranges: List[float] = [
33
                 [None, None],
34
                 [-pi/3, pi/2],
35
                  [0, pi/3]
36
                 1
37
38
         __joint_dp: List[float] = [
```

```
39
                 .08,
40
                 .08,
41
                 .08
42.
                 1
43
44
        @classmethod
45
        def __construct_name(cls, *args) -> str:
46
            return cls.__sep.join([cls.__basename, *args])
47
48
        @classmethod
49
        def get_base_name(cls) -> str:
50
            return cls.get link name(0)
51
52
        @classmethod
53
        def get_link_name(cls, n: int) -> str:
54
            return cls. construct name(f'{cls. link basename}{n}')
55
56
        Oclassmethod
57
        def get_joint_name(cls, n: int) -> str:
58
59
             :param n: index of the link that is controlled by the joint
60
             :return: name of the joint
61
62
            links = [f'\{cls.\_link\_basename\}\{\_\}' for \_ in (n, n + 1)]
63
            return cls.__construct_name(cls.__joint_basename, *links)
64
65
        @classmethod
66
        def get_tip_name(cls):
67
            return cls.__construct_name('tip')
68
69
        @classmethod
70
        def get_sensor_name(cls, type: str) -> str:
71
            return cls.__construct_name(cls.__sensor_basename, type)
72
73
        def __init_handles(self):
74
             self.__base_handle, *self.__links_handles = [
75
                     vrepapi.simxGetObjectHandle(self.client_id,
                         self.get_link_name(_),
                     → vrepapi.simx_opmode_blocking) [1]
76
                     for _ in range(self.__n_links)]
77
             self.__joint_handles = [
78
                     vrepapi.simxGetObjectHandle(self.client_id,

    self.get_joint_name(_),
                     → vrepapi.simx_opmode_blocking)[1] for
79
                     _ in range(0, self.__n_links - 1)]
80
            _, self.__tip_handle = vrepapi.simxGetObjectHandle(
81
                     self.client_id, self.get_tip_name(),
                      → vrepapi.simx_opmode_blocking
```

```
82
 83
             _, self.__prox_sensor_handle = vrepapi.simxGetObjectHandle(
 84
                      self.client_id, self.get_sensor_name('proximity'),
                      → vrepapi.simx_opmode_blocking
 85
 86
             _, self.__vis_sensor_handle = vrepapi.simxGetObjectHandle(
 87
                      self.client_id, self.get_sensor_name('visual'),

    vrepapi.simx_opmode_blocking

 88
 89
 90
         def ___init_datastreams(self):
 91
             vrepapi.simxReadProximitySensor(self.client id,

    self.__prox_sensor_handle,
              → vrepapi.simx_opmode_streaming)
 92
             vrepapi.simxReadVisionSensor(self.client_id,
              → self. vis sensor handle, vrepapi.simx opmode streaming)
 93
 94
         def __init(self):
 95
             self.__init_handles()
             self.__init_datastreams()
 96
 97
 98
         @property
 99
         def distance(self) -> Optional[float]:
100
             print(f'Reading from proximity sensor...')
101
102
             res, ready, (_, _, d), *_ = \
103
                  vrepapi.simxReadProximitySensor(
104
                          self.client_id,
105
                          self. prox sensor handle,
106
                          vrepapi.simx_opmode_buffer
107
108
109
             print(f'Readings:\n'
110
                    f' response: {res}; ready: {ready}; distance: {d}\n')
111
112
             return d if self.response_good(res) and ready else None
113
114
         @property
115
         def greenness(self):
116
             print(f'Reading from visual sensor...')
117
118
             res, ready, packets =

→ vrepapi.simxReadVisionSensor(self.client_id,
              → self. vis sensor handle,
119
                                               vrepapi.simx_opmode_buffer)
120
121
             greenness = packets[0][12] if self.response_good(res) and
              → packets else None # get average green channel
```

```
122
123
              print (f'Readings:\n'
124
                    f' response: {res}; ready: {ready}; greenness:
                     125
126
              return greenness
127
128
          @property
129
          def object_found(self):
130
              return self.greenness and self.greenness >= self.__G_THRESH
131
132
          def    move to next point(self):
133
              self.move_joint(self.__joint_handles[0], self.__joint_dp[0])
134
              self.set_joint_pos(self.__joint_handles[1], pi/4)
135
              min_, max_ = self.__joint_ranges[-1]
136
              if abs((cur pos :=

    self.get_joint_pos(self.__joint_handles[-1])) - max_) <=</pre>

    self.__ANGLE_EPS:

137
                  self.\__joint\_dp[-1] = -abs(self.\__joint\_dp[-1])
138
              elif abs(cur_pos - min_) <= self.__ANGLE_EPS:</pre>
139
                  self.\underline{\hspace{0.1cm}}joint\_dp[-1] = abs(self.\underline{\hspace{0.1cm}}joint\_dp[-1])
140
              self.move_joint(self.__joint_handles[-1],
               \rightarrow self.__joint_dp[-1])
141
142
          def get_joint_pos(self, joint_handle: VREPHandle):
143
              _, curr_coord = vrepapi.simxGetJointPosition(self.client_id,
               → joint_handle, vrepapi.simx_opmode_blocking)
144
              print(f'Getting joint pos... pos: {curr_coord}')
145
              return curr_coord if self.response_good(_) else None
146
147
          def move_joint(self, joint_handle: VREPHandle, delta: float):
148
              curr_pos = self.get_joint_pos(joint_handle)
149
              if curr_pos is None:
150
                  return
151
              self.set_joint_pos(joint_handle, curr_pos + delta)
152
153
          def set_joint_pos(self, joint_handle: VREPHandle, pos: float):
154
              print(f'Setting joint pos: {pos}')
155
              vrepapi.simxSetJointTargetPosition(self.client_id,

→ joint_handle, pos, vrepapi.simx_opmode_oneshot)
156
157
          def set_joint_vel(self, joint_handle: VREPHandle, vel: float):
158
              vrepapi.simxSetJointTargetVelocity(self.client_id,
               → joint_handle, vel, vrepapi.simx_opmode_oneshot)
159
160
          def ___touch_object(self):
161
              while True:
```

```
162
                  if self.distance is not None and self.distance <=</pre>

    self. D EPS:

163
                      break
164
                  self.move_joint(self.__joint_handles[1], 0.001)
165
                  self.move_joint(self.__joint_handles[2], -0.001)
166
167
          def ___home(self):
168
              for joint_handle in self.__joint_handles:
169
                  self.set_joint_pos(joint_handle, 0)
170
              while not all(isclose(self.get_joint_pos(_), 0,
                  abs_tol=self.__D_EPS) for _ in self.__joint_handles):
171
                  pass
172
173
          def _run(self):
174
              self.__init()
175
              while not self.object found:
176
                  self.__move_to_next_point()
177
              self.__touch_object()
178
              self.__home()
179
180
181
     if __name__ == '__main__':
182
          SERVER_HOST = '127.0.0.1'
183
          SERVER PORT = 19999
184
185
          controller = L3Controller(SERVER_HOST, SERVER_PORT)
186
187
         controller.run()
```