

Drok NT/ Juntek NT / TTGO adapter board with ADS1115 module.

Caveat: power on +5V and +3V: 20mA max!



TTGC


Drok NT/ Juntek NT / TTGO adapter board with ADS1115 module.



Differences Drok-Juntek: Left connector

Drok 6008

Juntek 3603



0	
0	
0	
0	
OOOOOO	
0	
0	

Current sense **

Voltage sense *

Free (Vin sense on 3603)

Current PWM**

Voltage PWM*

<1V Enable (by default)

CC/CV feedback (on some modules)

Fan PWM (on some modules)

V or 100mA	PWM - V	PVM - A	mV - Vi	mV -Vo	mV -A
Bias	-1	66	-	4	110
Step (for 1v or 100mA)	18,17	8,90	47,22	29,00	14,20
Res. (mV or mA per					
increment)	55,05	112,36	21,18	34,48	7,04

V or 100mA	PWM - V	PVM - A	mV - Vi	mV -Vo	mV -A
Bias	29,4	93	-6	47,6	145
Step (for 1v or 100mA)	47,1	57	62,2	71,2	85
Res. (mV or mA per increment)	21,23	17,65	16,08	14,04	1,18


*		**	
0v	.000	0.0A	0.109
5v	.149	0.1A	0.124
10v	.294	0.5A	0.181
15v	.439	1.0A	0.323
20v	.585	2.0A	0.391
25v	.729	5.0A	0.820
30v	.874		
35v	1.019		

*		* *	
0v	0.048	0.0A	0.145
5v	0.401	0.1A	0.230
10v	0.754	0.5A	0.570
15v	1.107	1.0A	0.994
20v	1.461	2.0A	1.844
25v	1.818		

Differences Drok-Juntek: Left connector

Drok 6012

Juntek 3806



Current sense **

Voltage sense *

Free (Vin sense on 3603)

Current PWM**

Voltage PWM*

<1V Enable (by default)

CC/CV feedback (on some modules)

Fan PWM (on some modules)

V or 100mA	PWM - V	PVM - A	mV - Vi	mV -Vo	mV -A
Bias	-1	66	-	4	110
Step (for 1v or 100mA)	18,17	8,90	47,22	29,00	14,20
Res. (mV or mA per					
increment)	55,05	112,36	21,18	34,48	7,04

V or 100mA	PWM - V	PVM - A	mV - Vi	mV -Vo	mV -A
Bias	29,4	93	-6	47,6	145
Step (for 1v or 100mA)	47,1	57	62,2	71,2	85
Res. (mV or mA per increment)	21,23	17,65	16,08	14,04	1,18

*		**	
0v	.000	0.0A	0.109
5v	.149	0.1A	0.124
10v	.294	0.5A	0.181
15v	.439	1.0A	0.323
20v	.585	2.0A	0.391
25v	.729	5.0A	0.820
30v	.874		
35v	1.019		

*		* *	
0v	0.048	0.0A	0.145
5v	0.401	0.1A	0.230
10v	0.754	0.5A	0.570
15v	1.107	1.0A	0.994
20v	1.461	2.0A	1.844
25v	1.818		