```
**********
                     k: Handler for 12 key
                     Atari Video Touchpad
                    By Brian Hall 12/18/84
              **********
               LIST -M
    = D300
             PORTA = 54016
    = D302
             PACTL = 54018
              WSYNC = $d40a
    = D40A
    = D20F
             SKCTL = $d20F
             ALLPOT = $d208
    = D208
    = D20B
             POTGO = $d20b
             PADDL0 = $0270
    = 0270
    = 0271
             PADDL1 = $0271
    = 0272
             PADDL2 = $0272
    = 0273
             PADDL3 = $0273
              STRIG0 = $0284
    = 0284
    = 0285
             STRIG1 = $0285
    = 031A
             HATABS = $031A
             RTCLOK = $12
    = 0012
             BRKKEY = $11
    = 0011
             Devnam = 'k'
    = 006B
0000 = 0600
                    ORG $600
              Installation code *
              ********
0400
              Start:
              ; First, we must search through the
              ; handler table to see if there is an
              ; opening, or the device is already
              : installed. An opening is marked with
              ; a 0 byte.
                     PROC
0600
                     1dx #0
0600 A200
0602 BD1A03
             :look
                    1 da HATABS.x
                    beg Install
                                 :found a spot!
0605 F00A ^0611
                                 ;already in?
0607
    C96B
                    cmp #Devnam
                                 ;yes!
0609 F005 ^0610
                    beg :out
    E8
                     inx
060B
060C
    E8
                     inx
                     inx
060D E8
                    bne :look ;keep looking
060E D0F2 ^0602
                    rts ; end of table?!?
0610 60
             :out
              Install:
0611
```

```
; We put the ASCII for the device name
                 ; in the table followed by the address
                 ; of its handler vector table.
 0611 A96B
                       lda #Devnam
 0613 9D1A03
                       sta HATABS.x
 0616 A926
                       lda #low Hndvec
 0618 9D1B03
                       sta HATABS+1.x
 061B A906
                       lda #high Hndvec
 061D 9D1C03
                       sta HATABS+2,x
                 ; Put a zero in to insure room for more
                 : handlers.
 0620 A900
                       1da #0
 0622 9D1D03
                       sta HATABS+3,x
 0625 60
                       rts
                       EPROC
                 Handler Vector Table
                 ********
 0626
                Hndvec:
 0626 3406
                       dw OpenV-1
 0628 4006
                       dw CloseV-1
                       dw GetV-1
 062A 5E06
                       dw PutV-1
 062C C906
                       dw StatusV-1
 062E C106
 9630 C906
                       dw SpecialV-1
J632 4CCA06
                       jmp Ret ; Init vector
                 *********
                          Actual Routines
                 ********
 0635
                OpenV:
                       jsr There?
 0635 20CB06
                 : ok
 0638 F001 ^063B
                       beq :yep
                       rts
 063A
     60
 063B
                 :yep
                       Movei PACTL,$30
                       Movei PORTA, $ f0
 0640
                       Movei PACTL, $34
 0645
                       1dy #1
 064A A001
                       rts
 064C
     60
 064D
                 CloseV:
                       Movei PACTL, $30
 064D
                       Movei PORTA,0
 0652
                       Movei PACTL, $34
 0657
                       1dy #1
 065C
     A001
                       rts
 065E
     60
                 GetV:
 065F
                 * Is the controller hooked up?
```

k: Touchpad handler

06B4 E004

```
jsr There?
)65F 20CB06
0662 F001 ^0665
                      bea Brk
0664 60
                      rts
               * Is break pressed?
0665
               Brk:
0665 A511
                      lda BRKKEY
0667 D007 ^0670
                      bne Nxt
0669
                      Movei BRKKEY,1
066D A080
                      1dy #$80
066F 60
                      rts
0670
              Nxt:
0670
                      Movei BRKKEY,1
0674 A200
                      1dx #0
0676
               :Loop
               * Select row
                lda Rowmsk.x
0676 BDDB06
0679 8D00D3
                      sta PORTA
               * Wait for some inane reason
               * - incorrect values if you don't
067C A514 :wait1 cmp RTCLOK+2
0680 F0FC ^067E beq :wait1
0492 A514 Ida RTCLOK+2
                1da RTCLOK+2
9686 F0FC ^0684 beq :wait2
          * Read column 1
0688 AD7302
068B C90A
                 1 da PADDL3
                      cmp #10
068D 9008 ^0697
                      bcc :11
068F A901
                      1da #1
0691 18
                      clc
0692 7DDF06
                      adc Basadd,x
bcc :Out

* Read column 2

0697 AD7202 :11 1da PADDL2

069A C90A
069C 9008 ^06A6
                      bcc :12
069E A902
                      1da #2
                      clc
06A0 18
06A1 7DDF06
06A1 7DDF06 adc Basadd,x
06A4 9015 ^06BB bcc :out
               * Read column 3
06A6 AD8502 :12 lda STRIG1
06A9 D008 ^06B3
                      bne :next
06AB A903
                      1da #3
06AD 18
                      clc
06AE 7DDF06
06AE 7DDF06 adc Basadd,x
06B1 9008 ^06BB bcc :out
06B3 E8 :next inx
```

cpx #4

```
686
    D0BE ^0676
                 bne :Loop
                ; We must have a value to return, so
                ; loop back.
06B8
    4C5F06
                       jmp GetV
                ; Found a value, so return it in A
06BB AA
                :out
                      tax
06BC BDE306
                      lda Keytab.x
06BF A001
                      1dy #1
06C1
    60
                       rts
06C2
               StatusV:
06C2 20CB06
                      jsr There?
06C5 D003 ^06CA
                      bne Ret
06C7 A001
                      1dy #1
06C9 60
                       rts
               * Null routine for unused cmds
06CA
               PutV:
06CA
               SpecialV:
06CA 60
               Ret: rts
               There?:
06CB
06CB AD7202
                       1da PADDL2
                       and PADDL3
06CE 2D7302
06D1 C9E4
                      cmp #228
96D3 F003 ^06D8
                      bea No
J6D5 A000
                      1dy #0
    60
06D7
                      rts
06D8 A08A
              No
                      ldy #138 ;?device timeout
06DA 60
                       rts
               : Table of row masks
04DB EEDDBB77
               Rowmsk db $ee,$dd,$bb,$77
               : Number to add based on row
               Basadd db 0,3,6,9
06DF 00030609
                *********
                * Alpha Equivalents for Touchpad Keys *
                * Assignable to any ATASCII chars *
               ********
06E3 0031323334 Keytab db 0,'123456789*0#'
                       EPROC
                       END Start
06F0
```

no ERRORs, 44 Labels, \$4454 free.