[v13,08/12] KVM: x86: Add Intel PT context switch for each

vcpu

10654369

diff (/patch/10654369/raw/)

mbox (/patch/10654369/mbox/)

series (/series/34463/mbox/)

Message ID 1540368316-12998-9-git-send-email-luwei.kang@intel.com

State New Headers show

Series Intel Processor Trace virtualization enabling

hide

[v13,00/12] Intel Processor Trace virtualization enabling (/cover/10654355/)

[v13,01/12] perf/x86/intel/pt: Move Intel PT MSRs bit defines to global header (/patch/10654357/)

[v13,02/12] perf/x86/intel/pt: Export pt_cap_get() (/patch/10654359/)

[v13,03/12] perf/x86/intel/pt: Introduce intel_pt_validate_cap() (/patch/10654361/)

[v13,04/12] perf/x86/intel/pt: Add new bit definitions for PT MSRs (/patch/10654379/)

Related [v13,05/12] perf/x86/intel/pt: add new capability for Intel PT (/patch/10654363/)

[v13,06/12] KVM: x86: Add Intel PT virtualization work mode (/patch/10654365/)

[v13,07/12] KVM: x86: Add Intel Processor Trace cpuid emulation (/patch/10654367/)

[v13,08/12] KVM: x86: Add Intel PT context switch for each vcpu

[v13,09/12] KVM: x86: Introduce a function to initialize the PT configuration (/patch/10654377/)

[v13,10/12] KVM: x86: Implement Intel PT MSRs read/write emulation (/patch/10654371/)

[v13,11/12] KVM: x86: Set intercept for Intel PT MSRs read/write (/patch/10654373/)

[v13,12/12] KVM: x86: Disable Intel PT when VMXON in L1 guest (/patch/10654375/)

Commit Message

Kang, Luwei (/project/kvm/list/?submitter=168537)

Oct. 24, 2018, 8:05 a.m. UTC

Comments

Alexander Shishkin (/project/kvm/list/?submitter=46111)

Oct. 24, 2018, 10:13 a.m. UTC | #1 (/comment/22282983/)

```
Luwei Kang <luwei.kang@intel.com> writes:
> +static void pt guest enter(struct vcpu vmx *vmx)
> +{
        if (pt mode == PT MODE SYSTEM)
> +
> +
                return;
> +
        /* Save host state before VM entry */
> +
        rdmsrl(MSR IA32 RTIT CTL, vmx->pt desc.host.ctl);
> +
> +
> +
         * Set guest state of MSR IA32 RTIT CTL MSR (PT will be disabled
> +
         * on VM entry when it has been disabled in guest before).
> +
        vmcs write64(GUEST IA32 RTIT CTL, vmx->pt desc.guest.ctl);
> +
> +
        if (vmx->pt desc.guest.ctl & RTIT CTL TRACEEN) {
> +
                wrmsrl(MSR_IA32_RTIT_CTL, 0);
> +
> +
                pt save msr(&vmx->pt desc.host, vmx->pt desc.addr range);
                pt load msr(&vmx->pt desc.guest, vmx->pt desc.addr range);
> +
> +
> +}
From my side this is still a NAK, because [1].
[1] https://marc.info/?l=kvm&m=153847567226248&w=2
Thanks,
Alex
```

Kang, Luwei (/project/kvm/list/?submitter=168537)

Oct. 25, 2018, 12:06 a.m. UTC | #2 (/comment/22284039/)

```
>> +static void pt guest enter(struct vcpu vmx *vmx) {
        if (pt mode == PT MODE SYSTEM)
                return;
> > +
> > +
        /* Save host state before VM entry */
> > +
        rdmsrl(MSR IA32 RTIT CTL, vmx->pt desc.host.ctl);
> > +
> > +
> > +
         * Set guest state of MSR IA32 RTIT CTL MSR (PT will be disabled
> > +
         * on VM entry when it has been disabled in guest before).
> > +
> > +
        vmcs write64(GUEST IA32 RTIT CTL, vmx->pt desc.guest.ctl);
> > +
        if (vmx->pt desc.guest.ctl & RTIT CTL TRACEEN) {
> > +
                wrmsrl(MSR IA32 RTIT CTL, 0);
> > +
                pt save msr(&vmx->pt desc.host, vmx->pt desc.addr range);
> > +
                pt load msr(&vmx->pt desc.guest, vmx->pt desc.addr range);
> > +
> > +
> > +}
> From my side this is still a NAK, because [1].
> [1] https://marc.info/?l=kvm&m=153847567226248&w=2
This place is save the host PT status and load the guest PT status before VM-entry when working in Host-Guest mode.
Thanks,
Luwei Kang
```

Paolo Bonzini (/project/kvm/list/?submitter=2536)

Oct. 29, 2018, 5:48 p.m. UTC | #3 (/comment/22289839/)

```
On 24/10/2018 12:13, Alexander Shishkin wrote:
> Luwei Kang <luwei.kang@intel.com> writes:
>> +static void pt guest enter(struct vcpu vmx *vmx)
>> +{
>> +
        if (pt mode == PT MODE SYSTEM)
                return:
>> +
>> +
        /* Save host state before VM entry */
>> +
        rdmsrl(MSR IA32 RTIT CTL, vmx->pt desc.host.ctl);
>> +
>> +
>> +
>> +
         * Set guest state of MSR IA32 RTIT CTL MSR (PT will be disabled
         * on VM entry when it has been disabled in guest before).
>> +
>> +
        vmcs write64(GUEST IA32 RTIT CTL, vmx->pt desc.guest.ctl);
>> +
>> +
        if (vmx->pt desc.guest.ctl & RTIT CTL TRACEEN) {
>> +
>> +
                wrmsrl(MSR IA32 RTIT CTL, 0);
                pt save msr(&vmx->pt desc.host, vmx->pt desc.addr range);
>> +
                pt load msr(&vmx->pt desc.guest, vmx->pt desc.addr range);
>> +
>> +
>> +}
> From my side this is still a NAK, because [1].
> [1] https://marc.info/?l=kvm&m=153847567226248&w=2
Then you should have replied to
https://marc.info/?l=kvm&m=153865386015249&w=2 instead of having Luwei
do the work for nothing.
Quoting from there:
>> One shouldn't have to enable or disable anything in KVM to stop it from
>> breaking one's existing workflow. That makes no sense.
> If you "have to enable or disable anything" it means you have to
> override the default. But the default in this patches is "no change
> compared to before the patches", leaving tracing of both host and guest
> entirely to the host, so I don't understand your remark. What workflow
> is broken?
>> There already are controls in perf that enable/disable guest tracing.
> You are confusing "tracing guest from the host" and "the guest can trace
> itself". This patchset is adding support for the latter, and that
> affects directly whether the tracing CPUID leaf can be added to the
> guest. Therefore it's not perf that can decide whether to turn it on;
> KVM must know it when /dev/kvm is opened, which is why it is a module
```

> parameter.

I'd be happier if we found an agreement, but without discussion that just won't happen.

Also, is there an existing interface to write a record into a tracing buffer?

Paolo

Thomas Gleixner (/project/kvm/list/?submitter=107)

Oct. 30, 2018, 10 a.m. UTC | #4 (/comment/22290933/)

```
On Mon, 29 Oct 2018, Paolo Bonzini wrote:
> On 24/10/2018 12:13, Alexander Shishkin wrote:
> > Luwei Kang <luwei.kang@intel.com> writes:
> >> + /*
        * Set guest state of MSR_IA32_RTIT_CTL MSR (PT will be disabled
> >> +
         * on VM entry when it has been disabled in guest before).
> >> +
> >> +
        vmcs write64(GUEST IA32 RTIT CTL, vmx->pt desc.guest.ctl);
> >> +
> >> +
       if (vmx->pt desc.guest.ctl & RTIT CTL TRACEEN) {
> >> +
                wrmsrl(MSR IA32 RTIT CTL, 0);
> >> +
                pt save msr(&vmx->pt desc.host, vmx->pt desc.addr range);
> >> +
                pt load msr(&vmx->pt desc.guest, vmx->pt desc.addr range);
> >> +
> >> + }
> >> +}
> >
>> From my side this is still a NAK, because [1].
> >
> > [1] https://marc.info/?l=kvm&m=153847567226248&w=2
> Then you should have replied to
> https://marc.info/?l=kvm&m=153865386015249&w=2 instead of having Luwei
> do the work for nothing.
> Ouoting from there:
>
>>> One shouldn't have to enable or disable anything in KVM to stop it from
>>> breaking one's existing workflow. That makes no sense.
> >
>> If you "have to enable or disable anything" it means you have to
>> override the default. But the default in this patches is "no change
> > compared to before the patches", leaving tracing of both host and guest
>> entirely to the host, so I don't understand your remark. What workflow
> > is broken?
> >
>>> There already are controls in perf that enable/disable guest tracing.
>> You are confusing "tracing guest from the host" and "the guest can trace
> > itself". This patchset is adding support for the latter, and that
> > affects directly whether the tracing CPUID leaf can be added to the
>> guest. Therefore it's not perf that can decide whether to turn it on;
>> KVM must know it when /dev/kvm is opened, which is why it is a module
> > parameter.
> I'd be happier if we found an agreement, but without discussion that
> just won't happen.
```

So at least we need a way for perf on the host to programmatically detect, that 'guest traces itself' is enabled, so it can inject that information into the host data and post processing can tell that. W/o something like

```
that it's going to be a FAQ.
```

Thanks,

tglx

Alexander Shishkin (/project/kvm/list/?submitter=46111)

Paolo Bonzini <pbonzini@redhat.com> writes:

- >> If you "have to enable or disable anything" it means you have to
- >> override the default. But the default in this patches is "no change
- >> compared to before the patches", leaving tracing of both host and guest
- >> entirely to the host, so I don't understand your remark. What workflow
- >> is broken?

>>

>>> There already are controls in perf that enable/disable guest tracing.

>>

- >> You are confusing "tracing guest from the host" and "the guest can trace
- >> itself". This patchset is adding support for the latter, and that

I'm not confusing anything. In the terminology that you're using, the latter breaks the former. This cannot happen.

- >> affects directly whether the tracing CPUID leaf can be added to the
- >> guest. Therefore it's not perf that can decide whether to turn it on;
- >> KVM must know it when /dev/kvm is opened, which is why it is a module
- >> parameter.

There is a control in the perf event attribute that enables tracing the guest. If this control is enabled, the kvm needs to stay away from any PT related MSRs. Conversely, if kvm is using PT (or, as you say, "the guest is tracing itself"), the host should not be allowed to ask for tracing the guest at the same time.

Regards,

Alex

Paolo Bonzini (/project/kvm/list/?submitter=2536)

Oct. 30, 2018, 11:26 a.m. UTC | #5 (/comment/22291025/)

Oct. 31, 2018, 10:43 a.m. UTC | #6 (/comment/22293129/)

```
On 30/10/2018 11:00, Thomas Gleixner wrote:
> On Mon, 29 Oct 2018, Paolo Bonzini wrote:
>> On 24/10/2018 12:13, Alexander Shishkin wrote:
>>> Luwei Kang <luwei.kang@intel.com> writes:
>>>> + /*
>>>> +
         * Set guest state of MSR IA32 RTIT CTL MSR (PT will be disabled
         * on VM entry when it has been disabled in guest before).
>>>> +
>>>> +
        vmcs write64(GUEST IA32 RTIT CTL, vmx->pt desc.guest.ctl);
>>>> +
>>>> + if (vmx->pt desc.guest.ctl & RTIT CTL TRACEEN) {
                wrmsrl(MSR IA32 RTIT CTL, 0);
>>>> +
                pt save msr(&vmx->pt desc.host, vmx->pt desc.addr range);
>>>> +
>>>> +
                pt load msr(&vmx->pt desc.guest, vmx->pt desc.addr range);
>>>> + }
>>>> +}
>>>
>>> From my side this is still a NAK, because [1].
>>>
>>> [1] https://marc.info/?l=kvm&m=153847567226248&w=2
>>
>> Then you should have replied to
>> https://marc.info/?l=kvm&m=153865386015249&w=2 instead of having Luwei
>> do the work for nothing.
>>
>> Ouoting from there:
>>
>>> One shouldn't have to enable or disable anything in KVM to stop it from
>>>> breaking one's existing workflow. That makes no sense.
>>>
>>> If you "have to enable or disable anything" it means you have to
>>> override the default. But the default in this patches is "no change
>>> compared to before the patches", leaving tracing of both host and guest
>>> entirely to the host, so I don't understand your remark. What workflow
>>> is broken?
>>>
>>>> There already are controls in perf that enable/disable guest tracing.
>>>
>>> You are confusing "tracing guest from the host" and "the guest can trace
>>> itself". This patchset is adding support for the latter, and that
>>> affects directly whether the tracing CPUID leaf can be added to the
>>> guest. Therefore it's not perf that can decide whether to turn it on;
>>> KVM must know it when /dev/kvm is opened, which is why it is a module
>>> parameter.
>>
>> I'd be happier if we found an agreement, but without discussion that
>> just won't happen.
> So at least we need a way for perf on the host to programmatically detect,
> that 'guest traces itself' is enabled, so it can inject that information
```

> into the host data and post processing can tell that. W/o something like
> that it's going to be a FAQ.

In guest-tracing mode there will be already a TIP.PGD and TIP.PGE packet respectively before vmentry and after vmexit, caused by the RTIT_CTL WRMSRs in pt_guest_enter and pt_guest_exit. The target IP of the packets will come from kvm-intel.ko.

In system mode instead you get a Paging Information Packet on vmentry/vmexit, with bit 0 set in the third byte. You won't get it if guest-side tracing is on (because tracing has been disabled by pt_guest_enter and won't be re-enabled until pt_guest_exit). I don't think it's correct to "fake" the PIP in guest-tracing mode, because TIP.PGD should be followed immediately by TIP.PGE.

Is this okay for perf users?

Paolo

Paolo Bonzini (/project/kvm/list/?submitter=2536)

On 30/10/2018 12:26, Alexander Shishkin wrote:

- >>> affects directly whether the tracing CPUID leaf can be added to the
 >>> guest. Therefore it's not perf that can decide whether to turn it on;
 >>> KVM must know it when /dev/kvm is opened, which is why it is a module
- >>> parameter.
- > There is a control in the perf event attribute that enables tracing the
- > guest. If this control is enabled, the kvm needs to stay away from any
- > PT related MSRs.

This cannot happen once the guest has been told it can trace itself. There is no standard way to tell the guest that the host overrode its choice to use PT. However, the host will get a PGD/PGE packet around vmentry and vmexit, so there _will_ be an indication that the guest owned the MSRs for that period of time.

If PT context switching is enabled with the module parameter, we could also reject creation of events with the attribute set. However that won't help if the event is created before KVM is even loaded.

Paolo

- > Conversely, if kvm is using PT (or, as you say, "the
- > guest is tracing itself"), the host should not be allowed to ask for
- > tracing the guest at the same time.

Alexander Shishkin (/project/kvm/list/?submitter=46111)

Oct. 31, 2018, 10:49 a.m. UTC | #7 (/comment/22293145/)

Oct. 31, 2018, 11:38 a.m. UTC | #8 (/comment/22293217/)

Paolo Bonzini <pbonzini@redhat.com> writes:

- > On 30/10/2018 12:26, Alexander Shishkin wrote:
- >> There is a control in the perf event attribute that enables tracing the
- >> guest. If this control is enabled, the kvm needs to stay away from any
- >> PT related MSRs.

>

> This cannot happen once the guest has been told it can trace itself.

So, they need to be made mutually exclusive.

- > There is no standard way to tell the guest that the host overrode its
- > choice to use PT. However, the host will get a PGD/PGE packet around
- > vmentry and vmexit, so there will be an indication that the guest
- > owned the MSRs for that period of time.

Not if they are not tracing the kernel.

- > If PT context switching is enabled with the module parameter, we could
- > also reject creation of events with the attribute set. However that
- > won't help if the event is created before KVM is even loaded.

In that case, modprobe kvm should fail.

Regards,

Alex

Alexander Shishkin (/project/kvm/list/?submitter=46111)

Oct. 31, 2018, 11:46 a.m. UTC | #9 (/comment/22293237/)

Paolo Bonzini <pbonzini@redhat.com> writes:

```
> On 30/10/2018 11:00, Thomas Gleixner wrote:
>> So at least we need a way for perf on the host to programmatically detect,
>> that 'guest traces itself' is enabled, so it can inject that information
>> into the host data and post processing can tell that. W/o something like
>> that it's going to be a FAQ.
>
> In guest-tracing mode there will be already a TIP.PGD and TIP.PGE packet
> respectively before vmentry and after vmexit, caused by the RTIT_CTL
> WRMSRs in pt_guest_enter and pt_guest_exit. The target IP of the
> packets will come from kvm-intel.ko.
```

Most people aren't tracing the kernel, so they'd just get a PGD with no address and a PGE after the kvm is done without any indication of what happened in between.

```
> In system mode instead you get a Paging Information Packet on
> vmentry/vmexit, with bit 0 set in the third byte. You won't get it if
> guest-side tracing is on (because tracing has been disabled by
> pt_guest_enter and won't be re-enabled until pt_guest_exit). I don't
> think it's correct to "fake" the PIP in guest-tracing mode, because
> TIP.PGD should be followed immediately by TIP.PGE.
```

Indeed, we should most definitely not fake PIP. Perf has RECORD_AUX, which already has PARTIAL flag that was introduced specifically because of kvm.

Regards, --Alex

Paolo Bonzini (/project/kvm/list/?submitter=2536)

Oct. 31, 2018, 12:07 p.m. UTC | #10 (/comment/22293283/)

```
On 31/10/2018 12:38, Alexander Shishkin wrote:
>> There is no standard way to tell the guest that the host overrode its
>> choice to use PT. However, the host will get a PGD/PGE packet around
>> vmentry and vmexit, so there _will_ be an indication that the guest
>> owned the MSRs for that period of time.
>
> Not if they are not tracing the kernel.
```

If they are not tracing the kernel why should they be tracing the guest at all? If you only choose to trace userspace, anything that happens between syscall entry and syscall exit is hidden and ioctl(KVM_RUN) _is_ a syscall.

```
>> If PT context switching is enabled with the module parameter, we could
>> also reject creation of events with the attribute set. However that
>> won't help if the event is created before KVM is even loaded.
>
> In that case, modprobe kvm should fail.
```

Does that mean that an unprivileged user can effectively DoS virtualization for everyone on the machine? (Honest question).

I am aware that guest-side tracing blocks host-side guest tracing, but that's exactly why it is entirely opt-in. Only root can enable it by switching the module parameter. I don't see any way to change that, other than rejecting this feature completely.

Paolo

Alexander Shishkin (/project/kvm/list/?submitter=46111)

Oct. 31, 2018, 2:21 p.m. UTC | #11 (/comment/22293551/)

Paolo Bonzini <pbonzini@redhat.com> writes: > On 31/10/2018 12:38, Alexander Shishkin wrote: >>> There is no standard way to tell the guest that the host overrode its >>> choice to use PT. However, the host will get a PGD/PGE packet around >>> vmentry and vmexit, so there will be an indication that the guest >>> owned the MSRs for that period of time. >> >> Not if they are not tracing the kernel. > If they are not tracing the kernel why should they be tracing the guest > at all? To trace the guest userspace, perhaps? >>> If PT context switching is enabled with the module parameter, we could >>> also reject creation of events with the attribute set. However that >>> won't help if the event is created before KVM is even loaded. >> >> In that case, modprobe kvm should fail. > Does that mean that an unprivileged user can effectively DoS > virtualization for everyone on the machine? (Honest question). Would the leave-PT-to-the-host still be allowed? Would ignoring the module parameter in that case and falling back to this mode still be fine? I'm not really the one to brainstorm solutions here. There are possibilities of solving this, and the current patchset does not even begin to acknowledge the existence of the problem, which is what my ACK depends on. Regards, Alex

Oct. 31, 2018, 2:43 p.m. UTC | #12 (/comment/22293635/)

Paolo Bonzini (/project/kvm/list/?submitter=2536)

```
On 31/10/2018 15:21, Alexander Shishkin wrote:
> Paolo Bonzini <pbonzini@redhat.com> writes:
> 
> On 31/10/2018 12:38, Alexander Shishkin wrote:
>>>> There is no standard way to tell the guest that the host overrode its
>>>> choice to use PT. However, the host will get a PGD/PGE packet around
>>>> vmentry and vmexit, so there _will_ be an indication that the guest
>>>> owned the MSRs for that period of time.
>>>
>>> Not if they are not tracing the kernel.
>>> If they are not tracing the kernel why should they be tracing the guest
>> at all?
>> To trace the guest userspace, perhaps?
```

Tracing the guest userspace and not the kernel is pretty much useless. I'd also be surprised if it worked at all, and/or would consider it a bug if it worked.

IMO tracing the kernel in system-wide mode should trace either all or none of the guest, but certainly not just the guest kernel. Tracing userspace should trace none of the guest.

>>> If PT context switching is enabled with the module parameter, we could
>>> also reject creation of events with the attribute set. However that
>>> won't help if the event is created before KVM is even loaded.
>>>
>>> In that case, modprobe kvm should fail.
>>
>> Does that mean that an unprivileged user can effectively DoS
>> virtualization for everyone on the machine? (Honest question).
>>
>> Would the leave-PT-to-the-host still be allowed? Would ignoring the
> module parameter in that case and falling back to this mode still be

That would still prevent the feature from being accessed, until someone with root access can rmmod kvm-intel.

- > I'm not really the one to brainstorm solutions here. There are
 > possibilities of solving this, and the current patchset does not even
 > begin to acknowledge the existence of the problem, which is what my ACK
 > depends on.
- Well, one way it does acknowledge the existence of the problem is by not turning the option on by default.

BTW, Intel (not you) also doesn't acknowledge the existence of the problem, by not suggesting a solution in the SDM. The SDM includes

> fine?

examples of host-only, guest-only and combined tracing, but not separate host and guest tracing.

Paolo

Patch

10654369 diff (/patch/10654369/raw/) mbox (/patch/10654369/mbox/) series (/series/34463/mbox/)

```
diff --git a/arch/x86/include/asm/intel pt.h b/arch/x86/include/asm/intel pt.h
index 4727584..eabbdbc 100644
--- a/arch/x86/include/asm/intel pt.h
+++ b/arch/x86/include/asm/intel pt.h
@@ -8,6 +8,8 @@
#define PT MODE SYSTEM
 #define PT MODE HOST GUEST
+#define RTIT ADDR RANGE
 enum pt capabilities {
        PT CAP max subleaf = 0,
        PT CAP cr3 filtering,
diff --git a/arch/x86/kvm/vmx.c b/arch/x86/kvm/vmx.c
index 692154c..d8480a6 100644
--- a/arch/x86/kvm/vmx.c
+++ b/arch/x86/kvm/vmx.c
@@ -978,6 +978,24 @@ struct vmx msrs {
        struct vmx msr entry
                                val[NR AUTOLOAD MSRS];
 };
+struct pt ctx {
        u64 ctl;
        u64 status;
        u64 output base;
        u64 output mask;
        u64 cr3 match;
        u64 addr a[RTIT ADDR RANGE];
        u64 addr b[RTIT ADDR RANGE];
+
+};
+struct pt desc {
+
        u64 ctl bitmask;
        u32 addr range;
        u32 caps[PT CPUID REGS NUM * PT CPUID LEAVES];
        struct pt ctx host;
+
        struct pt ctx guest;
+
+};
 struct vcpu vmx {
        struct kvm vcpu
                              vcpu;
        unsigned long
                              host rsp;
@@ -1071,6 +1089,8 @@ struct vcpu_vmx {
        u64 msr ia32 feature control;
        u64 msr ia32 feature control valid bits;
        u64 ept pointer;
+
        struct pt_desc pt_desc;
};
```

https://patchwork.kernel.org/patch/10654369/

```
enum segment cache field {
@@ -2899,6 +2919,69 @@ static unsigned long segment base(u16 selector)
#endif
+static inline void pt load msr(struct pt ctx *ctx, u32 addr range)
+{
+
        u32 i;
        wrmsrl(MSR IA32 RTIT STATUS, ctx->status);
        wrmsrl(MSR IA32 RTIT OUTPUT BASE, ctx->output base);
        wrmsrl(MSR IA32 RTIT OUTPUT MASK, ctx->output mask);
        wrmsrl(MSR IA32 RTIT CR3 MATCH, ctx->cr3 match);
        for (i = 0; i < addr range; i++) {
+
                wrmsrl(MSR IA32 RTIT ADDR0 A + i * 2, ctx->addr a[i]);
                wrmsrl(MSR IA32 RTIT ADDR0 B + i * 2, ctx->addr b[i]);
+
+}
+static inline void pt save msr(struct pt ctx *ctx, u32 addr range)
+{
        u32 i;
+
        rdmsrl(MSR IA32 RTIT STATUS, ctx->status);
        rdmsrl(MSR IA32 RTIT OUTPUT BASE, ctx->output base);
        rdmsrl(MSR IA32 RTIT OUTPUT MASK, ctx->output mask);
+
        rdmsrl(MSR IA32 RTIT CR3 MATCH, ctx->cr3 match);
+
        for (i = 0; i < addr range; i++) {
+
+
                rdmsrl(MSR IA32 RTIT ADDR0 A + i * 2, ctx->addr a[i]);
                rdmsrl(MSR IA32 RTIT ADDR0 B + i * 2, ctx->addr b[i]);
+
+
+}
+static void pt guest enter(struct vcpu vmx *vmx)
+{
        if (pt mode == PT MODE SYSTEM)
+
                return;
+
        /* Save host state before VM entry */
        rdmsrl(MSR IA32 RTIT CTL, vmx->pt desc.host.ctl);
+
+
+
         * Set guest state of MSR IA32 RTIT CTL MSR (PT will be disabled
         * on VM entry when it has been disabled in guest before).
        vmcs write64(GUEST IA32 RTIT CTL, vmx->pt desc.guest.ctl);
+
        if (vmx->pt desc.guest.ctl & RTIT CTL TRACEEN) {
                wrmsrl(MSR IA32 RTIT CTL, 0);
                pt_save_msr(&vmx->pt_desc.host, vmx->pt_desc.addr_range);
+
                pt load msr(&vmx->pt desc.guest, vmx->pt desc.addr range);
```

```
}
+}
+static void pt guest exit(struct vcpu vmx *vmx)
+{
        if (pt mode == PT MODE SYSTEM)
+
                return:
        if (vmx->pt desc.guest.ctl & RTIT CTL TRACEEN) {
+
                pt save msr(&vmx->pt desc.guest, vmx->pt desc.addr range);
                pt load msr(&vmx->pt desc.host, vmx->pt desc.addr range);
+
        /* Reload host state (IA32 RTIT CTL will be cleared on VM exit). */
+
        wrmsrl(MSR IA32 RTIT CTL, vmx->pt desc.host.ctl);
+
+}
 static void vmx prepare switch to guest(struct kvm vcpu *vcpu)
        struct vcpu vmx *vmx = to vmx(vcpu);
@@ -6749,6 +6832,13 @@ static void vmx vcpu setup(struct vcpu vmx *vmx)
        if (cpu has vmx encls vmexit())
                vmcs write64(ENCLS EXITING BITMAP, -1ull);
        if (pt mode == PT MODE HOST GUEST) {
+
                memset(&vmx->pt desc, 0, sizeof(vmx->pt desc));
                /* Bit[6~0] are forced to 1, writes are ignored. */
                vmx->pt desc.guest.output mask = 0x7F;
                vmcs write64(GUEST IA32 RTIT CTL, 0);
+
 static void vmx vcpu reset(struct kvm vcpu *vcpu, bool init event)
@@ -11260,6 +11350,8 @@ static void noclone vmx vcpu run(struct kvm vcpu *vcpu)
            vcpu->arch.pkru != vmx->host pkru)
                write pkru(vcpu->arch.pkru);
+
        pt guest enter(vmx);
+
        atomic switch perf msrs(vmx);
        vmx update hv timer(vcpu);
@@ -11459,6 +11551,8 @@ static void noclone vmx vcpu run(struct kvm vcpu *vcpu)
                                   (1 << VCPU EXREG CR3));
        vcpu->arch.regs dirty = 0;
+
        pt guest exit(vmx);
         * eager fpu is enabled if PKEY is supported and CR4 is switched
```

https://patchwork.kernel.org/patch/10654369/

* back on host, so it is safe to read guest PKRU from current

patchwork (http://jk.ozlabs.org/projects/patchwork/) patch tracking system | version v2.1.0 | about patchwork (/about/)