ECE354: RTX Project

Ben Ridder - brridder Casey Banner - cccbanne David Janssen - dajjanss

July 23, 2011

Contents

1	SOFTWARE DESIGN		
	1.1	Introduction	2
	1.2	GLOBAL INFORMATION	2
	1.3	Primitives	2
		1.3.1 Release Processor	2
		1.3.2 Set Process Priority	3
		1.3.3 Get Process Priority	4
		1.3.4 Request Memory Block	4
		1.3.5 Release Memory Block	5
		1.3.6 Send Messages	5
		1.3.7 Receive Messages	6
		1.3.8 Delayed Send	6
	1.4	Processes	7
		1.4.1 Null Process	7
		1.4.2 KCD Process	7
		1.4.3 CRT Process	7
		1.4.4 UART I-Process	8
		1.4.5 Timer I-Process	8
		1.4.6 Wall Clock Process	9
		1.4.7 SET PRIORITY COMMAND PROCESS	10
		1.4.8 Test Processes A, B, C	10
	1.5	SOFTWARE INTERRUPT HANDLERS	11
	1.6	HARDWARE INTERRUPT HANDLERS	11
	1.7	Hot Keys	11
	1.8	Initialization	11
		1.8.1 RTX Initialization	11
		1.8.2 RTX Initialization of Memory Management	12
	1.9	Implementation	12
2	Ma	JOR DESIGN CHANGES	13
3	ME	ASUREMENTS	14
4	LEA	SONS LEARNED	15

SOFTWARE DESIGN

- 1.1 Introduction
- 1.2 GLOBAL INFORMATION
- 1.3 Primitives

1.3.1 Release Processor

The release processor primitive is used to make a scheduling decision. Currently, this happens when the currently running process calls release_processor(). After making a mode switch, the kernel makes a decision on the next process to execute. When this decision is made, a context switch is made to the selected process. See Listing 1.1 for a high level pseudo code representation of this primitive

The kernel process decision currently uses several priority queues, four priority levels with two sub-queues. Every priority level has a READY and a DONE queue. Initially, all process in a priority level are in the priority level's READY queue and after execution they are moved to the DONE queue. In order to decide which process next, the kernel dequeues the next process on the highest non-empty READY priority queue. If all READY queues are empty, the DONE queues are moved to the READY queues and the kernel tries to select a process again.

A context switch is made after the kernel selects the next process. If there is a process running, the registers are saved on the stack and it's stack pointer is moved to the PCB. It's state is marked as STATE_READY to indicate it's state has been saved and is capable of executing again. Next, the selected process' stack pointer is restored. If the process is in the state STATE_STOPPED, meaning it has never been run before, the kernel changes the state to STATE_RUNNING and executes the process by returning from the exception. On the other hand, if the process has been run before, meaning that it is in the ready state, the data and address registers are restored from the stack. In this case, the method returns normally. Execution continues at the same it left off.

Listing 1.1: Pseudo code for release_processor()

```
int release_processor() {
   mode switch to kernel mode using system call exception

if all queues are empty:
   move DONE queues to READY queues

dequeue next process from highest non-empty priority queue
```

```
if there is a currently running process:
    save all of the registers on to the process stack
    save stack pointer to PCB
    set state to STATE_READY

restore next process stack pointer
    if next process state is STOPPED:
        return from exception using the next process exception frame
    else if state is READY:
        restore registers from stack

mode switch to user mode using system call exception frame
    return RTX_SUCCESS
}
```

1.3.2 Set Process Priority

The set_process_priority(...) and get_process_priority(...) primitives are used to set and get, respectively, the priorities of the specified process ID.

Setting the process priority is shown as pseudo code in Listing 1.2. First, the values of the process ID and the priority are saved to registers as a mode switch to kernel mode needs to be performed. These values are retrieved after the mode switch. After the mode switch, a check is performed to ensure that the ID and priority is valid. If it isn't, RTX_ERROR is returned. Otherwise, another check is made to see if the ID belongs to the currently running process and that there is a running process. If this is true, the priority of the running process is simply changed and RTX_SUCCESS is returned. If it is not the currently running process, the process is first removed from the appropriate queue based on its current priority level. Then the priority is updated to the new one and the process is enqueued onto the queue associated with the new priority with the same queue type as the one it was removed from. Finally, the function returns RTX_SUCCESS to indicate successful completion.

Listing 1.2: Pseudo code for setting the process priority

```
int set_process_priority(int pid, int priority) {
   move pid and priority into separate data registers
   mode switch to kernel mode

   retrieve pid and priority from the data registers

if invalid PID or invalid priority:
    return RTX_ERROR

if running process is the process to change:
    update running process to the new priority
else:
    dequeue process from appropriate queue
    update priority of that process
    enqueue process to its new priority queue

mode switch to user mode

return RTX_SUCCESS
}
```

1.3.3 Get Process Priority

Compared to setting the priority level, getting a process' priority is straight forward as can be seen in Listing 1.3. Similar to setting the priority, the process ID is moved into a data register and system is switched into kernel mode. After retrieving the process ID, a check is made to ensure that the process id is valid. If it is invalid RTX_ERROR is returned. The calling process should perform a check of its own to ensure that the returned value is not a negative which indicates an error. Finally, the process is looked up on the process table and the priority is returned from that.

Listing 1.3: Pseudo code for getting the process priority

```
int get_process_priority(int pid) {
   move pid into a data register
   mode switch to kernel mode

   retrieve pid from data register

   if the pid is invalid:
       return RTX_ERROR

   get process from the process table using pid

   mode switch to user mode

   return process priority
}
```

1.3.4 REQUEST MEMORY BLOCK

The request_memory_block() and release_memory_block() primitives are used by the operating system to allocate and deallocate memory blocks for processes.

Requesting a memory block is shown in pseudo code in Listing 1.4. First a mode switch to kernel mode is made. After the mode switch, a check is made to see if any memory blocks are available. If there are no available memory blocks, the process is moved to a blocked state and the processor is released. If memory is available, the memory block is popped off of the free list. The block index is retrieved and the appropriate memory allocation bit is set high. Finally, the memory block address is returned.

Listing 1.4: Pseudo code for requesting memory blocks

```
void* request_memory_block(){
   mode switch to kernel mode

if no available memory blocks:
    running process state = blocked on memory
    release_processor()

else:
    pop block of memory off the free list
    get block index
    set corresponding bit in memory allocation field to 1

return address of block
}
```

1.3.5 Release Memory Block

Releasing a memory block is shown in the pseudo code in Listing 1.5. First a system call is made using the address of the memory block as a parameter. After the mode switch is performed, a check is made to determine the index in the allocation field of the block. This index is used to see if this block is currently allocated. If it is not then the system returns RTX_ERROR. If the block has been allocated then the block is pushed back on to the free list and that bit in the memory allocation field is set back to 0. Next, a check is made to see if there are any processes currently blocked on memory. If any are found, the first blocked process has its state set to ready and RTX_SUCCESS is returned. If there are no processes blocked on memory then RTX_SUCCESS is returned right away.

Listing 1.5: Pseudo code for releasing memory blocks

```
int release_memory_block(void* memory_block){
   mode switch to kernel mode

if memory block is not allocated:
    return RTX_ERROR

else:
   push block back on to free list
   set correct bit in memory allocation field to 0

   if there are processes blocked on memory:
      set state of first blocked process to ready

   return RTX_SUCCESS
}
```

1.3.6 SEND MESSAGES

The primitives send_message(...) and receive_message(...) are used by processes to send and receive messages between them. Each process has its own message queue which is setup upon process initialization. When a process sends a message it is enqueued to the message queue of the receiving process. When a process attempts to receive a message it polls its own message queue.

Listing 1.6 describes the functionality of <code>send_message(...)</code>. First, a system call is made with the process id of the receiver and a pointer to the message envelope. The system call then switches into kernel mode. Once the mode switch is complete the message is then pushed on the end of the recipient's message queue. There is no size limit on the message queue so this will never cause an error. A check is then made to see if the recipient process is currently blocked on receiving messages. If this is the case the state of this process is set to ready. Then <code>RTX_SUCCESS</code> is returned.

Listing 1.6: Pseudo code for sending messages

```
int send_message(int process_id, void* message_envelope){
   mode switch to kernel mode

  push message on to end of message queue

  if receiving process is blocked on messages:
      set state of receiving process to ready

  return RTX_SUCCESS
}
```

1.3.7 RECEIVE MESSAGES

Pseudo code for receive_message(...) is shown in Listing 1.7. A system call is made to switch the system into kernel mode. In this system call a pointer for storing the process id of the sender is passed in as a parameter. Upon switching to kernel mode the running process checks to see if its message queue is empty. If the message queue is empty the process is now blocked on messages. The processes' state is changed to reflect this and release processor is called. If the queue is not empty the message is popped off the queue, the process id of the sender is written to the sender_id pointer, and the message is returned.

Listing 1.7: Pseudo code for receiving messages

```
void* receive_message(int* sender_id){
   mode switch to kernel mode

if message queue for running process is empty:
    running process state = blocked on messages
    release_processor()
else:
   pop message off queue
   *sender_id = process id of the message sender
   return message
}
```

1.3.8 Delayed Send

The delayed_send(...) primitive queues a message to be sent after a specified delay. Messages are put onto a internal queue that holds all delayed messages regardless of which process they belong to. Messages in the queue are ordered by send time, with the soonest at the front of the queue. This way, the check to see if a message should be sent can be run in O(1) time.

This function takes three parameters: the receiving process ID, a pointer to a memory block containing the message, and the delay time in milliseconds. After a mode switch to kernel mode, the parameters are checked to make sure there is a valid receiver id and delay value; invalid parameters return an RTX_ERROR. If this check passes then the message is inserted into the correct spot in the delayed message queue.

Each time the timer i-process runs, it checks the head of the delayed message queue to see if a message should be sent. If so, the message is dequeued and forwarded to the correct process and the head is checked again. The pseudo code for the delayed send is in Listing 1.8. The pseudo code and implementation information for the timer forwarding is shown below in the timer i-process section.

Listing 1.8: Pseudo code for delayed send

```
int delayed_send(int process_id, void* message_envelope, int delay):
    switch to kernel mode

if (receiver_id is invalid || delay is invalid):
    return RTX_ERROR

else:
    set message sender id
    set message receiver id
    set delay information
    insert into delay queue

return RTX_SUCCESS
```

1.4 Processes

1.4.1 Null Process

The null process was implemented to adhere to the project specifications. It has a priority of four and a process ID of zero. The process method is defined as an infinite loop that constantly calls release_processor(). It is added to the process table through a call to init_processes(...). As this process is required to always be at process ID zero, care should be taken to ensure that this is not overwritten by other processes in the initialization methods. This process is outlined in Listing 1.9.

Listing 1.9: Pseudo code for the null process

```
void process_null() {
   while (true):
      release_processor();
}
```

1.4.2 KCD Process

The process_kcd() blocks until a message is received. Once it receives a message, the message type is checked to see if it is either key input or command registration. If it is neither, the message is released.

When the message type is key input, the message is checked to see if it matches to a previously registered command. If a match is found the message is forwarded to the registered process for that command.

When the message type is a command registration, the PID of the registering process is saved along with the command itself. The command character is passed in the message body. The pseudo code for the KCD can been seen in Listing 1.10.

Listing 1.10: Pseudo code for implementing the KCD Processes

```
void process_kcd():
    while(1):
        receive a message
        if (message type = key input):
            if (message body = registered command):
                 send message to registered process
        else if (message type = command registration):
            save the PID and command to be registered
        else:
            release message
```

1.4.3 CRT Process

The process_crt_display() blocks until a message is received. If type is correct, then the message data is sent to the UART and the message is released. Pseudo code for the process can be found in Listing 1.11.

Listing 1.11: Pseudo code for the CRT process

```
void process_crt_display():
    while(1):
        receive a message
        if (message type = output || message type = key input):
            send message data to uart
        release message
    }
}
```

1.4.4 UART I-PROCESS

The UART i-process is run in response nice to both transmit ready and receive ready UART interrupts. After either of these interrupts fires, a context switch is immediately made to the UART i-process. Once it runs, the UART status register is checked to determine whether a read or a write is to occur.

When reading in data, all characters are appended to a buffer until a carriage return is read in. At this point, a null terminating character is appended. A check is made to determine the first value in the string buffer. If it is a percent (%), a message is created with the string buffer copied into its data field. This message is sent to the KCD. If it is an exclamation mark (!), the string buffer is sent to the UART debug decoder. After this, the character read in is echoed out again through a transmit interrupt request and interrupts are re-enabled.

If it is a write, a character is written to serial port and transmit ready interrupt is masked. If a carriage return was written, then a newline character is also queued to be written. A special case is considered for when the message type is specified to not require any newlines. Pseudo code for this process is below as Listing 1.12.

Listing 1.12: Pseudo code for the UART I-Process

```
void i_process_uart():
   while(1):
       determine uart state
       if(state = read):
          read in character
          append character to string buffer
          if (character = carriage return):
              append null to string buffer
              if (buffer[0] = '%'):
                  create a new message
                  copy string buffer into message data field
                  send message to KCD
              else if (buffer[0] = '!'):
                  send string buffer to uart debug decoder
           echo the in character by triggering a transmit interrupt
          enable interrupts
       else if (state = write):
          write character to serial port
          mask transmit ready interrupt
          if (character = carriage return AND requires a new line):
              print newline
       release processor
```

1.4.5 Timer I-Process

The i_process_timer() process runs immediately in response to timer interrupts. Upon receiving an interrupt, this process performs two tasks. First, it increments its internal time counter. Next, the delayed messages queue is checked to see if there are any messages to send out. All messages that were scheduled to be sent at the current time or sooner are sent. At this point, this process will relinquish control to the processor. See Listing 1.13 for the pseudo code for this process.

Listing 1.13: Pseudo code for the UART I-Process

```
void i_process_timer():
    timer = 0
    while(1){
        release processor
        increment timer

    if(delayed messages queue is not empty):
        while (queue head send time <= current time):
            remove message from delayed messages queue
            send message to original receiver</pre>
```

1.4.6 Wall Clock Process

The process_wall_clock() is used to display the current OS time on UART1. This clock is given an initial time by sending the %WS command and is updated every second. Clock time is printed until the %WT. Internally, the current time is stored in seconds.

The wall clock receives time updates by repeatedly sending delayed messages to itself. Every time it receives one of these messages, it updates its internal clock, prints out the time, and sends itself another delayed message. The delayed messages are sent with a one second delay. Once the internal clock reaches 86400 seconds (24 hours) it is reset to 0. These messages are only sent if the wall clock has been started with the %WS command.

When the wall clock receives a message from the KCD process it parses the command and performs one of two actions. If the command was \%WS, it parses the time from the command, sets the internal clock, and sends itself a delayed message. The user input is validated, and if it does not pass the clock is not changed.

Pseudo code for the wall clock process can be seen at Listing 1.14.

Listing 1.14: Pseudo code for the wall clock process

```
void process_wall_clock():
   while (1):
       receive message
       if (sender_id = wall clock pid):
          increment clock
          if (clock = 86400):
              reset clock
          if (clock is currently on):
              send a delayed message to itself with a delay of one second
              convert clock to hours, minutes and seconds
              convert hours, minutes, seconds to time string
              send time string as message to CRT
       else if (sender_id = KCD pid):
          if (%WS):
              if (clock is currently off):
                  send a delayed message to itself with delay of one second
              parse string and validate input
              store hours, minutes and seconds
           else if (%WT):
              turn off clock
       release message
```

1.4.7 SET PRIORITY COMMAND PROCESS

The process_set_priority_command() is a process that allows the user to change the priority level of any process through a command. This process accepts data in the form %C process_id priority_level. When the process is initialized it registers the %C command. It then waits to receive a message. Upon receiving a message it skips the %C characters and begins parsing the data. While parsing, the process id of the process whose priority is to be changed and the new priority level are extracted. Checks are made to ensure that proper process ids and priority values were provided and that nothing else was entered after the priority value. A kernel function call of set_process_priority(...) is then made using the parsed process id and priority value. This function call is responsible for the actual changing of the priority level. The memory block and the processor are then released. Pseudo code for this process can be seen at Listing 1.15.

Listing 1.15: Pseudo code for the set priority command process

```
void process_set_priority_command():
    register %C Command

while (1):
    receive a message
    skip %C in message

    parse process id
    validate process id

parse priority level
    validate priority level

validate line endings

call set_process_priority()
    update the priority level of the specified process

release memory block;
    release processor;
```

1.4.8 Test Processes A, B, C

The system also has three test processes implemented. These processes are used to stress test our system by depleting memory blocks. Process A requests a memory block and on receiving one sends a message to Process B. Process B receives the message and then sends the message to Process C. Process C then gets a message and checks if the number of messages it has received is divisible by 20. If it is it prints out "Process C" to the UART1. Then the process hibernates for 10 seconds. All of these processes loop forever inorder to deplete memory. In order to have these processes work properly within our system Process C was assigned a priority of 1 and the other two processes were assigned a priority of 2.

1.5 Software Interrupt Handlers

1.6 HARDWARE INTERRUPT HANDLERS

1.7 Hot Keys

1.8 Initialization

1.8.1 RTX INITIALIZATION

The RTX initialization happens in three phases: process, priority queues, and interrupts. Pseudo code for all of these phases can be seen in Listing 1.16.

The process initialization happens in <code>init_processes()</code>. For each test process, a PCB is created based on the process table supplied by the test cases. This PCB is then added to the kernel's own process list but not added to a priority queue yet. Then, for each process in the kernel's process list, a stack pointer is setup and a exception frame is added to the process' new stack. The format/vector word portion of the exception frame is set to 0x4000 to represent a 4 byte aligned stack and the SR portion is 0x0000. The program counter in this frame is set to the entry point of the process.

Next, priority queues are initialized. The data structures are already allocated but are not initialized. To ensure proper operation, the queues are put into a consistent empty state. After the queues are setup, the processes are added to appropriate queue.

Finally, the interrupts are setup. First, the vector base register (VBR) for the interrupts is set to memory location 0x10000000. Next, the soft interrupt for system_call() is installed to the VBR at vector 0.

Listing 1.16: Pseudo code for RTX initialization

```
void init() {
   init_processes()
   init_priority_queues()
   init_interrupts()
void init_processes() {
   init_test_processes()
   add null process to process list
   for each process in process list:
       initialize stack pointer
       push PC portion of exception frame onto the stack
       push F/V and SR portions of exception frame onto the stack
void init_test_processes() {
   for each test process:
       setup PCB
       add to process list
}
void init_priority_queues() {
   for each process:
       add process to correct priority queue
void init_interrupts() {
   initialize VBR to 0x10000000
   install system call ISR at vector 0
```

]}

1.8.2 RTX Initialization of Memory Management

The final phase of the RTX initialization is the memory management phase. Memory blocks are allocated beginning at the start of free memory. The function call $init_memory(void*memory_start)$, as seen in Listing 1.17. A free list is used to implement linking and management of the memory blocks. A free list is a singly linked list that stores the address of the next free memory in the first four bytes of the current memory block. The only pointer required is to the head of this list. Push and pop operations can be done in O(1) time. Over-allocation and double deallocation prevention is handled by a bit field containing a bit for each memory block. When the memory is allocation the associated bit is set to 1 and for when it is released it is set back to 0.

Listing 1.17: Pseudo code for RTX initialization of memory management

```
void init_memory(void* memory_start){
   head of memory = start of free memory + (number of memory blocks - 1)*(size of memory block)

for each block in free list:
    store address of next free memory block in current block
   initialize the memory allocation bit field to 0
}
```

1.9 IMPLEMENTATION

Major Design Changes

MEASUREMENTS

LEASONS LEARNED